THE THEORY AND PRACTICE

OF

MODERN LIGHTING

THESIS FOR THE DEGREE OF E. E.

Marshall George Houghton

1931

THESIS

Electric liftiling

Wagomword & Co
LIBARTY BOOK BINDLES
LIANSING MICH

Ele

dried enjurerry

OF,

mountain and manual

A whisis Sabmitt a to the Faculty of the middle Smann Sciences

01

Agriculturs and Applica leisnes

aarshall deorge_Houjhton

Unnaicate

ior the

Professional Degree

of

Lloctrical Enginer

THESI-

3 71 19

of modern illumination and a plantical method of decign in a clear and compar form with employmentations of the theory, processor, and limits of decign. The ground assigner,

In the proporation of this work the author found it convenient to treat the subject in the following number. First, a discussion of the immediate concepts, units of measurement and their application; seemed, the principles of light control and their bearing on the linal results; third, the requirements of modern in matrial and commencial interiors, and the Seeign to fill these reads; sounds, the did thing and emberier illumination, its resign and application. The prints are included that illustrate the various incommentals and their practical exclications.

There are a great many picture a public and area time to time which show the practical as well as the adeprisingle beautiful street: that may be obtained by painting with light. The reader, in thavelling around, will can many highling installations which he will wish to analyze; also now lighting problems to devolop. Those may be readily tone by nollowing the methods outlined in this book.

who withor found it impossible to becare Original photographs of installations in Difficient name of to illustrate that the same of lower so a great many commercial piets, a have been incorporated in the amounting the

appendin also contains outs of many cloudlight projectors and other lighting finters or derived to in
the design proud we. This is not a coupl to reformed
book on units but each is representative of the game
trangelish in the chosen.

the steering adjustment of the contribute of the limit of the steering adjustment that so the contribute on their policitis, and critical section of the contribute of their sections of the contribute of the con

marmiall w. not hom

omtroit, sichigan aug 1, 1814 The Theory and Practice of Lobern Lighting

Table of Contents

- 1. Introduction.
 - A. Scope of Trustise.
 - piccustion of modern standards and methods of obtaining these intensities.
 - 2. Engine ring data on many "model Layouts".
- 2. rundamentals or Illumination.
 - A. Fundamental Concepts.
 - 1. Units of Lastrement.
 - 2. Leilection Factors.
 - J. Photomutiy.
 - 4. Candlipower Distribution Curve.
 - 5. Footcundle L agarements.
 - B. Principles of Light Jontrol.
 - 1. Unaracteristics of Laterials.
 - a. R ilecting and Reinsching Durances, motal, Glass, Paintid Durances.
 - 2. Enrect of maintenance and Color of Surroundings on Resultant Illumination.
 - a. U meral Jonei derations
 - b. Depreciation of the highting of tem.
 - c. Fleaning. Copts and Irequincy.
 - a. mithodo or Uleaning.

- c. Leonomics of Proper Eminting.
- i. Willecting Properties of white and colored raints.

Desiling, wall and illocr colors. Depreciation of These Paints.

- g. Desiralla Finishes for
 - 1. Industrial Plants.
 - 2. Uffices. Schools and Stores.
 - 5. Residences.
- 2. Assentials of Apaern Indoor Illumination.
 - A. Quality of Illumination.
 - 1. Glard, Shadows, etc.
 - a. Lighting Horizontal and Vertical Surfaces.
 - B. Quantity of Illumination.
 - 1. Present Standards of Intensity.
 - 2. Choice with reference to Amount the Tye Jan Use.
 - C. Choice of a Li, hting system.
 - 1. Digect. Somi-indirect. Totally Indirect.
 - a. Dependent on Construction and Use of Euilding.
- 4. Home Lighting Fundamentals.
 - A. General Requirements.
 - s. Requirements for Individual Rooms.
- b. industrial and Commercial Interiors.
 - A. making a Cuita le Layout.
 - 1. Location of Outlets, Adequate wiring, spacing, mounting Height, Typical Larouts.
 - 2. root vanales Required. Discussion and Tables.

- 5. Room Efficiency and Reflector Characteristics.
 - a. Room Index.
 - b. Goefficients or Etilization.
- 4. Lamp Size Lumen Cutout Accospary.
 - a. melative dinicioncy various Lamb Diwes.
- B. Cove Lighting.
 - 1. Application and Installation.
 - 2. Lithods of Computation
 - 3. Typical Layouts.
- U. Special Interiors
 - 1. Show windows.
 - a. Corner windows.
 - b. Long Marrow Windows.
 - c. Island windows.
- 6. Floodlighting.
 - A. General Discussion on Scope and Use of this Type of Illumnation.
 - B. Direct Illumination.
 - 1. Building Anteriors, Monuments, Fountains, atc.
 - U. Opace or Area Lighting.
 - 1. Construction and mailroad Classification Yards.
 - 2. rootball rislds and mecreation centers.
 - 8. Airport Lighting.
- 7. Summary
- 8. Appendix.

This contains many tables, graphs and charts.

Also Flasprints of present Model Installations ".

"Light is the essential condition for Vision."

Webster's Dictionary

Changing the amount of illumination on a rotating disc or wheel apparently changes its speed of rotation. Under low illumination the disc appears to rotate rapidly; the geometrical designs on its face are blurred and indistinct. When the illumination is increased there is apparently a pronounced slowing down of the disc, the patterns becoming distinct. The truth illustrated here is fundamental: namely, that it takes less time to see under high illumination than under low—that there is a time factor in the process of seeing, just as there is a time factor in taking a photograph.

Saving time, crowding extra seconds into every minute, is the common objective of efficiency effort. We do it by substituting machinery for hands, and orderliness for lack of system; but wherever human eyes are used, if the light is inadequate, the hour is not long enough for the work to be accomplished. The eye in its camera action is forced to take time exposures instead of snapshots. These exposures are taken thousands and thousands of times a day, and the extra fraction of a second for each exposure spells an accumulated loss of half an hour or so during the period.

Ample diffused illumination on the work saves this time

and with less, rather than more, effort on the part of the operator.

comparatively recent years, and although it is quite generally conceded to be desirable, there are new who entirely comprehend how the accompanying benefits are derived. Many curves have been drawn by various authorities and research men that present basic facts which provide a direct link between light and time - between better illumination and the increased production and decreased accidents which have invariably resulted. Several of these curves and a complete discussion of the results are included later as an aid to choosing the correct value or amount of light needed for a given kind of work.

in addition, good lighting has numerous other advantages that cannot be expressed numerically, but which are none the less real and important. The marked improvement made in the general appearance of a room, the cozy comfortable atmosphere created in the home, the stimulating enlivening influence exerted in the store, the office and the shop - these are valuable by-products of proper illumination.

It is readily seen that the subject of illumination has a direct bearing on the health, wealth, and happiness of practically every living person. It follows that great benefits can be derived from the use of the know-lodge we have in this line, that those individuals who have

the most information at hand will be best fitted to benefit mankind.

For some time the need has been felt for a more comprehensive work to cover the several phases of illumination, at least in a general way, and give examples of actual installations. much of this information is now in print but can only be found in the catalogs of the various companies who either make installations or sell the equipment. much of this data has been published in current magazines or pamphlets at the time of the first showing. in order to get a cross-index or reference library at the present time one must have all these catalogs, pamphlets, and leaflets, as well as current magazines and trade literature on hand. It is evident to even the casual reader that to efficiently use such a mass of information one must have a very thorough knowledge of the products of the various manufacturers and their methods of using the same in order to turn with any degree of certainty to a catalog and get engine ering data and me thods on any one type of installation without wasting a great deal of time searching through irrelevant material.

It would be a very ambitious text, indeed, which attempted to completely cover the subject of illumination or even one phase of it, giving due allowance to the special cases which arise; so this thesis has been limited to a statement of the fundamentals in the various fields.

explanations of these factors, and one or two representative layouts as examples. This, it is hoped, will be of value to the student who is primarily interested in how things are done and to the design engineer for use as a basis to make new and varied layouts in fields which may not be wholly familiar to him. The writer has referred freely to the most recent commercial information on the subject and assembled sufficient data to make workable the formulae and graphs given under the separate titles. Additional data may be had from many of the companies mentioned in the bibliography.

As the trend goes from low to high and constantly higher levels of illumination the architect and designer are called upon to justify the increased operating expense and increased first cost. A large number of tests have been run in industrial plants to determine the relation between illumination and production, other factors being kept constant. In every case, increased illumination has increased the production for beyond the added lighting cost.

One such investigation was completed not long ago in the Inspection Department of the Timkin Roller Bearing company at Columbus Ohio. The number of bearings inspected per operator per hour was found, first under the old lighting system (providing an average of about five foot-candles on the work) and then under well designed systems providing 6,13, and 20 foot-candles.

unusual care was taken to prevent any factors other than illumination from influencing the results. During the ten weeks of the test the humidity and the interior temperature were kept practically constant, and the employees did not know their production was being investigated.

The results of the test furnished proof that for the class of work carried on in the inspection bepartment investigated, the production was materially affected by the illumination supplied. without exception, the production increased when the illumination was raised and decreased when it was lowered.

Under the old glaring lights, which gave only about 5 foot-canales on the work, the number of pieces inspected per operator per hour was 408. Under a well designed system providing 6 foot-candles, with a minimum of glare and specular reflection, the number of pieces inspected per operator per hour was 424, representing a 4% production increase over that obtained under the former faulty illumination of about the same foot-candles. Likewise. increasing the illumination from 6 to 13 foot-candles. with a well designed system, resulted in an output of 440 pieces per operator per hour, which was an additional 4% increase, and when the illumination was raised to 20 footcandles, the production increased to 458 pieces per operator per hour. representing a further 4.5% increase in production. rhus comparing the 20 foot-candle system with the one originally in use a 12.5% increase in production is found.

Granting that this has occurred we must now turn to the economics of the situation. The cost figures for the rimkin installation are:-

fixed charges, etc.) new 20 toot-candle installation \$\text{pot} 0.32 \text{ per hr.}\$

Cost of Lighting, old 5 foot-candle installation \$0.4 ""

Added cost of better lighting .28 " "

nourly total wages of 44 Inspectors 13.20 " "

Hourly saving to company through a 12.5% production increase 1.47 " "

Thus the saving to the Company is over five times the added cost of better lighting, and proves that the money spent on this improvement was a very good investment.

It is interesting to investigate this case from another angle to see what the increases in production were, compared to the added lighting cost in percent of pay-roll.

After this correction is made, and using the old lighting of 5 foot-candles as a standard, we find that with 6 foot-candles of new design lighting an increase of 0.5% in light cost provided a 4% increase in production; with 13 foot-candles a cost increase of 1.3% -

an 8% production increase; and with 20 foot-candles the lighting cost increased the pay roll 2.1% but provided a 12.5% increase in production. This easily proves that the lighting changes will pay for themselves many times over.

In addition to assisting the work, good lighting has highly beneficial influences in other phases of everyday lite. In the commercial field, the attracting power of the brightly lighted show window has been demonstrated repeatedly, and within the store good illumination not only assists the customers in selecting the merchandise wanted, but its cheerful atmosphere builds a good will and stimulates the desire to buy.

Insufficient illumination is the direct cause of over 17% of the night traffic accidents. Adequate street lighting avoids this loss, besides decreasing crime, facilitating traffic movement, and generally arousing civic pride.

defective vision, and to prevent eyestrain when studying, the school and the home should have ample light. In addition, the home may be greatly beautified by the use of light for decorative effect.

These are only a lew of the many reasons why illumination has come so rapidly to the front during the past lew years; the reader can furnish many others.

Now comes the startling statement from Mr. Symmonds of the Symmonds Saw Co., announcing construction plans for the coming year to include one large building with ground floor area of over b acres (2 city blocks) to be built without windows, and illuminated entirely by electric lights 'because electric lights are so much more satisfactory, cheaper in the long run, and furnish even illumination far superior to the ever changing value of sunlight obtained through windows that are always getting dirty and frequently breaking", to quote ar. Symmonds. A percentage of ultra violet light will be added to make the working conditions more healthful and forced ventilation will furnish the men with washed air of the proper moisture content. Truly this is a wonderful age, and the trend toward "manufactured ideal conditions" continues on all sides.

rundamentals of Illumination.

Without light, the most important of the senses which bring information from the outside world, that is the sight sense, is useless, for without light even a perfect eye is blind. On the other hand, the use of light determines what kind of service we can get from

our eyes, because it is a well known fact that through bad lighting the eyes become impaired and defective.

If one shuts his eyes, he can easily realize how much of his knowledge of what is going on in the world depends on light, and conversely, if he looks at the sun for an instant, he realizes how annoying and harmful a glaring light can be.

The process of seeing is not fully understood by everyone, and a short statement of the facts will give a basis upon which future work depends. Suppose the sun is shining on a building; - because of the light rays one can see its size, shape, and the color of the walls, window sills, etc.

the sun pours upon it a great many energy waves, including light waves, and instead or stopping or absorbing all the rays, each individual part of the building reflects and scatters a portion of the rays falling upon it, and absorbs the rest. As a result of this scattering, some light from all parts of the building in the field of view falls upon the eye; furthermore, the parts of the building appear in their characteristic colors. For example, the brichs appear yellow because in general they absorb relatively few of the rays of wave lengths which are capable of giving the impression yellow. The eye in turn conveys the message to the brain that the bricks are yellow. In the same way, the prown mortar absorbs most rays except a particular combination of waves which make

up the color brown, and when these are reflected to the eye. they convey the impression that the mortar is brown. If there are any parts of the building which absorb practically all of the sun's light that ralls on them. with the result that no visual impression is made, those parts are called black. The white portions of the building reflect nearly all of the light that falls upon them equally for all wave-lengths. and it is for this reason that the pillars appear white. The shape and form of the building and its parts are made evident by the varying amounts of light falling on the different surfaces and the percentages of this light which they reflect toward the eye. The pillars appear round only because the eye has become accustomed to recognize certain gradations or light and shade as being characteristic of round objects.

Again the amount of light available has much to do with how much we see and how readily we see it. when called upon to examine the inner workings of a watch, one almost always moves over to the window to get maximum illumination. Also in playing tennis in the late afternoon, we remember that the ball was clearly seen in our opponent's hand, but after it was served and in motion, it disappeared entirely, or seemingly so, until it bounced at our reet. This shows that the illumination was inadequate for moving objects of this size.

These factors must be made use of in ilocalighting of buildings, especially if color is used, in lighting of airports, tennis courts, or paseball diamonds, as well as interior work. In this highly complicated process of seeing which the eyes are performing constantly, it is well to remember that for both natural and artificial illumination an object is not seen as a result of the light which travels direct from the light source to the eye, but only as a result of the light which travels first from the source to the object looked at and from thence to the eye.

Units of measurement -

THE CAMPLE: -

some time ago, when new light sources began to supersede the candle, it was most natural that the illuminating power of these new sources should be expressed in terms of the candle, which was familiar to all. The first comparisons were made by setting the two lights up in the field of view and gauging the difference by looking from one to the other, the most natural direction in which to look at the sources being the horizontal. While there are any name r of directions one may look at a sou ca, the light power in a horizontal direction was made the basis of comparison, and the storage neither that in this direction from a candle made according to a stain definite specifications

a candle. The newer lights as they came out, were rated according to their strength in this same alreading and were stated to give so many candles, a 20 candle lamp being 30 times as strong (or having an intensity 20 times as great) in a horizontal direction. This rating of a lamp is now made by a device known as a photometer, a description of which is included later.

One very essential point to remember in this connection is that the condle power of a lamp represents its intensity in one direction only. It has been customary for years to rotate the lamp about a vertical axis while the candle power was being determined and the result was known as the mean or average horizontal candle power. Late commercial insormation shows, however, that with modern filament design and inside frosted bulbs the dead spot has been reduced so for that it is no longer necessary in practice to rotate the source while measuring its intensity.

One important conclusion must be drawn, however, and that is that the candle power of a source does not noces arily give an indication of the total quantity of light emitted by the source. For example, an automobile headlamp may produce a beam with a maximum candle power of 100,000, the source being a 21 c-p bulb. The reader is familiar, how ver, with the very efficient reflectors developed during the past two to three years which concentrates practically all of the emitted light into a narrow beam, running the beam candlepower quite high while the source c-p remains low.

Assume that a source is giving one candle in every direction, and that this course is placed at the center of a sphere painted black on the indide and having a radius of one foot. If now an opening is out in the sphere some of the light will escape. The quantity of light allowed to occar, may be varied by varying the size of the opening, with the candlepoter of the source and the radius of the sphere remaining fixed. It tollows that if some definite size opening is as uned, a definite quantity of light which may by used as a unit for measuring quantity will result. The simplest area or unit to assume is 1 square foot, and it has been established that the amount of light escaping shall by considered the unit of quantity, and is called a lumen. Thus a permanent unit for the measurement of the quantity of light has been established. If the area of the opening is doubled, the light escaping will be 2 lumens; if the area or the opening is 1/2 a square foot the light escaping will be 1/2 a lum n. Now, since the total surface of the sphere having a radius of 1 root is 12.57 square feet, removing the sphere entirely there would be equivalent of 12.57 openings 1 toot squere and the total light emitted tould be 1... 17 lumens. A value of 12.5 is sufficiently accurate for most practical purposes, and is a convenient figure; dividing the mean spherical candle power by 8 and multiplying by 100, the lumen output is obtained directly.

A lumen may also be defined as being equivalent to the quantity of light intercepted by a surface of 1 square foot, every point of which is at a distance of 1 toot from a source of 1 candle.

Both the lumen and candle are used to measure the cause, these units applying to the light source itself and not to the point where the light is utilized. To measure the amount of illumination on a deak, book, newspaper, or other working plane, there is a unit called a foot-candle. A foot-candle represente an amount of illumination equal to that produced at a point on a plane 1 foot distant from a source of 1 candle and perpendicular to the light reps at that point. Now if the surface is not perpendicular to the incoming beam of light it is evident that the light is appead over a larger area hence the intensity on a plane perpendicular to the beam is 1, and the new plane makes an angle A with the plane perpendicular to the beam, that the intensity on the new plane is 1 x cos A.

The level of illumination measured in foot-candles is the measurement most intimately associated with everyday use of light, and it is a measurement which the eye either consciously or unconsciously is making whenever the faculty of vision is being employed, because the number of foot-candles there are on a working plane, all other things bring equal, determines directly whether or not there is sufficient light. Some time if you would like to get a working knowledge of what a root-candle of illumination is, just hold a newspaper approximately one foot away from a candle and read it for ten minutes. There is a definite reacon for adding the time limit. At first the illumination may seem adequate but very soon you will wish for more light.

Inasmuch as the source of illumination is very seldom as small as one candle-power and the distances are greater than one foot, with much larger areas, an equation must be set up to express the change in one with respect to another.

The first law considered will be the relation between the change in the candle-power of the source with a fixed distance and area. It may be stated as follows: - The amount of illumination on a given area located at a fixed distance from the source varies directly as the intensity of the source. The proof of this truth is very simple. Suppose an area is illuminated to an intensity of 1 foot-candle by a five candle power light sourse. If now the five candle nover source is removed and replaced by a 10 candlebower light, the intensity on the area will be 2 noot candles, or twice as much as before. The 10 candle youer light will emit twice as many lumens as the b c-p unit, hence twice as amny lumens will be intercepted by the given area at the same distance as in the hirst case, and the intensity will be twice as great. In like manner, in a 25 c-p source is used, the intensity will increase live rold.

The second relation is commonly known as the inverse square law. The inverse square law is the most widely known of all optical laws and is treated in all elementary physics books. Briefly stated it is,: - The amount of illumination received on an object varies inversely as the square of the distance, between the object and the

source. The explanation of this basic truth is as simple as the first one. With a source of 1 candle, the intensity on a plane 1 foot distant is one foot-candle. Let this area of one square foot astermine the limits of a beam from the light source. Now move the plane 2 feet distant from the source and the same beam will cover four square feet. Inasmuch as the same number of lumens are in the beam as before and they are spread over 4 square feet instead of 1 square foot, the intensity must be 2 as much as before or 2 foot-candle. If now the plane be moved 3 feet away from the source, the same beam will cover an area of 5 square feet and the intensity will be 1/25th foot-candle. At 5 feet the intensity will be 1/25th foot-candle, etc.

In spite of the fact that this law is the most widely known of the optical laws, its misapplication has led
to many poor lighting installations. In these the
principal error has been in mounting the lighting unit
too low with the idea of getting more foot candles on
the working plane. Lounting a local lighting unit
close to the work is the proper thing to do if the
area to be lighted is small, such as the tool point
of a drill press or lathe, or the needle of a sewing
machine, but in no case should the units of a general
lighting system be lowered to accompodate the apparent
need for more light over a particular point.

The distribution curve of a lighting unit for general lighting will usually show that the unit has

been designed to give a reasonably high concentration of light directly beneath it, but that also a great portion is spread out in somes and at such angles that light is provided in areas at some distance from a point directly beneath the unit. Therefore, for general overhead lighting the units should be mounted as high as is practical with their distribution so that every point in the room will be lighted from several directions. This will reduce sharp shadows as well as give more head room, and the room will be more uniformly illuminated. Local lighting where necessary should be used to supplement the general illumination.

Reference to the second law, first case, in which the surface was illuminated to an intensity of 1 footcandle; by definition this is one lumen. This gives the important relation that it one lumen is so utilized that all of the light is spread over a surface of 1 square toot, the surface will be lighted to an average of 1 foot-candle. This relation greatly simplifies the designing of a lighting installation, for once the number or square feet to be lighted and the root-canalogor illumination which it is desired to provide are known, it is a simple matter to find now many lument must fall on the working plane. It, for example, it is desired to illuminate a surface of 400 square feet to an average of 10 toot-candles, 4,000 lumens must be projected on the surface. This method of calculation is called the "Lumen Method" and has many advantages over the older

"point by point" system as will be seen later when the complete process is outlined.

RIFLECTION FACTORS.

The amount of illumination on a surface in foot-candles should not be confused with the brightness of the surface. A bail or gray surface lighted to an average of five foot-candles does not as ear as bright as a white one, because such a large percentage of the light that falls on the surface is absorbed and lost. A full statement of the situation will read, "The brightness of an object depends both upon the intensity of illumination on it and the percentage of light that it reflects." The ratio between the foot-candles reflected from a surface and the foot-candles directed on it is called the reflection factor of the surface. The following short table shows the reflection factor of a number of painted surfaces: -

Reflection ractors.

White 80%	Sky blue 35%
1vory 70%	Clive Green 20%
Bu11 65%	Cardinal Red - 20%
Sage green 40%	вlаск 5%

Since the ease with which objects can be seen depends directly upon the amount of light they reflect, it is seen that very high levels of illumination must be provided where the materials worked on are dark in color.

and walls of a room will have a direct bearing upon the kilowatts or installed lights necessary to bring the room up to a given level of illumination. The installation of more lights means greater first cost, greater upkeep and greater operating expense.

PHOTOMETRY.

Photometry is a very specialized branch of the science of illumination and must be made the object of a great deal of study in o der to cover all phases of it.

Any reader who wishes to make a study of this subject is referred to specialized physics texts or other books on light and its measurement. For the purpose of this text it is sufficient to know that: - Photometry is the science of measuring accurately the intensity of a lighting source and its distribution around the source.

The simplest type or photometer that can be made may be described as follows: - A vertical paper screen in the center of which is a grease spot is placed between the lamps to be compared. By sliding the screen back and forth a position can be found where the outlines of the spot will vanish and the spot itself will disappear. When this condition occurs, the illumination on both sides of the screen is the same and the intensity of the unknown unit can be found by calculation from the relation; the intensity of the unknown is to the intensity of the known unit as the inverse square of the distances between

the respective units and the screen. For accurate photome-

parison photometers are the same in principle. In this case than the illumination on one side of the screen is greater than that on the other, the spot will appear darker on this side and lighter on the other side, than the surrounding paper. The reason for this is call evident.

FOOT-CANDLE MEASUREMENTS.

It will be noted that in measuring the candlepower of light sources as previously discussed, the illumination on opposite sides of the screen is balanced. Generally, however, the interest is in the amount of illumination itself. or the root candle intensity which is being supplied to a given working plane, and not in the candle power of the sources which supply this information. Devices of lled ioot-canale meters have been developed to read these values direct, their main difference from photomaters being in construction and clibration. In most all cases they are small and easily port ble, their value being to check existing installations for redesign, or verify a new building on an acceptance test. The principle of operation is simple. Asmill inconsescent lamp is concealed in the box at one end of the screen. This illuminates translucent spots on the screen to a high intensity at the lamp and low at the other. The illumination to be me sured is assumed to be uniform over the entire scle. At the point where the spots appear neither brighter nor darker than the currounding scale, it is evident that the

illumination from within is equal to that on the outside and the intensity can be road directly. The scale is calibrated with the lamp within burning at a certain specified voltage and a rheoctat and voltmeter are provided so that these standard conditions can be daylicated each time a residing is wanted.

THE CANDLE POWER DISTRIBUTION CURVE.

The candle cover distribution curve of a lemb or lighting unit is a graphical chart choming the intensity of illumination or light distribution from the unit. The unit is assumed to be the center or hub of a wheel and intensities are measured in all directions around the unit at in ingle, compared to thespoxes of a wheel. These values, then plotted on a circular chart all lines of which radiate from the center, show exactly how much light lawves in any one direction from theunit. These distribution curves were widely used at one time in calculating the illumination at certain distances from the source, but the lumen method of computing illumination was shown to be so such more accurate and simple that the "point-by-point method has fallen into disuse. Distribution curves are now used principally for decign information and for comparing reflectors for a given service from the standpoint of light distribution and light abcomption.

PRINCIPLES OF LIGHT CONTROL.

It is now a common fact that the light from a bare incandescent lamp is distributed in such a manner that it cannot be used under most conditions without a reflector or enclosing plassware. A reflector of suitable design will redirect the light into such angles that it can more efficiently be used. Some times the enclosing plassware also serves this purpose but its chief advantage is in modifying the brilliancy of the light course, diffusing the light to produce a cost and pleasing illumination.

ployed are the direct, indirect, and semi-indirect. In the direct lighting system, the units distribute the light downward into the room or onto the working plane: in the indirect system all of the light is thrown upon the ceiling and reflected from there to the working plane; in the semi-indirect system the majority of the light is thrown upon the ceiling and reflected downward, as in the indirect system, the remainder of the light is distused directly through the fixture to the working plane. The choice between these three is made on the basis of the use of the room, class of service, and available lands - both first co tend overating expense being taken into account. More will be said about this later.

Reflectors and enclosing plassware are made from

three classes of substances: - transparent, translucent, and opaque. Transparent substances transmit a large portion of the light striking them without scattering it. hence objects may be seen clearly through transparent plates. window glass and gold fish bowls are transparent. some lights, especially for outdoor use, are surrounded by a clear glass bowl to protect them against the elements and the light bulb can be clearly seen through them. rranslucent substances transmit light but scatter it so that the outlines or objects cannot be slearly seen through them. A good example of this is the milk white or milky bowls and units that are commonly used for direct illumination. The opaque substances do not transmit any light but reflect and absorb it. Steel reflectors, either polished, enamelled or painted, are good examples of this type of light control. All three types of substances absorb a certain portion of the light rays which strike them, and the radiant energy so absorbed tends to raise the temperature of the unit.

Light may be controlled by four methods; absorption, refraction, reflection, and diffusion. By the use of these methods it is possible to make the light from any source perform practically as desired. To explain these four methods of control one must go back to the fundamental statement which says that a ray of light will travel along a straight line indefinitely until modified or redirected by some outside body or agency. Such modifi-

cation might be by absorption and will vary from a small percent to complete extinction of the beam. It is noticed when a beam of light passes through a piece of dense glass or a cloud of smoke or steam.

. The second form of modification is termed reiraction, and applies to that peculiar property evidenced where light rays pass from one transparent medium to another of different density and a pear to be bont at the point of junction of the two mediums. Refraction makes a fish line appear to land at the moint it enters the water. We know the line does not pend, but the light waves coming from that part of the line under the water are reiracted when they come into the air, thus creating the illusion. The third and best known method is reflection. The redirection or throwing back of 'light from a surface is best illustrated by a mirror or an automobile heallamp or cearchlight "reilector". The fourth form is diffusion, which is the breaking up of the beam and Spren ing its rays in all directions either by passing through a medium or falling upon a surface.

surfaces in use at the present time and their effectiveness. The simplest form of reflection is that which
takes place when a ray of light strikes a polished metal
surface. The angle of incidence is equal to the angle
of reflection in this case and is called regular reflection.
It is easily seen that it is possible to redirect light traveling in any given direction into any other direction by

means of a surface properly placed. While all poliched motal surfaces reflect light in the manner described, they do not reflect it in like amounts. For instance, a poliched silver surface will reflect 50% of the light that is thrown on it, an aluminum surface reflects 60%, and a carbaida plated reflector will return approximately 65% of the beam which impinges on it - the talknes being absorbed and lost. Poliched metal reflectors are used most extensively in equipment where they can be tightly covered to help out the dist, dirt, and fules in the air which will tarkish them and decrease their efficiency. Automobile and railroad headlights, and small flood-lights for airport and advertibing illumination and the best examples in this alloss of equipment.

actoristics to polished metal sariaces, but the commercial type of mirror has silver weeking; thus the light is forced to pass through the glass twice, once approaching and then leaving the silver surface, and the loss in the glass depends on its quality. This brings the efficiency down to about 85% en implies the mirrored glass luss desirable for laboratory wass, even though its deterioration is less than polished metal. Mirrored realectors have the disadvantage that they usually throw brilliant images of the filament on the surfaces illuminated. Practically these images are often eliminated of fluting the reflector or frosting the lamp.

of the light and decre be its efficiency.

much use is made of mirrored plays for reflecting surfaces in the totally indirect type of lighting fixtures, in motion picture machines, floodlights, and show window reflectors.

Dull finished motel reflecting surfaces are favored for certain types of fixtures due to their hight weight and low cost, the more common materials are spun aluminum and aluminum finish metal. Desk lamps, small spots and floodlights are daily examples familiar to everyone. The chief disadvantage of this surface is its ability to quickly acquire a laper of dust and dirt which seemingly cannot be wiped, washel, or surabled clean. The low first cost offsets this disadvantage to a great degree.

ing light and finds a great deal of use at the greent time commercially. It is white or milk-glass, sometimes called opal glass. Its operating properties can easily be explained if we consider it as plain glass with time white particles held in suspension. As a beam of light strikes this glass, 10 to 15 percent is immediately reflected from the polished outer currace, the remainder continues on until it strikes all of the fine particles where it is dispersed in all directions. In the enclosing globe type of fixture where where diffusion is the main objective, the glass should have a maximum transmission without revealing the outlines of the filement or light

bulb; the class is then said to be completely translucent. When this condition exists there is, not even one percent of the light which passes through unchanged. The transmitted light will be detreed about the corporation may bring the edition by of the care up to ab or bays.

Two piece class white are used a great meal in which the class in the upper unit is much denser than text in the lover half and reflects a large percentage of the light pack assumence to give thinker intercity of direct illumination. A could amount of largers escape upward and writing up the intentity on the ceiling. Similar histories and these are often inversed the ased for indirect illumination, the angerity of the light being sent to the chiling first, where it reflects asymmetry to the colling limit, where it reflects asymmetry to the colling limit, where it reflects asymmetry to the corbing plane.

as important as the design of mirrorer place reflectors, and depends entirely on the opporation of the characteristic desired. The only care necessary in the choice of this class of equipment is to be sure that a decree enough place is obtained to reduce the brightness of the light source to a point that a sharp contrast can not be noticed between the unit and its surroundings.

White class is used for totally enclosed units, open reflectors and semi-insirect units for offices, school rooms, some types of industrial units, and general commercial work. The two dried moventages of this reslector

material are in its smooth surface which limits the collection of dust and is easily cleaned, and its property of transmitting a portion of the light which gives a luminous reflector and enhances the appearance of the unit.

Porcelain enamel steel reflectors are well known to the commercial and manufacturing trade as being the basis for industrial lighting units where efficiency can be sacrificed a little to give a more rugged and permanent reflecting surface. Porcelain enamels vary a great deal in efficienty. But in spite of this fact, the units are widely used, the majority being manufactured under the trade name of n.L.M. domes.

sizes of bulbs are made from frosted glass. The glass surface is either etched with acid or sand blasted and unless a very fine job is done, the surface compares favorably with spun aluminum and collects dirt readily. It is also very hard to clean.

wherever it is desired to produce a very broad distribution of light and have a high degree of efficiency, the illuminating engineer turns to a set of refracting prisms. They are the basis of the rresnel lenses used for light house service, street lighting units, railway and traffic signals, and many semi-indirect and direct type of units for public buildings, offices, and schools. This is a more expensive method of light control, but the results justify the expense incurred.

on Resultant Illumination.

Until recently, it was generally thought that after a lighting installation was made it could be completely ignored until a bulk burned out and then a new one would grudgingly be installed. This attitude has changed a great deal, but there is still much good work to be done by the electrical contractor, as well as all others con ected with the industry, in advicing the customers as to the necessity of frequent and regular cleaning. The housewife believes her home would soon become a very poor plact to live unless she cleaned it periodically; offices and stores have their scrub people; factories and industrial plants have regularly employed sweepers and cleaners, but there are still those who do not give the lighting equipment the attention it deserves. The sad part about the whole situation is that just as soon as the intensity drops so low that the men can not see clearly to do their work well, the lighting engineer gets the blame. His good judgment is questioned because of the oversight by those those duty it is to see that the lighting units are cleaned regularly. It becomes, then, the engineer's duty to embody withhis design a suitable cleaning schedule to be followed by the customer in order to maintain the st ndard of excellence which the new building exhibits on its opening night.

It is interesting at this point to review the

results of tests which have been made to determine the actual amount of depreciation that can be expected in normal installations. The intensity in several offices was measured fast after being cleaned and an accurate record kept for a period of six months. By that time 40% of the original intencity was being absorbed by the dirt. A great deal of this depreciation occurred during the first few weeks, so for a period of several months the desks had been receiving only 60% of the light which had been intended for them, and thich could have been obtained at practically no extra cost if a little attention had been paid to cleanliness. Why. then, should lighting equipment be allowed to become so inellicient and place a big handicap on the large percentage of workers who are unlucky enough to be located between the lights where the depreciation is the highest, when a very small amount spent in cleaning will keep the average acticiency close to 95% at least above 90%? It has been pointed out previously that the increased efficiency more than justifies the cost and effort.

There are two big divisions in the causes of falling off of illumination as the time passes; they might be called acquired and inherent depreciation. The first is by far the most serious - dust, soot, flying particles of oil and all other sorts of foreign matter collect on the balbs and amp surfaces. These form a coating thick because of its black and dirty nature

absorbs a large percentage of light which must penetrate it before reaching the work.

classes would give Location - first, Type second, and resign of equipment - third place. It is quite obvious that an installation located in a small or suburban town will have a much lower depreciation than one in a downtown office where soft coal is used as fuel in adjacent buildings. The store will not have anywhere near as much dirt in the air as a machine shop, hence the cleaning ratio will point to the machine shop as the one needing the most attention. In the extreme case shown here the ratio may be as high as 10 to 1. A careful selection of lighting units and paint will help considerably, however.

under the heading, "Type of Unit" it is shown that a steel direct lighting reflector will not depreciate as fast as an indirect unit. The dust does not readily gather on the inner reflector surface, and the reflector is strong and substantial and will stand abuse. A semi-indirect or totally indirect unit will be affected most by dust settling on the upper surfaces and cutting the light rays off short. Naturally, then, these should not be selected for an exceedingly dusty location but will be very satisfactory in the cleaner building.

Since the question of proper maintenance is such a vital factor in good lighting practice, it is most

desirable to examine the firsture with , rest care and see that the choice is one which will be the best for the location in question. Is it of a share that will be addicult to clean? Will a reasonable accumulation of dirt saterially reduce its light output? Are there a great many parts to remove in order to clean the glassware properly and replace the lames? Does the unit assemble easily or are there too many small scresw) clips, etc., so that the time of assembling will be materially increased over that it should be? Is the cleaner out to drap and break the light while trying to assemble it because of the awaward catches, etc.? By care fully answering a series of questions like the fore oing the engineer will be sided in his choice of lighting fixtures, and a more satisfactory layout will result.

There are several methods of clearing which are in use at the present time and it is well to indicate some methods are much better ther others. It is commonly thought that for dry dust a good wiping with a dry cloth cleans the glasswere sufficiently. This is not true however, as tests show that this only removes about 50% of the dirt that a damp or wet rag will. When it is considered that the time involved is about the same for both methods, the difference in results will justify using the water. Soap and water showld be used if grease or other wet accumulations are prevalent. It is well to take extra care and get the glassware

completely dry before putting it back, as damp glass collects dirt very rapidly and much of the benefit of the washing is quickly lost. where the units are mounted high a great deal of time can be saved, as well as an extra trip up the ladder, if an extra unit is procured and cleaned. This is carried up the ladder on the first trip and put in the place of the dirty one which is removed and brought back down to the floor where it can easily be cleaned. It is then exchanged for the next unit in line and so on.

Industrial installations present a more difficult problem, as the fixtures are cuten up in high bays above moving cranes, etc. In such a case it is well to utilize the small fixtures manufactured and sold by a leading electrical catering company which permits of disconnecting the entire unit. support and all. and removing it for inspection and cleaning. in some buildings the units can be placed just above the crane beam and this can be utilized as a 100t walk for relamping and cleaning. As a rule, once a month is sufficient to clean units in such places; however, the most efficient way is to keep track of the intensity with a foot-candle meter and determine the mecessary irequency of cleaning by limiting the depreciation to a reasonable percent. Over all efficiency will improve as the guess-work is eliminated.

Many people do not understand the economics of proper painting, and again it is the duty of the engineer

to impress the fact on all who buy paints that the first cost is not always the complete co.t. When specifying paint, he should be careful not to get a paint with a high depreciation. This is especially true of the ceiling paint which is most important from the standpoint of light reflection. As a guide it is recommended that a plaster ceiling be treated as follows:-

First cost ---- good impervious primer.

Second and third costs ---- high grade lithopone paint (not less than 75% lithopone.)

Fourth cost ---- high grade eggshell enamel.

Entensive tests have been run and it is not out of place to mention the names of some typical high grade paints for the last coat. These are arranged alphabetically by companies and the omission of any prominent manufacturer should not cast reflections on the cultity of his product; the ones named proved satisfactoryon the test.—

Tecmilite - - - - - - - - Dean and Barry Co.

Moore's White Mill - - - Benjamin Moore Co.

Savakota - - - - - - - Chas. M. Childs & Co.

Degraco - - - - - - - - Detroit Graphite Co.

B.P.S. Inside White - - - Patterson - Sargent Co.

S.W. Egashell Mill White - Sherwin Williams Co.

Rich's Mill White - - - - U. S. Gutta Percha Co.

From an illumination standpoint, the walls of a room are not as important as the ceiling, and a less expensive coating wall serve. However the same economies

can be affected on the walls by choosing a high grade paint with a good initial reflection factor as well as a low rate of depreciation. rirst coat - good impervious primer mixed with an equal part of zinc lithopone paint. second and third coats - high grade zinc lithopone paint of which the last should be tinted to the desired color.

more to paint an interior correctly than to apply calcimine or some other paint which depreciates rapidly or has a low reflecting factor, but careful analysis reveals the expenditure is well warranted.

ion factor has upon resultant illumination; if all surfaces of a room were painted black and had no reflecting factor, the illumination on any surface would be only that received directly from the lamps. If all surfaces had a reflection factor of 50%, the illumination would be practically doubled. If the walls and ceiling were painted eggshell or white and the reflection factor raised to better than 90 percent, the illumination would be increased approximately ten times.

rinishes for Industrial Plants

Of late years the industries have been informed concerning the value of paint and lighting by the extensive national advertising campaign put on by the

the paint manufacturing companies. The amount of natural lighting is greatly increased if the interior surfaces are painted light in color; then any light which comes in contact with the walls and floor will be reflected again, around the room, raising the level of illumination appreciably. The change may be as much as from 85 per cent to 10 per cent, depending on whether the surface is a clean white or dark brown and smoke covered.

Surprisingly high utilization constants can be obtained in rooms which are properly painted. with a white ceiling and side walls, and light wood floors (bare), the cross reflections were so numerous that a utilization constant of 1.00 was obtained. The photometer actually measures the same energy more than once. Of course this cannot be expected in practice, but is illustrates how important the colors of the surroundings are in enabling the illuminating engineer to have the maximum amount of light on the working plane for any given current expenditure.

Another important point to note from the readings obtained is that the color of the floor cannot be ignored if much exposed. Light which strikes the floor will be reflected to the ceiling and back again, providing the surface is such that it doesn't absorb all the impinging rays. All of the floor not covered with machinery should be painted as light as is consistent with the nature of

work being carried on. In buildings where the aisle is subjected to heavy or persistent traffic and a real light surface cannot be maintained, it is recommended that these aisle-ways be made as narrow as possible and have distinctly defined borders so the truck drivers will keep within the prescribed limits; the remainder of the floor area can then be painted a more efficient light gray. A good color for this type of work is the well known battle-ship gray which is furnished in several shades.

should receive attention. (It is well understood that a coat of paint will materially lengthen the life of a piece of apparatus.) If this paint is of suitable color, it will serve to increase the illumination. Such a paint should be hard in order that it may not be marred easily; smooth, but not glossy, in order that it may be easily cleaned, collect the minimum dirt, and not give any annoying reflections, light in color that it may increase the useful light in the room. It is desirable that it be impervious to the actions of oils and compounds used as lubricant for drill points and milling machine cutters.

many colors have been tried to find the one best suited for machinery and for most uses a light gray seems to answer the purpose. It reflects approximately 35% of the light which strikes it and yet is dark enough so that linger prints and stains do not show up too much.

Light orange has received considerable tavorable comment and can be recommended where the darker colors are not preferred by the plant owners or operators. It should be kept in mind that proper painting of machinery will also make for safer operation, the shades which generally prevail around slotters, milling machines, and punch presses are eliminated, and the moving parts made visible.

high grade oil paint is desirable, but where white-wash is absolutely necessary, irrequent cleanings will speed production and keep the lighting bills at a minimum. The sidewalls also should follow the same color scheme as the ceiling. The lower part of the sidewall is of less importance in reflecting light, and for purposes of appearance it is eften desirable to have a shade of dark green, gray, or some other neutral color, as finger marks and other disfigurements are not quite so noticeable. The dado is of advantage in another respect also in that it reduces the brightness of the background in the field of view.

A clean bright interior has a decided effect in improving the morale of the workman and it increases the production materially.

Suitable Finishes for Offices, Schools, and Stores

On account of the widespread use of indirect and semi-indirect lighting systems it is always desirable that the ceilings be light in color. A color should be chosen such that its reflection factor is above 50% and much better results are obtained when a 70% or higher factor is installed. The exact tint is determined by the use to which the room is to be put, allowing for proper color harmony.

throughout unless the contract between north and south rooms will not be noticed. A slight bluish cast is preferable in a north room and is obtained in combination with pale clive green to give the desired results. A south room will respond best when the clive green is given a yellow cast. Light buff or cream are very good colors for walls and come next in line. There are cases however, where a greenish tint will give a soft and restful atmosphere which is much to be desired and answers the color question for these rooms. The co-efficient of reflection should not exceed 60 to 65%.

It should be borne in mind, however, that a light colored room is much more cheerful than one finished in dark colors and in many cases dark surroundings will give the impression of bad lighting while in reality there is a high enough intensity on the working plane.

In many places it is well to secrifice lighting economy

to the psychological effect produced on the individuals.

A dark, gloomy interior will always be oppressive and weigh down on one's feelings so it bright and cheerful pupils, customers and clerks are desired, the tendency should be toward the brighter shades.

many lighting installations, will be materially reduced if the artificial lighting unit is viewed against a bright ceiling. Light walls and ceiling tend to spread the caylight around the room and reduce contrasts during the daylight hours. Great care should be taken in specifying glossy walls or ceilings because glare and specular reflections are much more pronounced with this type of surface than with any other.

Desirable Finishes for Residences

Lighting efficiency in the home is not at all important, but the color of the walls and ceilings has a big effect on the pleasing appearance of the rooms.

is a noticeably poor color and lighting units contract so brightly that they are annoying. There is one way to get around a painting scheme using dark colors, and that is to furnish desk and floor lamps in addition to

the central fixture. These bring up the intensity where it is desired and allow the rest of the room to remain dimly lit.

of course, the most desirable finishes are light colored wall paper or paint. Ivory, white, ivory tan, silver gray, cream, pale azure and combinations of these colors are usually considered best for ceilings. The walls follow along with the darker shades of the above mentioned colors. Lately the use of buffs, tans, and light browns both clear and stipple has come to the fore as a favorite interior finish. Paint directly on a plaster wall will have a higher diffusion but a slightly lower co-efficient of reflection. Use should be made of this fact when choosing lamp sizes.

The Essentials of modern Indoor Illumination.

Up to this point, the fundament I concepts of the measurement of light and the means by thich it can be controlled have been stated and discussed at some length. These factors are basic, and a thorough knowledge of them is absolutely necessary to design a satisfactor lighting layout.

quality and quantity are two distinct divisions that must receive special consideration in indoor work, so the discussion continues, taking up these and other necessary features from the design engineer's standpoint.

The quality of illumination ras to do with the distribution, diffusion, and color value of the light; while the quantity is the amount of light, either recessary or already available, on the working plane. There are several divisions under quality, and the first of these is glare.

GLARE.

Clare may be defined as any brightness within the field of view that interferes with vision, causes eye fatigue, annoyance, or discomfort. It is light out of place, and may be direct or reflected, that is, it may come directly from the lighting unit to the eje, or may be reflected from the wall, polished deak surface, mickled machine surfaces, or gladed paper. Clare should always

be guarded against in making a layout and if it becomes evident later should be removed.

Direct glare from a light source is the most common and generally the easiest avoided. Direct glare from a bare lamp is one of the greatest hazards to vision. On this account all lamps of 60 watt size or larger should not be installed without a shade.

ent upon the contrast in brightness between the light source and the background. when meeting an automobile on a dark road, the headlights may be so bright and glaring as to be blinding to the eye, while the lights of the same automobile on a brightly illuminated street in the city would hardly be noticeable.

Locating a unit within the field of view will also increase the glare. Take two examples, one from each extreme. In the rug department of a large store, the rugs will be hung high on racks and the units should be placed back out of the natural line of vision with the rays directed forward to the vertical surfaces of the rugs. A directed type unit such as is used in store windows answers this purpose. An alternate solution is a totally indirect or semi-indirect system with a very dense milk glass unit, which will give the necessary illumination without glare. The second example could well be a shoe store where the brightness of the units is less of a problem, and a unitormly high level of illumination over

the entire floor area is desirable. He knows that the people move about considerably, and their attention is not repeatedly drawn upward, as it would be while inspecting rugs, in such a manner as to include a lighting unit in the direct field of view.

There are two distinct glare points to watch for in artificial lighting. The one is a source of light that feels uncomfortably bright as soon as it enters the field of view. This type or source should never be used for interior lighting. The second, and a much lower glare point, is one which, while not bright enough to cause immediate discomfort, will fatigue the eyes when it remains within the field of view for a period of time. This lower glare point is much more difficult to determine because it varies for different individuals. A good figure to follow is to never let the brightness of a unit which is to be continually in the field of view exceed } candle per square inch of apparent area. A unit which is not to be in the field of view continually may have its brightness increased, the limit being 2 to 3 candles per square inch of apparent area, depending on the color of the background.

to the eyes as a shine or glint of the lighting unit on some polished surface. It is much harder to deal with because it usually comes from some location below the horizontal, and the eye cannot be protected from it easily. Specular reflection, as it is sometimes called,

is most frequently encountered by the reader while looking at the highly polished or glossy surfaces of a magazine, the print in certain sections seeming to fade away into a bright shiny spot or larger area.

Local specular reflection may be relieved and generally removed by changing the lighting source to such a position with respect to the work that the specularly reflected light will be thrown away from the eyes.

The brightness of a reflected image is dependent upon the brightness of the source. Lither change the unit for one which possesses thicker milk glass, thus diffusing the light to a higher degree, or else change the color of the background so that it has a higher coefficient of reflection, reducing the point brilliance to a degree where it ceases to bother.

SHADOWS.

Almost as important a question as glare, shadows deserve consideration when making any lighting layout. In general, shadows are undesirable and should be eliminated. Their most frequent causes are spacing the lighting units too far apart or not using large enough bulbs. Having given large enough bulbs and units properly spaced, shadows may creep in due to an increasingly thick layer of dirt on the fixtures.

in lounge rooms, dens, and some lobbies, soft shadows are restful and pleasing. It is the sharp, black, well defined shadows which should be guarded against.

rhey are the ones which hide projections on the floor or moving parts of machinery and tend to impair depth vision. Large area lighting units tend to eliminate deep shadows, and if two or more units shed light on an area it is almost impossible to have deep shadows.

shadow illumination required in photograph studios or in art museums where statuary and monuments are displayed.

UNIFORMITY OF ILLUMINATION.

In years past the owners of buildings, in their desire to keep the initial costs low, saw fit to allow lighting installations to be made in which proper spacing was not established. instances are on record where workmen situated between lighting units had only one quarter the illumination their neighbors had. who were located under the lights. R.L.M. domes with 200 watt lamps were mounted 10 feet above the iloor, and seven feet above the working plane. These units were spaced 20 feet apart. This gave an intensity on the working plane of 12.5 foot-candles directly under the units. while at points 10 teet away, located between the units, an intensity of 3 foot-candles was obtained. by changing the spacing of these units to 10 feet the intensity under the units was increased to 14 root-candles while that between units was 12 foot-candles, a permissible variation.

stated, viz, in general, the spacing between units shall not be more than one and one-half times the neight of the light sources above the working plane. Closer spacing will be necessary to maintain extra nigh levels of illumination, but the maximum limit stated should not be exceeded, except in special cases, and then with the knowledge that an uneven level will result.

ILLUMINATION ON VERTICAL SURFACES.

There are many places, such as drafting rooms, school rooms, and newspaper composing rooms, where light is required principally on norizontal planes as desk and table tops. It has been the custom to calculate the necessary illumination on the assumption that if the horizontal surfaces received enough the vertical and sloping surfaces would also. Inasmuch as vertical illumination from ordinary units is only about half that of the horizontal, it is readily seen that at times this may be inadequate. For general illumination, the units should have a good distribution in the 60 - 60 - 70 degree zones as well as downward; this will give sufficient illumination on the vertical surfaces.

in art museums, poster boards, show windows and in some industrial applications, such as automobile body painting, etc., where illumination on the vertical plane is desired above that on the horizontal, angle reflectors should be used to supplement general overhead lighting.

COLOR QUALITY OF LIGHT.

it has adapted itself to function best in ratural light.

Matural light varies considerably in quality throughout
the day, but should be the standard of reference with
artificial units, the same as daylight levels of illumination represent the standards for industrial plants.

The ability to see objects in their true colors is important when one is matching colors of materials or trying to get a true conception of an original work at an art exhibit. Colors help a great deal in distinguishing one object from another, such as a brass bushing on a polished steel plate. A black and white picture will not always show these objects one against the other. Since in a great many applications it is difference in color which renders objects readily recognizable to the eye, color discrimination is important from a utilitarian standpoint. Another factor to consider is the unfavorable impression created by unnaturally-colored light; this must be guarded against also.

carried on with the color results always in mind until now all of the colors of daylight are present, though not quite in the same proportions as in daylight. The changes in the colors of objects when viewed in this light are not serious. For some operations, however, it is especially desirable to approximate natural light as closely as possible. The mazda daylight lamp, with a

blue glass bulb produces a light of atternoon sunlight in quality. This entails an absorption of about 55,0 of the emitted light. Using the same bulb with special blue glass enclosing globes, the light approximates noon sunlight: 60% of the emitted light is absorbed. The third combination, a projector type unit using a daylight bulb and special enclosing plassware, gives a north sky quality and is used for color matching alone and requires a large expenditure for power as 85% of the light is absorbed. For show windows, clothing, fur, and rug stores, or wherever color is an element in the display of merchandise, the daylight bulb should be used. In industries where the requirements are more strict, such as chemical and textile factories, lithographing and other paper work, and the areas to be lighted are medium in the projector is for very exact work where the areas to be illuminated are very small, such as color matching units on store counters - - hosiery and jewelry counters, and clothes shops. The exact north sky units will satisfy even the most exacting individuals and are the best that science has developed for this work (- except for the mechanical. electrical matching machines which eliminate the human element).

QUANTITY OF ILLUMINATION

The eye is capable of adapting itself to see under illuminations which range from a high level of 6 to 10 thousand foot-candles down to a fraction of a foot-candle. rhrough this wide range good vision is possible. Un a clear, bright day the illumination in sunlight will vary from 6 to 10 thousand foot-candles, and in the shade will drop to approximately 1.000 foot-candles. The other extreme will be found on a clear moonlight night when the illumination varies from 1/2 foot-candle down. An illumination of approximately 100 foot-candles will be obtained indoors by a north window on a clear day. it is readily seen that it will be difficult indeed to provide too much light for the eye as long as it is well diffused and there are no extreme brightness contracts between the surface to be looked at and its surroundings. The problem is to properly control the light.

At the present time the highest recommended illuminations are for operating rooms in hospitals and for show windows in brightly lighted districts; these values are from 100 to 200 foot-candles. The next bracket of from 50 to 100 foot-candles will find many and varied uses such as jewelry and watch making, extra fine bench and machine work, extra fine inspection, linotype, monotype and engraving, the ring of the boxing arena, automobile paint shops and dark leather sorting, cutting and sewing. Excellent lighting for industrial plants is from 20 to 30 foot-candles according to present accepted

standard. To the uninitiated this sounds like a great deal of light and this illumination does look very bright when first installed. To make a room bright as day means an illumination above 100 foot-candles. Considerations of economy usually limit the level of artificial lighting to the lower values, and many factors must be taken into account because of the low limit imposed on the designer.

A word at this point about the function of the eyes will explain the necessity for maintaining high levels of illumination. The eyes are always on duty during the waking hours, shifting around and changing focus, the muscles and nerve centers using a large amount of energy during the day's work. It becomes important that the lighting shall be such as to make possible an effective impression upon the retina with the least strain. When the illumination is of a low order, these impressions will be inadequate, the eye muscles have extra work thrown on them and they become rapidly exhausted. The speed with which the work is done has to be greatly decreased and mistakes are frequent.

rests of several thousand employees in factories and commercial establishments show that more than 50% of the employees have uncorrected faulty vision. Additional tests also show that an astigmatic eye or subnormal eye is helped more by improvements in illumination than the normal eye. It follows that as the

illumination is increased a point is quickly reached where the men with subnormal eyes will be able to see almost as well as those with normal eyes. This is the desirable situation because it improves the 50% of the men having faulty vision.

many tests on the time and light required for perception of a small test object under various levels of illumination, the results of which are shown on the accompanying graph. This shows that it takes 3-1/2 times as long for the normal eye to perceive the test object under 2 foot-candles as it does under 100 foot-candles, twice as long under 6 foot-candles, 1.7 times as long under 100 foot-candles, 1.5 at 16-foot-candles, 1.4 at 20, 1.3 at 30, 1.2 at 40, 1.15 at 50 and 1.1 times as long at 60 foot-candles as it does under 100 foot-candles. This is an average curve for normal eyes and shows that good illumination has an optimum value between 10 and 20 foot-candles, at the knee of the curve.

and illumination required for discrimination, plotting the normal eye against the astigmatic eye, shows the pronounced improvement registered by astigmatic eyes over a given increase in illumination. Taking a normal eye as 1, or unity, at 12 foot-candles, it takes 4-1/2 times as long to discriminate under 1 foot-candle and twice as long at 6 foot-candles, relatively speaking.


An astigmatic eye requires 15 times as much time at 1 foot-candle as the normal eye needs at 12 foot-candles, or 3-1/2 times as much as the normal eye under 1 foot-candle (the same illumination). The astigmatic eye needs 4-1/2 foot-candles to see as fast as the normal eye does under 1 foot-candle, and 12 foot-candles to see as fast as the normal eye at 6 foot-candles. A continuation of the curve will show that the astigmatic eye needs 20 foot-candles or more to see as fast as the normal eye at 12 foot-candles.

Information collected by messrs. Luckiesh, raylor and Linden, of the General Electric Research staff shows that the speed of reading with a black and white contrast in an illumination of 16 to 24 foot-candles is 20% faster than the speed in 3 foot-candles of illumination. With a gray background, the increase was not so great, and taking into account the fact that commercially we seldom, if ever, have a white background with black objects, facts again show the necessity for higher illumination such as 20 to 30 foot-candles for commercial establishments.


decrease spoilage, reduce the number of accidents, bring up the morale of the personell and pay for themselves after a limited time.

nation have been established by experience and are issued by various authorities and are given as a guide for different classes of work. By keeping in mind the character


of the work and the fineness of detail to be observed. one is able to select from the values given in the table a suitable level of illumination. A very complete table is included with this work as an aid to those wishing to make new designs. This table is one which is made available to the trade by a reliable manufacturer of lighting equipment and can be used freely except for one reservation, viz., the "minimum values" given are too low and should not be used. column headed "good practice" gives, as a whole, fairly accurate values to use in the formula for finding the necessary lamp size. where the value obtained is slightly over a given lamp size, the next size larger should be chosen. It should be kept in mind that there is a marked tendency toward higher levels of illumination.



It takes 3/2 times as long to see a small test object under 2 fic. as it does under 100 fic.



An astigmatic eye must have 4 to fic. to see as fast as a normal eye at 1 fic.



Black and white contrast 20% faster.

M.G.H.

CHOICE OF A LIGHTING SYSTEM

As has been previously discussed, there are three general systems of illumination classified according to the manner in which the light is distributed:

- A Direct Lighting
- B Indirect lighting
- C Semi-indirect lighting

The fundamentals of these three systems will be discussed, as will the general requirements, and a guide given to assist in the proper choice of a system.

The individual characteristics of a room to be lighted are important factors in the selection of a lighting system. Cost and efficiency are factors which limit the choice, although the present tendency, particularly in the more specialized branches, is to make good lighting the first consideration. Attention is again called to the fact that a suitable choice of colors and frequent painting or cleaning are important.

where a decorative lighting unit is essential the primary purpose of the lighting unit is to provide light of sufficient quantity and quality to establish and maintain the required intensity on the working plane. No matter how beautiful or artistic a unit is, it should not be accepted unless the lighting requirements are satisfied. Units can be designed to be highly artistic and still function as efficient

DIRECT LIGHTING.

Direct lighting systems employ lighting units which send the greater portion of light directly to the surfaces being illuminated.

Direct lighting is recommended for industrial or commercial interiors such as machine shops, assembly rooms, factories, foundries, etc. This system has the greatest overall efficiency from a power input standpoint and the least depreciation with the passage of time. The presence of large quantities of dust and dirt in the atmosphere, and the dark tone of the walls and ceilings are most effectively overcome by a direct lighting system. Line shafts near the ceiling of machine shops preclude the use of a semi-indirect system. For high bays and mounting above crane runways a searchlight or projector type of direct lighting unit is the only kind which will provide satisfactory illumination on the working plane with a reasonable expenditure of power.

At first, open reflectors of metal or glass were the most common type of units used, but with the arrival of more efficient bulbs and a constantly increasing lumen output, the use of the open type glass reflectors has been largely discontinued. Open type metal reflectors, especially those of porcelain enamel interior surface, are being used very successfully

in the industrial lighting field. Forcelain enamel reflectors are commonly classified by shape, as a dome or bowl. The dome is preferable because it gives a better illumination on vertical surfaces and higher efficiency.

The highest grade of industrial units manufactured for this purpose are called the "R. L. M." domes.

(R. L. M. stands for reflector and Lamp Manufacturers standard Dome.) These must be built to standard specifications of contour and quality of the reflecting surface. This insures a durable and highly efficient unit, a contour of reflectorwhich will insure an effective light distribution, and a depth which will shield the filament from view sufficiently to minimize glare.

A still higher development of the dome is known as the classtell diffuser. It is a combination of the dome reflector and a white glass globe. The milk glass globe completely encloses the bulb and diffuses the downward light. The reflector fits over the globe and concentrates the rays downward except for a new slots around the top which allow a small portion of the light to be emitted upward, thus illuminating the ceiling and improving the appearance of the lighted room. The reflector also reduces glare by niding a large part of the bright area of the globe. These units

chould be recommended where a very high quality of illumination is desired in an industrial plant.

INDIREUT LIGHTING.

In illumination by the indirect method all of the light is first thrown to the ceiling and upper side-walls where it is redirected and diffused to all parts of the room. Where from the unit is eliminated since the ceiling acts as the light source and a maximum of distribution is directly downward. A very even distribution of light is obtained, with soit shadows and without reflections from surfaces at the working plane. A somewhat smaller percentage of illumination is thrown on vertical surfaces than with the other two methods.

This system is the least efficient from a power input standpoint as all light which is received at the working plane must first be reflected from the ceiling or sidewalls. To help raise the level of illumination for a given power input the most efficient units employ a mirroreu glass reflector within the bowl to direct the light to the ceiling.

The quality of illumination obtained by indirect lighting is counted to be the very test. This somewhat offsets the increase in cost, but in spite of this fact, the present tendency is to employ a semi-indirect system almost exclusively where formerly an indirect layout would have been specified.

SIMI-INDIRECT LIGHTING.

semi-indirect lighting furnished a means of combining the leatures of direct and indirect systems. With a correctly designed bowl of white glass, brightness of this unit is low enough so that eye fatigue is avoided, and sufficiently direct light is emitted so that the proper degree of vertical illumination, and soft or graded shadows are produced. As has been previously noted, a light density of white glass may be used in certain locations where the units are hung high and the nature of the work is such that the units are not in the usual range of vision. There is no marked difference in lighting effect between a very light density semiindirect init and the would enclosing unit for direct lighting, but the general rule says that any unit which directs more than 50% of the light usward is classed as Semi-indirect. The botter chass of these units usually is of sufficient density so that only 20 - 25% of the light is transmitted through the bowl. This type of illumination has a higher overall efficiency from the power standpoint than the indirect system, gives a higher grade of lighting than the direct method, as well as elimicatin, some of the bad features.

residence, office, and public brilding lighting, there the system must be of good appearance and in harmonious relations with the decorative or architectural features of the surroundings. Since this system best julills these

requirements, it has come to be used more than either of the other two.

MAKING A SULTABLE LAYOUT.

For an engineer or anyone who is installing a system or estimating its cost. or who is responsible for the results, the location of outlets, wire size and choise of units are of utmost importance. Even with the proper unit. an incorrect spacing will spoil the lighting effect. wiven the right unit with proper spacing, inadequate illumination will result if the wire size is not large enough to furnish the lamps with full operating voltage. It becomes imperative. then, that the units be properly spaced and adequately wired. If this is done, a change can be made in the type of reflector or bulb size at a later date without overloading thus improving the flexibility as well as insuring proper operating conditions. Special attention is called to these facts here because of their great importance to successful lighting. choice of units and proper spacing is covered in this book. For information on computation of wire size, the reader is referred to any good handbook or elementary text books of direct and alternating currents.

SPACING OF LIGHTING UNITS.

The spacing between units in relation to their height determines the degree of uniformity of illumination and also influences the degree of shadow which results

This has been discussed somewhat previously but the various facts will be summed up now for ready reference.

In most cases the construction of a building divides it into a number of bays, and for the sake of appearance the units should usually be placed symmetrically in these bays. rhis contributes to uniformity of illumination. Panel designs, or beams, on the ceiling, and other decorative or outstanding features, also call for a symmetrical spacing, but it must always fall within the limits of maximum permissible spacing with regard to the height of the units above the working plane, if uniformity is desired. when there are no natural divisions in the room, and the outlets are not already placed, the room should be divided into a number of areas approximately square, and the units placed at the center of each, the maximum distance between units not exceeding 1-1/2 times their height above the plane of work, which in most eases corresponds to a spacing about equal to the mounting height above the floor. with such a system, the distance from the nearest row of outlets to the wall is one-half the spacing distance; the distance from the walls may necessarily be made less than half the spacing distance in order to avoid shadows and to maintain a high level of illumination on benches or desks close to the walls. it will be found necessary to install more than this minimum number of units in order to create and maintain a level above 30 foot-candles.

Another case where the above minimum does not hold

is for a high bay mounting in a turline room, or naching shop up above a traveling crame. A special type unit has been developed called a high high bay unit which is. essentially a small angle spread floodlight, much like an automobile her dight with a dour lans, and mill require a reasonably close syncing to turnish even distribution at the working plane. The light from a unit of ordinary characteristics would be almost completely dissipated before it reached the floor from a ligh way mounties, so we must report to the deep reflector to include the editionary of the quotient. The direct lling lighting units above a crare way, it is a good policy to use the triangular or diamond spacing so that a complete row of units can never be covered by the walking beam at any one position of the crane. This eliminates shadons on the iloor.

A group or sample or model installations are shown on the accompanying blueprints and an explonation of each is included. These are readily followed, always beeping in mild the caximum unit special is 1½ times the height above the working plane.

FASTORS INFLUSHBLIG STAR OF LARP REGULACED.

The lumen method of calculation is the simplest and quickest that has been developed, so it is the one most used at the present time. It wing decided upon the desired number of foot-candles, the total number of lument unich must be supplied at the working plane is

equal to the foot-candles desired multiplied by the area of the space in square feat to be illuminated. It is evident that the lamps must emit a greater number of lumens than this, because not all of the light generated reaches the plane of work; some of it is absorbed in the reflector or endlosing glassware; part of it strikes the walls and ceilings and of this, part is absorbed and only a portion reflected to the work. The amount lost depends upon the characteristics of the lighting unit, the finish and color of the walls and ceiling, and the proportions of the room.

RCOM INDEX.

of the room is called the room index, and in order to better understand the effect of room projections and the mounting height of units on recultant illumination, consider a room 40 ft. by 40 ft. with dark table equipped with two sistems of lighting which are identical except that in one the units are 10 ft. above the iloor and the other 14 ft. It is easily seen that a higher level of illumination will result in the case of a lower mounting height because with the same amount of light starting downward, there is less light in proportion which strikes the walls and a higher proportion striking the working plane.

The isst that in one case the amits are further from the world's plane in itself has no influence upon

the percentage of light utilized. It is the proportions of the room, lot the notable distance to the second. A mountary height of 10 it. in a room 40 it. in 40 it. is exactly the same as tar as elliciated is concerned as a room 16 it. In 16 it. with a mountary neight of 14 it.

The chape and side of the room, for a fixed moneting height, is listing important with reserved to the proportion of the light which attributes are discoulds, materially affecting the foot-candles on the corlocated working plane. For example, take a room of it. x 2) it. with the same ceiling halpst do the 40 it. x 40 it. room previously considere. The floor area in both rooms is the same but the proportion of wall area is much greater in the 60 it. x 20 it. room than the 40 it. x 40 it. thus giving a smaller room index. This shows that there is a comparatively higher utilization of light in large rooms for equal mounting height.

It does not collow that it is desirable to keep all light off the walls and ceilings. A certain amount of it is necessary to reduce brightness contrasts, to prevent a tundel-like appearance of the room, and to give it a more cheerful, pleasing atmosphere.

It is not becomeny to calculate the room index for each individual room at it is becaused. Instruct at the room index does not very with the installation, tables of trace values have been concluded both for indirect and confidence well as for direct indirect and confidence is tellered and it is easy.

necessary to losa by the project room vive that nonnting height, to select the room index.

COMPICION OF CONTRACTOR.

As its name implies, the coefficient of utilination is the percentage of proportion of lating governmently the lumps thich simpley reachathe working plane. It is copenfort upon the type of diffusing and replacting equipment, the solor of the walls and cailing, and also upon the proportions of the room.

Due to the compair and quality of materials, certain types of reflectors will direct light more efficiently to the work than will other types. With open type enoughled-steel realisators (R.L.M. Domos) the influence of the color of walls and estling is at a minimum. The effect of this factor became of increasing importance with open glass realisators, enclosing light-directing, and single dimasing write. It is on anjor injecture in semi-indirect and indirect types of lighting where the majority or all of the light must be realisated from the ceiling or walls before reaching the place of work.

the unit, color of cailing and walls, and room index, it would be very difficult for the unitated to assign a project value to it. Here again the engineer-scientist as come to our rescue and made exhaustive tests on all representative types of units and incorporated his findings in a table. This table is

included and the exact method to apply it will be explained in detail.

Take the chart of reflection factors of colored surfaces and compare with the painting schedule on a new layout, or with the actual colors of the room on a redesign installation, and find the actual reflection factors of the ceiling and of the walls. Record these values. Next pick out the unit which is to be used. or one with a distribution curve as close to the new one as possible. and refer to the opposite page of calculation data. Next make use of the reflection factors obtained at iirst. if the ceiling reflection factor is 70% or better, use the first three columns as indicated; 50% to 70%, the middle three columns; less than 50%, the last three columns. In like manner an individual column choice is made by reference to the wall reflection data. Now follow this column down to the zone applying to the chosen unit and the proper coefficient of utiliation will be found opposite the room index, previously determined on another chart. This appears quite complicated but the method is really simple and after several coefficients have been determined, it works itself down to a system and no trouble will be experienced. An example will be added later.

DEPRECIATION ALLOWANCE

In addition to increasing the total lumens provided by the lamps to compensate for the losses in utilization allowance must be made initially for the inherent depreciation in lumen output of the lamps and in reflecting efficiency of the reflector, walls, and ceiling due to deterioration and to the collection of dust and dirt. The average depreciation will vary from 15% to 50% depending upon the type of reflector and local conditions of smoke and dust. The length of time between cleanings is also a very big factor.

The probable average illumination in percent of initial illumination will vary, due to all the factors mentioned above. To obtain uniform results, the following depreciation factors may be used as a guide: .75 - .80 for clear or clean locations, .70 for average rooms, and .65 for dirty locations or places which are infrequently cleaned.

CALCULATION OF LAMP SIZE

Only one more factor must be taken into account, and that is the necessary bulb size. It readily follows that the necessary lamp lumens can be found from the formula as given, and by reference to a table which shows the lumens emitted by bulbs of different size a suitable one can be chosen.

Required = (Number of) (Coefficient of) x (Depreciation)

Per Outlet (Outlets) x (Utilization)

The explanation of the formula is as follows: rrom the definition, one foot-candle over an area of one square foot equals one lumen, therefore, to find the total lumens necessary for the room, multiply the total floor area in square feet by the desired footcandle intensity. Now divide the total number of lumens needed by the number of units, thus finding how many each unit will have to emit (assuming 100% efficienty). This figure must be increased by the amount of light absorbed by the unit - ceilings and walls - so it is necessary to divide by the coefficient of utilization, previously determined in the table for the room and unit in question. The last step is to make an allowance for the natural accumulation of dirt: this is accomplished by dividing by the depreciation Tactor. All mathematical steps having been properly performed, the result obtained is the lamp lumens required per outlet. Reference is now made to a table which gives the lumens emitted by bulbs of each size. and it will be noted that the figure obtained lies between two bulb sizes - so the larger one is chosen.

A study of the many layouts included will give the application of this method to commercial problems. The accuracy and ease with which it works is easily

apparent, and satisfaction can be guaranteed by the lighting engineer to even the post particular customer.

SUGGESTED LAYOUTS - SYMMETRICAL SPACING



CASE 1
A common practice.
Useful when boy size is no greater than maximum permissable spacing.



Useful in parrow tays where width is less than two thirds the length.



Used in rectangular bays which are too large for Case 1. Note units prevent addition of partitions.



are too large for Case 1 and too small for Case 6.



Equivalent to three units per bay. Used in bay sizes between lase 4 and lase 6.



Most common case with modern bay sixes.

Exterior room dimensions, ceiling height, and column spacings will determine which case will apply for the new layouts.

COMMERCIAL APPLICATIONS



PRINTING - LINOTYPE - ENGRAVING Room 56' x/12' - 14' ceiling Caen stone ceiling, Irory tan walls.

Room Index - Table 6 = 3.00
Mounting height - 12 ft.
Use 52 units - #9 in table 7
Coefficient of Utilization = .58 Table 7
Depreciation factor = .80
Intensity-50 foot candles

Lamp homens (56'x112') x 50 = 13,000

Use 150 matt bulb - Table 9 - which gives 14,800 lumens - enough to provide 57 foot-candles.





TURBINE ROOM - POWER HOUSE
Toom 50'x 100' - 42' to roof truss.
35' clearance to top of crane larry.
White celling - white tile sidewalls.

Room Index - Table 6 - = 1.2.

Mounting height = 36 to clear crane.

Use 18 high bay units - #5 in table 7.

Coefficient of Utilization = .58 (")


Intensity = 15 foot candles - Table 5.

Lamp Lumens = (50×10) × 15 = 8,980 per unit = 18 x .58 x .80 = 8,980

Use 500 watt bulb - Table 9-which emits 9,500 lumens - This bulb will give 15,9 foot candles.

Turbine room open to public-hence high values for intensity -15 f.c. and low depreciation .80%

AIRPORT ADMINISTRATION AND CONTROL BUILDING



SECTION

A-A

This building offers terminal facilities for bassanger and mail routes, airport executive offices, bilots quarters, and a master control room with all necessary switching and observation equipment

PAINTING SCHEDULE

ROOM	USEOF	6046	R
No.	ROOM	CETLING	WALLS
1	ENTRY-	IVORY	BUFF
Z	MAIN	IVORY	TAN
3	ROOM	STONE	BUFF
4	MAIL	#2-GRAY	#5-GRAY
5	PILOTS	TAN	BUFF
6	WASH	WHITE ENAMEL	WHITE-
7	SHOWER	WHITE ENAMEL	TILE
8	CONTROLS SWITCHES	IVORY	BUFF- (WINDOWS)

ILLUMINATION DATA.

	10. /x	or on	e X	01/2	2 4	10 / S.	80 W	No Second	100	Or S	10 X	Tie Holl	(0)
10	12, to	/ Nº 5	20,00	53. 9	10.5	405	193	S K	No. 40	Oux	195	6 6 8	1
1	Office	20'x30'	9	6	10'	1.2	.43	.80	15	4360	300	18.2	
2	Main	20'x20	14	4	10	1.2	.29	.80	15	6460	300	123	
3	Waiting Room	20'250	9	10	10'	2.0	.51	.80	12	2940	200	13.0	
	Mail												
5	Pilots Lounge	20'x20	8	4	10'	1.2	.35	.80	15	5350	300	14.9	
6	Wash	15'×15	8	2	9'	.6	.27	.80	10	3470	200	9.2	
7	Thomas	5'x10'	Proof					,80					
8	Control- Switches	12'x12'	12	4	THE OWNER OF THE OWNER, WHEN		The second second	.80					

COVE LIGHTING

that special adaptation of indirect lighting commonly known as cove lighting, not only has all the other advantages of indirect lighting, but has the additional advantage of entirely concealing all lighting fixtures as well as the light sources.

Industrial lighting is primarily for utilitarian purposes, with the possible exception of the
higher class general and private offices, whereas
window lighting seeks pleasing aesthetic effects
even though its most important aspect is purely utilitarian. The point in this case is the sales power
of the window, and in this respect window lighting
differs from all other types of lighting.

now, when it comes to such interiors as church and theatre auditoriums, ball rooms, lodge rooms, hotel and club dining rooms, library reading rooms, court rooms, time store interiors and other similar installations, indirect lighting from cornices and coves offers an excellent solution. The trouble up to the present time has been to get the aesthetic minded architects and interior decorators into agreement with the all too practically and economically minded engineers and owners. A compromise must sometimes be made between the utilitarian and the aesthetic and this can now be done more easily since cove lighting has been developed. Many large interiors would be

ruined architecturally by the installation of a host of lighting fixtures of the ordinary type that would be required for their proper illumination. with cove lighting it is possible to eliminate visible fixtures. The lighting units may be cleverly concealed within cornices and coves in the architectural desing, wall and floor urns and in other ways. In these locations and for the others previously mentioned, cove lighting should be considered.

standpoint of the utilitarian inasmuch as it has long been recognized as the marest approach to daylight in its beneficial effects upon the eye. Glare is very nearly, it not entirely, absent due to the low brightness of the illuminated surfaces of the ceiling and walls. Shadows are greatly softened because of the dirtuse character of the illumination and hence annoyance and eye ratigue are reduced to a minimum.

Please refer to the blueprint of "A Cove-Lighted Auditorium" attached.

stallation. From the size of the room, width, length, and ceiling height, (average height if the ceiling is curved) a room index is selected from table 6. width is 40 it. at the cove, length of the main floor 84 it., ceiling height at cove is 25 it. and 30 it. in the

center, giving an average height of 27-1/2 feet.

Inspection of table 6 for large, high rooms gives
a room index of 1.5.

tlectors. In this case each cove has 82 reflectors installed on 12 inch spacings. The units are spaced close together to keep from naving the ceiling streaked as it would be if they were farther apart. Experience shows that these units seldom are installed with spacings greater than 18 inches; more units and smaller bulb sizes give more even illumination on the ceiling: 8, 10, 12 and 15 inches are the most common spacings used for units.

ordinary methods of computation, but in this case experience teaches that it is generally quicker and just as satisfactory to arbitrarily put the units in at some given spacing, and choose a bulb size, then figure through and see what intensity would exist at the working plane. If it is too low, try the next size larger bulb. If this, then, is too high, the units may be spaced a little farther apart and fewer of them used. This will bring the intensity near to the desired value.

should the first computed intensity to much too low, in addition to stepping up to the next size larger pull, the units should be respaced closer together and the formula changed to allow for the entry pulbs which till be needed at this new spacing. The reverse of this process is also true. This cut and try method may seem altogether too arbitrary to the unministed, but it only means changing one or two values in the formula while making the preliminary computations. This is easily and quickly done, and as the designer gains a little experience he will see the wisdom of this method as it gives a workable layout at each step, even though the intensity may not be the desired value. The chosen build size in this case was 100 watts, rate 1300 lumons emitted.

the painting schedule called for a caen stone ceiling with a reflection factor of 78%, and an ivory tan wall with woodwork averaging ob to cbp for reflection factors.

the indirect lighting thats in table 17 and solect unit also as one representative standard for cotally indirect illumination. Under "Very Light Ceiling" 70% and "Fairly Light Walls" 50%, opposite a room index of 1.5 the coefficient of utilitation is found. It is .26, which is a good average value; generally it varies between .20 and .20.

The depreciation factor for any totally indirect system under clean conditions is .75.

Solving the general equation for intensity in toot-candles:-

Intensity = Lumens sumber Coefficient of per lamp of units utilization factor

Floor area in square feet.

Substituting values previously determined:
intensity = $\frac{1350 \times 164 \times .26 \times .75}{40 \times .84}$ = 12.3 toot-candles.

This is a desirable intensity for auditoriums.


by inspection of the cross-section of the auditorium, it is evident that the intensity under the balcony
on each side will be somewhat less than that out on the
main floor. To raise this low intensity to normal and
keep down the shadows, mount 6 ornamental units, #23
in table 7, 14 feet high and on 14 feet centers under
each balcony. Install a 100 watt bulb in each of these
units and the shadows will be eliminated. The usual
red exit lights should be specified above each door.
No attempt is made to design the lighting layout for
the stage, as this is very highly special is ed and cannot be covered in the scope of this book.

By inspection it is quite evident that the areas under the balcony will be very well illuminated by the "spill light" from the main lighting fixtures due to the complete dispersion from the ceiling. The light from 12 ornamental units with reflectors has been added to bring this up to normal. It should be noticed that


the total floor area was not used; only that which is directly under the coves, and probably the intensity over the whole area may be somewhat less, due to the amount of light which escapes to the area under the balcony. Attention is now called to the fact that the ceiling has a reflection factor of 78% and the walls average 60%. In choosing the coefficient of utilization, a vlue of 70% was used for the ceiling and 50% for the walls in order to use the tables. Actually the ceiling is 8% higher and the walls 10% higher than that allowed, hence the intensity is higher than the first computed figure and will compensate for the losses incurred by the use of the cove projected area on the floor as the actual floor area. This does not occur in ordinary rooms.

If every fourth light is connected on the same circuit and each circuit is put in a series with a dimmer, a variety of lighting effects may be obtained by changing the intensity of each set with respect to the next in line. Other combinations may readily be made by series parallel connections.

To utilize color lighting in conjunction with white lighting of full intensity, it is necessary to bank additional color reflectors both above and below the main installation. This can be more readily done in a shallow cove by placing the color units on the vertical center line between the white units. Theaters and dance halls will be the largest users of the combination systems.





PLAN-UPPER PART OF AUDITORIUM




Marked dimensions vary table "7, on 14 ft. center with height and width of room

SUGGESTED COVE ARRANGEMENTS





Outline for large cove used in theatres and dance halls. This provides a feet walk and access opening "up behind" for relamping and cleaning



M.G.H.

window display, in its essentials, is the same as the theatre stage setting, but until recently the stage manager has outstripped the window display man in the effective use of light. All progressive merchants have redesigned the window lighting, however, until now they can have from 100 to 500 foot-candles of general illumination by turning on additional switches, and even much higher levels up to 1,000 foot-candles by the use of high intensity spotlights which are directed on the central figure of the display.

varies with the location of the store, those in the brightly lighted districts of a large city requiring the most, and those in the outskirts of the same city or in other less densely populated districts requiring less.

candles in the city to 100 foot-candles elsewhere. In choosing an intensity for window display work, there is one good rule to follow:- When in doubt as to whether or not the value chosen is large enough, just step up to the next higher level and make the design for that figure. An additional 100 foot-candles will only cost approximately twenty cents per hour and inasmuch as a window stands out in direct proportion to its brightness, the increased arraying power of the window will easily

boost sales to ofiset the cost.

"Light on the object but not on the eyes". is a basic fundamental of all lighting problems and is especially true in show window lighting. modern show windows, when illuminated in accordance with the correct principles, have the light sources located at the top and front of the window. close to the plate glass where they may be readily concealed by valances, painted signs, or curtain drapes, with this arrangement, strong illumination may be directed downward and forward to the trim, giving it the direction which experience has shown produces the most effective results. It has sometimes been found advisable to set the reflectors up into the ceiling until the mouths are flush. The reflector for each window should be carefully selected by studying its distribution curve so that it will direct all of the light to the floor and not lose a percentage of it out of the window. moreover, reflectors should be closely spaced to insure most effective lighting; this also permits of turning off alternate units leaving sufficient illumination for a white or light colored display.

The necessity for ample provision for window spot and flood lights cannot be overstressed. For instance, if a displace of dark suits is arranged in the window, it will be found that the window will be eark no matter

how much light is poured onto the suits. If, however, a light background is used and the extra illumination is poured onto it, the suits and other dark material will be silhouetted sharply against the light background and the value of the display will be greatly enhanced. These results can only be accomplished by Ilexible lighting; flood and spot lights provide this medium.

Marvelous effects in imparting atmosphere to window displays may be secured by the judicious use of
colored lights. where careful application of colored
light on various merchandise is made, striking window
settings may be obtained. General rules to be followed
in the application of colored light are very difficult
to give, because each window display in itself presents
a specific problem requiring special treatment. In
general the best results will be obtained if the lighting engineer provides the window decorator with a good,
efficient, flexible layout, leaving the details to him.
It is to that end that the accompanying layouts are
m.de.


observed in designing show window lighting layouts are:
To conceal the light source; to locate the light source
at the top and front of the window; to control the light
by use of the proper reflectors correctly spaced; and to
use plenty of light - enough to make the window stand
out clearing and attract the passerby. To these might

well be added a fifth, and that is to provide several wall, floor and ceiling plug outlets so that other means of lighting may be easily added as required.

The direct type of illumination as used in show windows is the most efficient in commercial use at the present time. The reflectors emit as high as 85% of the generated light and a good average coefficient of utilization is .65. The usual size of narrow windows will only require one row of units and the spacing will vary from 8 inches to 18 inches depending largely on the required intensity. The quickest way of computing bulb size and checking the installation is to assign units at 12 inch spacing; this gives the number of units: then choose the required intensity, from 100 to 500 foot-candles as outlined, and solve the general formula for the lamp lumens per unit. This gives a choice of the nearest bulb size; if this is too large, fewer units may be used and they may be spaced a little farther apart: or if the reverse is true, several add1 tional units will bring up the intensity to the proper value. These should then be equally spaced all around the window.


quire a double row of reflectors, one of which is tilted to concentrate its output on the back area of the window. An illustration is included to show this method of design.


ILLUMINATED WINDOWS



LONG NARROW WINDOW Units mounted flush is notice is 10ft above the floor.

Conduit troughs shown with cross to mark outlets .-







ISLAND WINDOW Glass on all four sides Units flush-10 ceiling.

connect alternate units on the same circuit - each trough separate.
With alternate lights turned on the intensity is 125 foot-candles.

ILLUMINATING A LARGE CORNER WINDOW





Area - 21'x20'- \(\text{Liph.} \)

Ceiling - 12 ft. high.

Units - 10 ft high.

Ecom Index - 1.2 (Arerage)

Coefficient of Utilization - .65 a

Number of Units - 64.

8 5 portlights extra.

Required Intensity - 300 f.c.

Lamp lumens 360 x 300 = 3240

per unit = 64 x .65 x.80 = 3240

Use 200 watt bulb. (3200 lumens)

Figure exclusive of spatights.

FOR OTHER DISTRICTS.

All 300 watt bulbs gives 490 f.c.

" 150 " " 212 f.c.
" 100 " " 125 f.c.

Connect alternate units in each trough on the same circuit. This gives four levels of illumination in front of each mindow permitting a choice of the one best suited for the display. Liberal use of the spothishs will serve to bring out high points and lends to the flexibility of the scheme.

rLOODLIGHTING BUILDINGS

The first step in the design of a floodlighting project is to determine the effect desired. In the case of building illumination it should enchance the effect striven for by the architect. Decide what portion, or portions are to be lighted and to what intensity. In area lighting the use to which the area is to be put will determine the quantity of light needed. Another factor which influences the quantity of light is the neighborhood in which the building is located. ror buildings located in the central parts or business districts of large cities, the higher intensities must be used in order to get the necessary contrast and make the building stand out as it should. The usual range of intensities for floodlighting buildings is 10 to 20 foot candles: 25 to 30 foot candles are sometimes used in the loop districts downtown or for advertising purposes. These are the favored intensities for billboards and signs.

Having decided upon the lighting effect desired the next step is to determine the available locations for projector equipment. sometimes, particularly in display lighting, the choice of location is very much restricted and the design is greatly influenced by the availability of locations.

In display lighting the concealment of the equipment is generally of first importance and locations are ing with set-backs at various floors offers ideal locations for mounting projectors which will be invisible to observers. They should be mounted inside of and just below the top of the parapet so they will be protected and out of sight. Care should be taken to see that snow, ice, water, and refuse will not accumulate on them.

when locations for mounting the floodlights are not available upon the building itself, it is sometimes possible to mount them on adjacent buildings or ones across the street. A suggested layout for this type of lighting is included and the method followed is very evident from the drawings.

There is another method which is becoming popular for floodlighting buildings. It is used a great deal on low buildings and in locations where no other type of projection can be used. It consists of a lantern bracket type of projector, the external appearance of which duplicates the street lighting units used in the city where the installation is being made. A very novel scheme is used for the internal arrangements. Provision is made in the base for a 200 or 300 watt bulb which illuminates the interior of the unit and casts its rays up and down the street as does any ordinary street light. A 500, 750 or 1000 watt bulb is located in the top of the unit and is ecuipped with a very efficient reflector, thus directing practically

all the output of the large pulb onto the area to be illuminated. By mounting these units on posts like street lights the direct glare is kept out of the eyes of the passerby.

In the common width of sidewalk, standards for lantern brackets should not be placed closer than 20 feet apart, neither should they be placed directly in front of the doorways. Instead, one should be installed on each side of the entrance. This adds to the appearance of the building and gives the best lighting layout.

in cases where existing street lights are of a certain type it is well to select a lantern tracket of similar design so that all will appear alike.

After choosing a lantern bracket the building and sidewalk layout should be inspected to see now many units can be installed without spoiling the appearance, bearing in mind that they cannot be closer together than 20 reet.

a unit located on the curb of a usual width sidewalk placed 12 to 15 feet from the wall will illuminate an area about 20 feet wide by 50 feet high. This area is not materially different for any bulb size so it follows that for high buildings a double bracket will be necessary, that is two units will be mounted on each standard or post.

almost entirely upon the intensity desired and the distance to the surface to be illuminated. The use of 500 watt units for the lower height buildings with "throws" up to approximately 15 feet, gives satisfact-ory results. For the higher buildings, even with average sidewalks, the 1000 watt units are much more effective. If the highest order of brightness is desired for the building the maximum number of 1000 watt units will be required; this means double brackets every 20 feet. The 750 watt bulb will be useful in obtaining the medium intensities.

ets, a bulb size is estimated based on the distance to the building and the desired intensity. This information, with the building size, enables the foot candles to be computed as outlined on the blue prints. If the actual foot candles are materially different from the desired intensity, a change in bulb size or a re-arrangement of units, or both, will accomplish the desired results. Reference to the blue prints will illustrate how this is carried out.

This type of lantern bracket is used extensively in illuminating gas stations and other such areas where they will enhance the beauty of the arrangements as well as efficiently light it. For this service the 500 watt bulb has been found to be most satisfactory. The units should be so located that the majority of the light is

cast across the flow of traffic, thus furnishing illumination with the least possible glare.

any type of floodlighting that evenness of illumination and complete coverage are most essential. The amount of surface a floodlight projector will cover is a function of the distance from it and the beam spread of the unit. For our purpose we may group floodlights into four general classes:

Narrow beam projectors - up to 15° beam spread

medium beam " - 16° to 29° " "

Wide beam " - 30° and over

Special beam " - In which the horizontal and vertical beam spreads are not alike.

The exact beam spread required for a specific installation can be easily determined by mathematical calculation or by measurement on a sketch drawn to scale. The closer the bank of projectors to the surface to be illuminated the larger number of units required. Careful reference to the blue print of the floodlighted tower on the office building will bear out this statement. Too much can not be said about making a scale drawing and working up the layout from it. It is fast, accurate, and easily checked. A reasonable allowance should be made for the overlapping of beams at the edges so that a uniform intensity will be maintained.

Attention is called to the fact that there will be a small percentage of "spill" light outside of the published beam spread. Under ordinary circumstances this is perfectly all right and serves to bring up the intensity of the area between the units but should it be desired to eliminate this "spill" light a louvre may be installed just inside of the lens which will eliminate all but the main beam. These can be purchased from the floodlight manufacturers as extra equipment. A visor made of sheet aluminum can also be furnished where it is only desirable to eliminate the upward spill light. This clips on the outside of the front door and is not used in conjunction with a louvre.

Another feature in floodlight construction that is well to mention at this time is in regard to color illumination. Provision is made on practically all units manufactured at the present time to facilitate clipping in a color screen behind the present lens which will impart color to the beam. The screen is made of a special grade of heat resisting glass, designed for the purpose, and it will retain its color qualities for an indefinite period. This screen is used regardless of the type of lens or spread of the beam when color effects are to be obtained.

the between the sharping a mall compared one beam classification to another is to charge entropy the type of lens, the type of reflector or established homel beam classifications of astron, regions on a horizontal appointmental the came vertical eye as a horizontal sound according to the following selecule:

Narrow beams - up to lo beam oproad

Vertical beam apreads vary from bo to 100

Horizent l beam apreads vary from 70 to 120

generated by a plain reflector and plain lens. The efficiency of the beam averages 20%, or rall efficiency 66.5%.

medium beams - 16° to 29° beam spread.

Variable beam spreads vary from 11° to 15°

Horizontal beam spreads vary from 18° to 22°
generated by a plain reflector and plain lans. Beam efficiency 25%; total efficiency 66.5%

Wide beams - 20° beam spread and greater

Vertical beam operads vary from 20° to 20°

Horizontal beam spreads vary from 20° to 46°

generated by a prismatic reflector and plain lens. Ecam
efficiencies 15% and 25%, total efficiency 50.5%.

Special Beam Ulassification

Tyne మక్కల t			m Uproa	d <u>vortianl</u>	Afarciency beam total		
Plain	ranlite	l. dium	450	bo	28%	6 8%	
11	**	1.6	450	10 ⁰	41%	71%	
11	.t	11	450	150	25%	66 5 75	

rype Reflector	Type Lens	Horiz (eam Sp	Efficiency Beam rotal		
Prismatic	ranlite	ыe dium	440	₃₀ °	25%	66.5%
Plain	н	•	70 ⁰	620	1570	55%
u	u	**	70°	13°	15%	5 5%
Prismatic	ff	te	75 ⁰	25°	15	55%
14	H	11	700	₃₀ 0	15	55%

The above special beams are representative of what can be secured as they were picked from the catalog data of a responsible manufacturer. Many other combinations are being furnished, a complete list of each will be found in the lighting catalogs.

various sizes of bulbs are used in the above described units. These range from 200 watts to 1500 watts. with this information and a choice of reflectors practically every condition may be satisfied.

the method of making a floodlighting layout for a building is a more or less "cut and try" proposition at first, but as experience is gained it will be found to be a more exact art. As this discussion progresses, careful reference should be made to the floodlighted tower of the office building and the computation sheet, blue prints of which are enclosed; also the floodlighted theater building.

one thing that always must be kept in mind is uniformity of illumination. It follows that the closer the
bank of floodlights to the surface it must illuminate,
the larger the number of units necessary to fulfill the

requirement and the smaller the individual bulb sizes. when the units can only be placed two to eight feet back from the surface they are to illuminate, they must be spaced not farther than four feet apart, using 500 or 300 watt bulb depending upon the intensity required. Quite often it is found mecessary to space units on two to three foot centers insuring a very complete coverage. wide or medium wide beams spreads are commonly used for this work. As the bank is moved further away from the surface uniform coverage can be secured with a much smaller number of units, using the same or a smaller beam spread. In order to maintain the same intensity then it becomes necessary to increase the bulb to a 750 or 1000 watt size. Longer distances of projection, such as across a street. or higher than average intensities will generally require the 1500 watt bulb, unless the percentage of units to area illuminated is some what high in which case the 1000 watt bulb will be sufficient.

The calculations for the necessary number of units is carried out as follows: consider the distance of projection and the area to be covered and choose a bulb size. This gives the emitted lumens per unit and substitution in the general formula with the area to be illuminated, foot candle intensity, 66.5% efficiency and an 80% depreciation, readily solves the number of units of that size which will be recessary to fulfil the requirements.

next, runr to the beam classification chart and select a beam spices which will give acceptably anisomm coverage. This may be readily emerce by making a conicarcular, precing the units on it and solving the chosen beam opposite. Done overlapping checks be allowed both norm-outsily and ver isally to as are even cev rage.


can not be detailed with the number of reflect recemproduct the formula. There explores to the control of the building, the location at which the projectors must be placed with respect to the sample to be illustrated, or crued reasing. It is necessary then to set aside the exact number of units as commond, place them so they will illustrate as much up pas able, and not missiver units will be required to eliminate the mark place. The other arrangement will be acquired to eliminate the mark place. The other arrangement will be acquired to eliminate the mark place. The other arrangement will be sound patternetory unit so the entire lighten access is changed to employ an almost the citact.

and care entirely as covers its own area, then light and care spots or straks will be eliminated and the mist depirable effect will be created. This process is just as essential as the original cession and must be collowed through carefully to obt in the pest results.

At ention is again called to the blueprints and pictures of floodlight installations in the back of the book.

FLOODLIGHTING SMALL BUILDINGS FROM THE CURB WITH LANTERN TYPE BRACKETS






SIDE ELEVATION


Dank building 77 ft. high 43 ft, wide. Six large pillars of cast stone in the front. per standard, 14 "reflector, 750 watt bulb.


Intensity = 4x14550x.85x.80 = 12 feet-candles. Two units per standard are used to match street lights.



Bank building 40 ft. high, 60ft wide. Use one lighting. Equipt with 14 reflector and 1000 watt bulbs. Intensity = 2x20,200x.85x.80 = 11.4 feet-candles

FLOODLIGHTING FROM THE CURB. LANTERN TYPE BRACKETS






Building as shown-Cast stone - White - 100 feet high. Use Lantern bracket, 14 "reflector, 100 matt build."

Intensity-Trant = 8x20,200 x.85 x.80 = 8.5 feet-condites.


" - Side 4x20,200 x.85 x.80 = 8.0 " "



No. Units = 100 × 140 × 20 = 30 units

Each of these units equipped with a 1000 watt, \$40 bulb emitting. 17,800 lumens in a begin 35° x 30°. [Eff 66 2] This layout illuminates the white stone front to 20 hat contines. All units mounted on building across the street. Tellowing the usual custom, the under side of the parque is covered with 15 wort bulbs. This brings the intensity of the door up to a very high figure.

ILLUMINATED TOWER ON A LARGE OFFICE BUILDING




ELEVATION Scale 1"= 40'-0"

This is the south elevation and fronts on a main boulevard. The east side also faces a main theroughture. The building is in the main business district of a large city.

The bottom four sections of the tower are illumnated to 20+ foot candles; the top 10'x15' area to 36 f.c. The location of all floodlights is shown on an attached drawing.

FLOODLIGHT LOCATIONS ON OFFICE BUILDING TOWER

Ladge, 3'0" wide at 100' level



PLAN Scale 1" = 20-0"

Level	Color	No. Units	Wattage	Spread
100 Ft.	White.0	11 68	1000	30° × 30° 20° × 10°
160 Ft.	White.0	15 11	750 500	40° × 30° 20° × 10°
200 Ft,	Red	20	500	20° ×10°
215 Ft.	Yellow. 6	12	500	20° × 10°
230 FT.	White.0	8	300	20° × 10°

mgt.

LIGHTING DATA - OFFICE BUILDING TOWER

No. units needed = Area in square feet x Intensity Lamp lumens x Unit Efficiency x Depreciation

Level	Side	Watts	Tormula	Nember Units	Spread	Color .
	West		60 × 100 × 20 = 11.4 20,200 × .65 × .8	11	30°×36°	White
100 Foot			60 × 100 × 20 = 24 9650×.65×.8	24	20° x 10°	White
	North, South	500	60 x 80 x 20 = 19.2 9650 x 65 x 8	20	20° × 10°	White
160 Foot	West Fast North	750	40 × 40 × 20 = 4.2 14,550×.65×.8	5	40°×30°	White
root	South	500	40 × 40 × 20 = 6.4 9,650 × 65 × 8	7	20°×10°	White
200 Foot	W-E N-5	500	* 30 x 15 x 20 = 3.6 9650x * 32 x .8	4	20°×10°	Red
215 Foot	W-E N-5	500	* 20 × 15 × 20 = 2,4 9650 × *32×B = 2,4	2	20° × 10°	Yellow
230 Foot	H-E N-5	300	10 x 15 x 35 5370x.65 x.8 = 1.88	2	20° x 10°	White

* Note - Colored lights are only 50% as efficient as white.

An extra flood light is installed on each corner to boost the intensity, increase the definition, and prevent any "feather edges". This bractice has been found to be very helpful and increases the visability greatly.

TOTAL TO ORDER			
Color	No. Units	Watts	Spread
White	11 15 19 8	1000 150 560 300	30°×30° 90°×30° 20°×10° 20°×10°
Red	20	500	20°×10°
Yellow	12	500	20°×10°

Connected load - 145 units - 81.15 Kw. Exclusive of neon tube beacon

COLOR FLOODLIGHTING

There are two types of color floodlighting - still and mobile. The still color floodlighting installation is the simpler in design, as it consists of but one system and is patterned much the same as the still "white" installation. In fact, a "white" floodlighted building may readily be colored by inserting color filters behind the lens. Colored floodlights are, on the average, about 50% as efficient as the corresponding white light so in order to maintain about the same level of illumination it will be necessary to increase the bulb sizes or install additional units.

The simplest still color explication is the Iloodlighting of a building in one color. More complicated
installations may be designed to flood various portions
of the building in various colors. Two things must be
kept in mind, however - first, that the use of more than
one color calls for narmony in the colors used; and
second, that the floodlights should be located, if at
all possible, so that they are easily accessible for
changing the color filters. This last feature will permit variance from time to time of the color effects produced. (One good example of this system in Lansing,
michigan, is the board of water and Light building, on
west Ottawa street. This untilizes colors both from
units on the building and from other units in the attic
windows of the city hall.) Still color floodlighting

layouts are designed the same as a "white" installation except due allowance must be made for the 50% efficiency of the color units:

mobile color lighting is the most complicated but it provides the finest, most attractive and spectacular results, and its design should begin with a study of the architecture of the building to be floodlighted. The modern type of skyscraper with numerous set-backs, pilasters and other forms of architectural adornment offer exceptional opportunities to the ingenuity of the designer. These set-backs also provide ideal locations for the installation and concealment of equipment which adds charm, mystery and illusion to the effect when viewed from the ground.

number of colors, the space available for the equipment and the amount of money available for the installation. The installation should be designed to provide sufficient flexibility in effect to prevent monotony. The lighting units should be concealed on the building itself as much as possible. Provision should be made for rapid changes in the arrangement of both color and motion.

The intensity of the illumination and the number of floodlights of each color depend upon the location of the building and the material of which it is constructed, the same as if it were a "white" installation. Each color system is required to fulfill an entire individual part in

the program; this means that there must be a full set of floodlights for each color designed as explained above.

These color units will be panked to ether and with the white units so that as each is individually lighted it will produce the desired effects.

The installation is operated by an all electrical controller which consists of cycle dimners for the control of the white system and magnetic contractor switches. properly synchronized with the operation of the cycle dimmers, for controlling the colored light. The action may be set to make changes of any duration of time desired. As the "wash" system operates, the white lighting is gradually increased from zero to maximum, at which point its intensity completely washes out the color and the building appears in white. Une color may be switched off and another on without perception of any change to the onlooker. Then, as the white system is gradually decreased. the second color gradually comes up to its full intensity. A ain. the white light increases, washes out the color. another color takes its place and the white decreases. This action is constant and according to a predetermined sche dule.

une of the outstanding examples of this type of art is a large bank on which three complete floodlighting systems are installed: - l-med, 2-slue, 2-white or uncolored. The control equipment is located in the basement and is arranged to give twelve color changes in two minute

intervals. During this time the building changes from white to red, red to white, white to blue, blue to white, white to red and blue (purple), red and blue to white. There are also six periods during which the various tints of red, blue and purple are either increasing or diminished.

Another teature of this system is that various changes can take place on various portions of the building at the same or different times. The delicate shades produced by the increasing and decreasing intensity of the white system, and the combination shades obtained by switching on two or three blending colors at the same time are beautiful. There is a broad field and an unlimited opportunity for this type of illumination.

Results are dependent upon the Illuminating angineer, Architect, and electrical contractor who must work together to the common end and develop the sensational combinations possible with this form of lighting. These results will more than justify the increase in cost above the ordinary type of floodlighting.

The University of Derroit rootball statium

Ploodighting for the University of Detroit at dium was first installed for a few test cames in the full of 1929 and the success of the trial was measured by an incroaced attendence at the milit papes over those played in the day time. The installation, during these test paras provided approximately 8 noct canales over the 11.ld and it as found advisable to use an illumination ball; i.e. one which was painted white. Due to the success of the scheme it was accrued to jointo the lighting of the field in a lightery and schodule the majority of the sames at night for the fall of 1900. uredit for the decign and installation of this cutstanding step in illumination belongs to two alumni of this school - s. r. Labadie, slectrical in incor of the risher Body company and marry martin of martin and oil on communy. both of Detroit.

as it provides an intensity of 50 foot-candles in the stands with "spill "light from the sain units. This is many times the intensity usually thought nicessary. (8 to 10 foot candles) and is adequate for the players to function as rapidly as by any and without any antopance from plane. It is not even madespary to use an illuminate ball. The biggest recommendation for the system came from the visiting

They experienced no difficulties eligible then - solves to the not conditions.

where conomic practicability of this because has been evidences by recons crowds at each of the passes played last fall. This statement is made to justify the apparent high load, which amounts to 220 k whot electrical energy. The system has a transmis for voltage of 400,

located at the base of each corner tower to farming ourrest to the four 110 volt, 10 k w floodinghts which are
mounted on the top of each tower. This monitains good
voltage regulation, as each corner tower requires 348
angeres at 110 volts, and neeps the foeder size from to
one # 4/0 cause on the high side and two # 4/0 causes per
phase from the transform rup the tower to the units.
The center towers also have four units but there are 30
k # each; 20 - 1000 watt, T-30, 105 volt units have mounted
as close together as possible within the respector. These
are connected in parallel, the four respectors are connected
in series and operate deress the 460 volt supply. This
curse the 1000 watt bulbs at 10,5 over voltage and increases
their lumen outgut.

The entire spatem operates at an officions of 10 lumens per watt. The 10 K w lamps operate at approximately their normal life of 100 hours, and the list price per bulb has been recently reduced from \$185.00 to \$125.00 each, decreasing both the initial and maintenance cost

considerably. The 1000 watt 105 volt T-20 bulb is burned 10% above its rated voltage which increased its lumen output to 30 lumens per watt, or 30,000 lumens per bulb, but decreases its maximum life to approximately 125 hours. This sytem facilitates maintenance as it limits the use-ful life of all units to approximately 100 hours, and theoretically all bulbs will need to be replaced at the same time. Another feature of the design is that all units are mounted on trunnion bases and can be easily swung around for servicing without danger to the maintenance man. A set of guides permit their return to the original location without any further adjustments.

Each of the towers if 105 feet high, approximately 3-1/2 feet square, and is anchored with a concrete foundation, sunk approximately five feet in the ground. The towers are so designed that they are capable of withstanding a 100 mile gale. Steel ladders run up the inside of each tower to a platform located directly beneath the units which facilitates maintenance.

A complete layout of this important development is included as it indicates the modern trend for foot-ball field illumination.

Another interesting feature introduced here is that 2 - 20 inch m.L.M. domes containing 1000 watt bulbs are mounted on each tower and pointed toward the stands.

These lights are independent of the regular system and

when the main lights go out, the stands will still be illuminated to a moderate intensity by the six 1000 watt domes on each side.

The lighting units for this installation are all special and as yet are not on the market commercially. It will be found relatively easy to make duplicates, however, as the dimensions are given on the attached drawings.

THE UNIVERSITY OF DETROIT STADIUM BEST ILLUMINATED FIELD IN U.S.A. - 1930

4 units

10 " in the stands. Even Illumination - No glare 320 km lighting load.

Each of the four Towers at the corners of the field has tour units mounted as shown. Each unit has a 36 barabolic mirror (mouth width - 4 ft) and contains a lorn. bulb.

Each central tower on the 50 yard line has 4 special snow shown. These units are 8 Ht. at the top, 6 ft, at the bottom, and 16 inches deep; and each unit


Both units are special, being Efficiency = 30 lumens ber watt

Installation designed by: (E.F. Labadie - Fisher Body Co. Detroit. Harry Martin - Martin & Gibson Co. ", 20 KN each 10

è ///// 8

UNIVERSITY OF DETROIT SPECIAL LIGHTING UNITS FOR FOOTBALL STADIUM

IOKW UNIT-ON END TOWERS






SECTION

This shows the location of the 36" barabolic mirror and the 10 KM. bulb. The reflecting surface of the surrounding housing is of exadized aluminum. The unit is built of sheet aluminum welded to a steel framework

20 KW UNIT-ON CENTER TOWERS



TOP VIEW





SECTION

This unit is also built up with aluminum on a steel framework. The reflecting surface is a chromium plated spun copper mirror and directs the light very efficiently to the field. 20-1000 watt bulbs placed close together as shown furnish the light.

		t eng
		!

TYPICAL LIGHTING LAYOUTS FOR FOOTBALL FIELDS . -






Mount 6 units on each center tower and I on each end tower. 40° spread lens and louvers. Use 1500 watt bulbs - P5 52: X if dimension D is less than 125 ft., and G 40 if D is more. Construct dimension "H = D" X = Locate two units at each end with bottom louvers to light beer air for high bunts.







Intensity = 31,050 x 40 x 7 x 75 200 x 400 = 8.1 foot-candles

AREA LIGHTING

In this type of lighting it may be said, as a general rule, that the elimination of glare is of the utmost importance. One effective way of reducing annoying glare is to mount the projectors a sufficient height above the surface illuminated. Practically all of the manufacturers catalogs state the beam candle power of their units but if they do not it will be supplied on request. Beam candle powers and mounting heights are shown in the following table:

Maximum Beam Candlepower	Minimum Mounting Height - reet
10,000	15
20,000	20
50,000	30
100,000	50
200,000	70
3 0 0. 00 0	90

In the lighting of parking spaces, gas stations, driveways, etc., locating equipment so that it faces the flow of traffic, either in or out, is not recommended. As a general rule the larger portion of light should be directed at right angles or as nearly so as possible, to the direction of traffic.

when lighting an area for sports, locations should be chosen so that a minimum number of spectators face the projectors and the area is illuminated evenly over the playing field. Several examples will be cited.

For playing tennis at night a very high intensity and even distribution of illumination are required. Glare and shadows must be eliminated. A large, open type. short range, wide angle floodlight should be chosen for this work. To illuminate a single court properly, six units must be used. These are mounted on the tops of poles 30 to 50 feet high located approximately 10 feet from the edge of the playing court, one at each corner of the court and one opposite the net on each side. These are directed sharply downward and play can continue without any discomfort to the players. case there are double courts the poles between must support two units. 1000 watt P.S-52 bulbs will be found quite satisfactory as they provide 34 foot candles. use of 1500 watt units will raise the intensity to 53 foot candles: this is even more desirable due to the smallness of the ball and the speed with which it moves.

Miniature golf courses have recently come to the fore and require consideration to that of the tennis courts except a much lower intensity is required. The balls do not move at high rates of speed. Eight flood-lights of the short range, open, wide angle variety will also do fine work here. For square area one unit is put at each corner and one in the middle of each side. Courses not larger than 120 feet square can be lighted with 1000 watt

lamps to an intumbity of V.D loot candles or latter, while those of 150 reet on a side require 1500 watt bulbs for the same intensity. Rectangular areas should be treated in a similar manner by locating poles down the long sides every 60 to 90 feet with two units per pole. These units should be mounted a minimum of 25 leet above the ground. A much better figure is 20 to 40 feet as it gives much better distribution of light. Short range ilcodingnts may also be used for this type of lighting, best results being obtained when a ranking or spreading lans is used.

Golf driving ranges are cost illuminated by m dium and long rame aloodlichts. After many tests a certain floodlight company recomends the following layout. For each tO neet of midth of the driving range install one pole 20 feet high with four unit; on it. Two units have a 1000 watt P.S.-12 culb and spread lens, the other two have a 1000 watt 6-40 bulb and a clear lens. The spread lens units illuminate the immodiate foreground and air while light from the directed type units continue on ara to cover the last half of the coalse, from 125 to 500 yards. Driving ranged the generally about 200 jands deep. If the wees are uncovered the poles should be praced about 25 rept back as this allows spill light from the same units to illuminate the tees, otherwise sectrate Lighton, must be provided for this purpose. With covered tess the units may be locatedimmediatelypack of the shelter.

Aviation Field Lighting

For this type of lighting, the fundaments can again be stated in terms of lumens of light or foot candles delivered per square foot of area. Certain illumination values have been fixed by the united States Government as minima which must be met before a field can receive its license. Before one attempts to design a layout for an airport he should familiarize himself with the regulations as outlined in the bulletin "Airport nating megulations". A copy of this bulletin may be obtained by writing the Aeronautics Branch of the Repartment of Commerce in Washington.

the important lighting equipment for an airport may be grouped into three general divisions: beacons, marker lights and landing field floodlights.

Beacon lighting is an application of the principles of marine lighting with a thought to the additional distribution of light into the vertical plane, on account of airplanes travelling in three dimensions. Each airport must be supplied with a rotating beacon which rotates in a counter clock-wise direction at the rate of 6 revolutions per minute. A common unit to use for this service has a 24 inch reflector and accommodates a 1000 watt, 110 volt T-20 bulb. This provides a 3,000,000 candle power beam and can be seen for from 10 to 80 miles depending on the weather conditions.

marker lighting, which covers boundry, approach, obstruction, and roof sign lighting, is an application of the principles of good sign lighting practice. All of these lighting fixtures are standard equipment by the various manufacturers and are listed in their catalogs so that they may be purchased as units. No special theory is involved in their application except that the floodlighting of the roof and walls of the hangers should be carefully carried out as outlined in the section devoted to floodlighting of buildings.

Landing field floodlighting is the most talked about, the most expensive, and many times the most unscientific part of an installation.

The fundamental considerations of satisfactory landing field floodlighting, in their order of importance, are the following:

- 1. Low vertical divergence of the beam
- 2. uniform illumination of the field.
- 3. Sufficient intensity of illumination on the field.

The reason for the low vertical divergence is quite evident when consideration is given to the fact that it is much easier to look from a dark place into a brightly illuminated area than it is to see after one gets into the

team, of felly flow iacing the flow like new divergines information the useful light on the civil a well as kerrs - the air of over area from last or religetnone. The most caticinatory and last controll limiting source is the are. Some are new mean with a 4,000,000 candle power beam, a horibertal sivery select 1800, and a vertical divergence of $1-f/4^{\circ}$. This type or that is by ium the wost Reveloped to data and it recontented and used by the Army, Dayy, Transcontinental Air Transport. and many other responsible operators. The two rate vertical divurgance of flow lights thich a e the propert balls veries from 4° to 10° . This shows that confiderable light will open a ward with the miler divergence and be and is apt to confuse the including pilot unless he is landing across or with the beam. Careful location of the banks of li has will do much to help this consision, and grovide gaie lithing for landing.

unitary illumination of the fit little wort conwide ation and a loss invelor manufact in coveral ways.

Suppose, for increase, for a is a light list in the cover of the leading to a. who floodly its must be leaded at the edge of the field so they will not be a heard to the incoming planes, and the long low beam stretching out over the port will be intercepted by the rice of ground and a shadow will be east cross the remain or of the 11 ld.

This is not a good condition for landing and can be particularly overebre by mounting the lights of appears. In no case,

however, should the units be mounted higher than 20 feet above the ground as it creates too much light in the air above the field. The field should be graded down if this does not remedy the shadows, or else spread the units along one side and even up the lighting as much as possible. Reference to the type "L" and "T" airports included will illustrate this method.

It is well, wherever possible, to illuminate the port from one side and one end, the locations being chosen such that with the prevailing winds the majority of landings can be made either across or with the beam. Only the one bank of lights need be used in normal wind and weather but when it is foggy the second bank will help considerably by bringing up the average intensity.

Among other things, the government requires that to obtain an A-1-A rating an airport must be a minimum of 250 feet square and have a minimum of .15 foot candles of illumination on the vertical surface at all points on the usable portion of the field. It follows that if the field is 5000 feet square, it still must have the minimum of .15 foot candle as called for in the requirements. This more than doubles the work of the lighting engineer because he is not allowed any larger vertical divergence or higher mounting height than before and he has twice as far to project the light. An analysis of the results obtained with the high intensity are will show a standard for reference.


rla Terry 10 1 1000 min. Here the eli Massadern on the midel simport ereleted, five a sammand conditipower of 4.000,000 with a vartical liver, ence of 1-1/40 and a seam spr ad or 1000. As the unit to inscalled iron 10 to 15 rest high small tilltog old htly depresed, the actu 1 um and divergence is $1/2^{\circ}$. One unit is submanteed to cov r an a 4a 2830 by 2800 meet to a minimum of .15 icot cancles. Actual test result, how ter, show that under everage clear weather. the area cive of to .16 foot canalog is a correctionately 5000 fort wide by 4000 fort agan: and the arca immediately in front of the unit 5400 fect wide by MEOO idet deep is illustrated to an intumpity of .35 root canales. This gives quite a factor of calety for lad weather and all est no vertical divergence. The unit comes equivald with a 10 K b bulb so mount d is ise that then it is desired to change the eurloss, or in case of an arc isilure, a control button on the outside is pushed thich lights the 10 K W bulb and suings it around into the focal center as the arc mechanism backs away to an accessable location there the accessary as justantity can be made. The 10 k W bulk with its large light contur provides a beam of 1,250,000 andle power and a virtical diversonce of to.

Illuminating an airport with anumber of ileadlights is carried out in a similar manner to the one described except that the ligh beam intensities are built up by a multiplicity of unit, each unit contributing its share


of lum no to the total. In decree to the preloced lagouts will show how this is recordling.

Dualist are lights and many lipes of closely httput a manufactured to give various lighting characteristics. A complete Secondation of these anitalise included in the various catalogs of the manufactures and included as ching a are being as despecialistically which are upt to infilludace the results, the lighting eninter charles rein to the company being a peciation a upit.

distinctly distinct. The arm farm disperies land consisting of military decembers, is 1990 m.m. in disperse, is of high quality optical class, and is ground as arrestel land. This is the foot entreised unit and gives best control of the light. The most company used allocalight has a 24 meh dismet r, 10 meh notes, procision parabolic class reflector and can be obtained in either a 40° of 80° horizontal spread while the vertical divergence is 4°. Several units are use to that their usaus overly and provide even illustrate for the recognance intensity. Suppositive beam candle powers are shown on the attached drawings and illustrate how the required lighting is built up for the larger disports.




ILLUMINATION FOR SQUARE AIRPORTS




Airbort 2500 ft. square.
Minimum for A-1-A rating
Illuminated by one
bank of 6 chits. Each
unit with one 3000
watt, 32 volt, 78,000
lumen, GT38 bolb
and 440° = prend
lens.


Beacons, boundry, and obstruction lights are not shown.



Birtort 5000 x 5000 ft. Illuminated with one bank, of 14 units with 3000 watt, 32 volt, GT 38 bulbs each bulb emitting 78,000 lumens. 40° spread lens.

ILLUMINATING IRREGULARLY SHAPED AIRPORTS - T, L, AND X.





Use two banks of units.

Each unit with 3000 woth,

72 volts, GT 38 bulb.. This provides 15 feet cardles within the marked orea.

good for airports with a very uneven contour

There are 6 unite per bank and each but emite 18,000 lumens. 40° spread lens.

ELECTRIC FUUNTAINS

The classifying of an electric fountain under building illumination or area lighting would be hard to justify so it will be referred to as "Space Lighting" because that explains more nearly what actually takes place in a fountain.

water effects or just the one change, the task of illuminating it is comparatively easy. The lighting units are submerged in the water basin out of sight and they project their beams upward into space where they pass through the streams of water and spray giving the very pleasing appearance with which we are all familiar. Additional colors are furnished by extra sets of lighting units. All of the lighting units are, as a rule, connected to a cyclic dimmer so that the water is brilliantly lighted in ever-changing colors of red, amber, green and blue as it rises and falls.


the manufacturer of one line of fountains lists the following as the standard line. The smallest has 9 projectors and provides 7 colors and 7 water effects - 49 changes in 7 minutes. This installation uses 250 watt bulbs while all of the others use 1000 watt bulbs. Mext comes the 15 projector fountain. It has 10 color and 6 water effects - 60 changes in 6 minutes. Thirty-five projectors furnish illumination to the next larger size and it has 12 color and 8 water effects which take place in a 10 minutes eyels.


This one is particularly effective with its 70 foot central geyser. The largest one and by far the most pretentious boasts sixty-three 1000 watt projectors, which furnish 12 colors to 8 water effects, 96 changes in a 10 minute cycle. The largest also has a 70 foot central geyser and harmonizes well either in a large basin or as a lake type.

The projectors should be arranged uniformly around the fountain and located at the places which will produce the most inclusive effects on the water. This can easily be decided by drawing a diagram of the water pattern created by the fountain and placing the floodlights at the base of the spill water. Minor re-arrangements after putting the fountain in service will correct any apparent defects.



THE FAMOUS BUCKINGHAM MEMORIAL FOUNTAIN GRANT PARK, CHICAGO






EDISON BUILDING . PHILADELPHIA .








UNITS FOR EDISON BUILDING.

• **3**7,




NIGHT SKYLINE - CHICAGO






CHICAGO TRIBUNE TOWER





PHILADELPHIA ART MUSEUM

•




MISSOURI STATE CAPITOL






PURE OIL BUILDING - CHICAGO



* * · ·



CONSOLIDATED GAS BUILDING.



CARBON - CARBIDE BLOG. - CHICAGO.




BERKS COUNTY TRUST CO. READING, PA.
















- Single Lantern Brackets. -




Double Lantern Brackets.





THE ARENA - ST. LOUIS, MO.






DALLAS NATIONAL BANK - DALLAS

Floodlighted from two story building across


the street . -











·


















Textile Machine Works, Reading, Pa.




General Office Lighting




Permaflectors in Special Indirect Units






















· · ·



Quotation Boards







Lighting from Coves




•















FOOTBALL FIELD

AND UNITS

• به این . Ķ • • Ġ

;












TENNIS COURTS AND UNIT






GOLF DRIVING RANGE







R.R. SWITCHING YARD AND "HUMP"

. .










INTERIOR - THE ARENA - ST. LOUIS













MINIATURE GOLF COURSE - UNITS





TWO MINIATURE GOLF COURSES

.







NIGHT CONSTRUCTION AND UNIT.

·














TWO TYPES OF WINDOWS

:

.

.

v





RUG DISPLAY USING WINDOW FLOODLIGHTS





ART GALLERY




UNIT

Artificial skylight illumination in an Art Gallery.

Upper view shows arrangement of units above skylight.




Syracuse University Stadium Lighted with Type LCE-24 Floodlights



Rose Bowl—Pasadena, Calif. Lighted with Type LCE-24 Floodlights



Syracuse University Stadium Day View of Installation



Rose Bowl—Pasadena, Calif.
Day View of Installation




Night Game Showing Close-up of Play




Close-up of Floodlights on Tower

:






ARTIFICIAL SKYLIGHTS FOR LIBRARIES






SECURITY TITEE AND TRUST CO. WILMINGTON, DEL.



TIOGA NATIONAL BANK, PHILADELPHIA
ARTIFICIAL SKYLIGHTS.




1 General view of lobby.

1 Close-up of ceiling

1 Detail of one bay

hobby is cove illuminated from 15 art panels in the ceiling.



Totally indirect units and urns for bank lighting.






Pay Clarks Offices

Board of Directors Room.

Cove illuminated.







Examples of Cove Lighting




Totally indirect illumination - Office.





















Stock quotation boards illuminated from above by an inverted cove carrying 100 watt reflectors on 12" centers.







TWO MODEL


GAS STATIONS

AND THE UNIT

ELLUMINATING THEM



A WELL SLLUMINATED GAS STATION




NIGHT VIEW - GOLF DRIVING RANGE






THE UNITS USED.








THREE MODEL GAS STATIONS. LIGHT FROM LANTERN BRACKETS









200 WATT LANTERN BRACKETS FURISH THIS LIGHT



FOUNTAIN IN LOGAN SQUARE, PHILADELPHIA.



Today's ceiling shower or can is the artistic development chandelier of the early days of lighting.


More light—true—but a drab lifeles ness prevails—

.

.



Fanels removed







THREE TYPES OF LANTERN BRACKETS.



LANTERN BRACKET ASSEMBLIES



SYRACUSE, N.Y. AIRPORT. Illuminated by units placed around the boundry.



UNIT MOUNTING




TYPE AKP-14 UNIT.

.



MUNICIPAL AIRPORT - GRAND RAPIDS, MICHIGAN






Unit with door open, showing bulb, reflector and louvers.




SCENIC AIRWAYS - PHOENIX, ARIZONA




UNITS WHICH FURNISH ILLUMINATION

TO THE AIRPORT



MUNICIPAL AIRPORT. UTICA, N.Y.






ILLUMINATEO HANGAR




Wind Cone, Illuminated.

Type MSA-1 unit, a wide angle projector for hanger illumination.



John Warren Watson Co., Philadelphia, Pa.



14 "Unit Used.



Plain Curved Lens



Fanlite Lens Medium Angle



10008 COTTON Ca LCATTRAD LLOS

110 volt Standard Lighting Service Lamps

./atts	-	Lumon	Output
100		15:	50
150		250) U
20 O		22	\circ
5 00		583	\mathcal{O}
50 U		5 b))
750		140	JO
1000		2100	\circ

General Lighting and Flocalight Lamps

watts	Volts	Bulb	Lumens	surving Position
200	115	PEZO	334 0	Any
3 00	115	r535	5370	n'
5 0 0	115	P540	9650	11
750	115	£552	14550	11
1000	115	r552	20200	n
250	115	G 30	3570	base lown
$\mathfrak{s} \cup \mathfrak{O}$	115	640	830 <i>0</i>	-1
400	115	G 30	6240	11 11
1000	115	4 40	17 800	n u
1500	115	P552	31050	Any
1500	115	G 40	27000	Base Bown
1500	32	т 24	34500	rielā rloodlights
3 000	32	GTSS	78000	11 14
000c	115	4 64	130000	11
10000	115	U 8 O	260000	tt 2.

LULIA CUTPUT Ca LULTIPLI LILES

110 Volt Stalladed Lighting Service Lamps

watts	-	Lumun	Output
100		158	O
140		ZU() U
200		Z 20	$\mathcal{C}($
5 00		560) ()
50U		\$ 5 €)O
7EU		1400))
1000		2100))

General Lighting and Flocalight Lamps

watts	Volts	витр	Lumens	surving Position
200	115	P 530	334 0	Any
300	115	r535	5370	11
500	115	P540	9680	it
7:0	115	F552	14550	n
1000	115	r552	ຂົດຂຶ້ນບໍ	H
250	115	G 30	3570	nwoleesed
500	115	640	6300	-4
400	115	G 50	e240	11 11
1000	115	G 40	17800	11
1500	115	P552	31050	Any
1500	115	4 40	27000	Base Down
1500	22	т24	24500	rieli rloodli nts
3000	32	GT38	78000	11
၁000	115	4 64	130000	n u
10000	115	G 80	260000	# 44

The foot-candle values given in the following pages correspond to present standards for different classes of industrial operations, offices, stores, etc. They are merely an index to good practice. In most cases, where higher foot-candle values than shown in this table are being used, it is found that the benefits derived more than offset the slightly increased cost. The desirable illumination for any particular installation depends upon actual conditions, such as the accuracy of the operation, the fineness of detail to be observed, the color of the goods worked on or handled, and, in the case of stores, the advertising value resulting from the attractiveness of a well-lighted interior.

TABLE No. 5
Present Standards of Foot-Candles of Illumination for COMMERCIAL INTERIORS

	Foot-Candles Recommended			Foot-Candler Recommende	
	Good Practice	Mini- mum	٠	Good Practice	Mini- mum
Armories: Drill Sheds Exhibition Halls	10 12	6 8	Dance Halls Dental Offices:	6	4
Art Galleries: General On Paintings	5 25–100	3 10	Waiting Room. Operating Office Dental Chair	6 12 50	4 8 25
Auditoriums	5	3	Depot—Waiting Room	8	5
Automobile Show Rooms	15	10	Drafting Room	25	15
	10	10	Elevators:		
Bank: Lobby Cages and Offices	10 15	6 10	Freight and Passenger Fire Engine House:	6	4
Barber Shop	15	10	When Alarm is turned in	8	5
Base Ball—Indoor Game	15	10	At Other Times	3	2
Basket Ball	15	10	Garage—Automobiles:		
	13	10	Storage—Dead	3	2
Bowling: On Alley, Runwayand Seats	8	5	Live Repair Dept. and Washing	8 15	5 10
On Pins	25	15			
Billiards—General	6 25	4 15	Gymnasiums: Main Exercising Floor	12	8
Cars:			Swimming Pool Shower Rooms	8 6	5 4
Baggage, Day Coach, Din-			Locker Rooms	6	4
ing, Pullman	8	5	Fencing, Boxing, Wrestling	12	8
Mail: Bag Racks Letter Cases	12 15	8 10	Halls, Passageways in Interiors	3	2
Storage	6	4	Handball	25	15
Street Railway and Subway	10	6	Hospitals:		
Churches:	_	_	Lobby and Reception Room	6	4
Auditorium	3 8	2 5	Corridors	3	2
Pulpit or Rostrum	12	8	Wards (with local illumi-		
Art Glass Windows	25-50	15	nation)	5	3
Club Rooms:			Private Rooms	8 0.2	5
Lounge	5 12	3 8	Night Illumination Operating Table	100-200	0.1 75
Reading Room			Operating Room	15	10
Court Rooms	10	6	Laboratories	15	10

TABLE No. 5 (Continued)

Present Standards of Foot-Candles of Illumination for COMMERCIAL INTERIORS (Continued)

	Foot-Ca Recomm			Foot-Ca Recomm	
	Good Practice	Mini-		Good Practice	Mini-
Hotels:	Fractice	шиш		(Two to	
Lobby	8	5	Show Cases	times th	at of
Dining Room	6	4	Share Windows	store pro	per
Kitchen	10 8	6 5	Show Windows: Large Cities—		
Bed Rooms	3	2	Brightly Lighted District.	150	100
Writing Room	12	8	Secondary Business Loca-		
Library:			Neighborhood Stores	75 50	50 30
Reading Rooms	12	8	Medium Cities—	00	-
Stack Room	6	4	Brightly Lighted District.	75	50
Lodge Rooms	6	4	Neighborhood Stores Small Cities and Towns	50 50	30 30
Lunch Room	12	8	Lighting to Reduce Day-		•
Market	12	8	light Window Reflections.	200-1000	
Moving Picture Theatre:			Stores—Department and		
During Intermission	5	3	Large Specialty: Main Floors	15	10
During Pictures		0.1	Other Floors	12	8
Museum:			Basement Store	15	10
General	8	5	Stores-Medium Size:		
Special Exhibits	25-100	10	Art	12	8
Office Buildings:			Automobile Supply	12 12	8
Private and General Offices-	_		Bake Shop Book		8
Close Work	15	10	China	12	8
No Close Work	10	8	Cigar	15	10
File Room	6	4	Clothing	15 12	10 8
Reception Room	6	4	Confectionery Dairy Products	12	8
Post Office:			Decorator	12	8
Lobby	10	6	Drug	15	10
Sorting, Mailing, etc	15	10	Dry Goods Electrical Supply	15 15	10 10
Storage	10	6	Florist.	12	8
Private and General Offices	15	10	Furrier	15	10
File Room and Vault Corridors and Stairways	6	2	Grocery	12	.8
	•	-	Haberdashery	15 12	10 8
Railway:		-	Hat	15	10
Depot—Waiting Room Ticket Offices	8 12	5 8	Jewelry	15	10
Rest Room, Smoking Room	8	5	Leather, Handbags and	10	•
Baggage Checking Office	12	8	Trunks	12 12	8
Storage	6	4	Millinery	15	10
Concourse Train Platform	4	2	Music	12	8
	8	5	NotionsPiano	12 12	8
Restaurants			Shoe	15	10
Racquet	25	15	Sporting Goods	12	8
Schools:	_	- 0	Tailor	15 15	10 10
Auditorium	8	5	TobaccoVariety Store	15	10
Office	12	8	Telephone Exchanges:		
Corridors and Stairways	5	3	Operating Rooms	8	5
Drawing	25	15	Terminal Rooms	12	8
Laboratories	12 12	8	Cable Vaults	6	4
Sewing Rooms	25	15	Tennis (Indoor)	25–50	15
Study Room—Desks and			Theatres:		
Blackboards	12	8	Auditorium	3 8	5
Skating Rink (Indoor)	8	5	FoyerLobby	12	8
Squash	25	15	Toilet and Washrooms	6	4
The second secon					

TABLE No. 5 (Continued)

Present Standards of Foot-Candles of Illumination for INDUSTRIAL INTERIORS

	Foot-Candles Recommended			Foot-Candles Recommended	
	Good Practice	Mini- mum		Good Practice	Mini- mum
Aisles, Stairways, Passage-ways	3	2	Construction— Indoor General	5	3
	_		Dairy Products	12	8
Assembling:	8	5			•
Rough	12	8	Electric Manufacturing: Storage Battery, Molding		
Fine Extra Fine	20 50-100	12 25	of Grids, Charging Room Coil and Armature Wind-	10	6
Automobile Manufacturing:			ing, Mica Working, Insulating Processes	20	12
Automatic Screw Machines	15	10	Elevator-Freight and Pas-		
Assembly Line	15	10	senger	8	5
Frame Assembly	12 20	8 12	Engraving	50-100	25
Body Manufacturing—					
Assembly, Finishing and	50 100	05	Forge Shops and Welding	10	6
Inspecting	50-100	25	Foundries:		
Bakeries	12	8	Charging Floor, Tumbling, Cleaning, Pouring and Shaking Out	8	5
Book Binding:			Rough Molding and Core		•
Folding, Assembling, Past-	8	5	N18K1DR	10	6
ing, etc	•	3	Fine Molding and Core Making	15	10
Stitching	12	. 8			
Embossing	15	10	Garage—Automobiles: Storage—Dead	3	2
Candy Making	12	8	Live	8	5
Canning and Preserving	12	8	Repair Dept. and Washing	15	10
			Glass Works:		
Chemical Works:			Mix and Furnace Rooms,		
Hand Furnaces, Boiling Tanks, Stationary Driers,			Pressing and Lehr, Glass Blowing Machines	10	6
Stationary or Gravity Crys-			Grinding, Cutting Glass to	10	
tallizing	5	3	Size, Silvering. Fine Grinding, Polishing,	12	8
erators and Stills, Mechan-			Beveling, Inspection, Etching and Decorating		
ical Driers, Evaporators,			ing and Decorating	15	10
ical Driers, Evaporators, Filtration, Mechanical	4		Glass Cutting (Cut Glass), Inspecting Fine	25 -50	15
Crystallizing, Bleaching Tanks for Cooking, Ex-	6	•	Glove Manufacturing:		
tractors, Percolators, Ni-		_	Light Goods—		
trators, Electrolytic Cells.	10	6	Cutting, Pressing, Knitting	12	8
Clay Products and Cements:			Sorting, Stitching, Trim- ming and Inspecting	15	10
Grinding, Filter Presses,	_	_	Dark Goods		
Kiln Rooms Clean	5	3	Cutting, Pressing, Knitting	15	10
Molding, Pressing, Clean- ing and Trimming	8	5	Sorting, Stitching, Trim- ming and Inspecting	50-100	25
Enameling	10 15	6 10	Hat Manufacturing:		
Color and Glazing	13	10	Dyeing, Suffening, Braid-		
Cloth Products:			ing, Cleaning and Renn-		
Cutting, Inspecting, Sew-			ing— Light	10	6
ing— Light Goods	15	10		15	10
Dark Goods	50-100	25	Forming, Sixing, Pouncing, Flanging, Finishing, Iron-		
(Oil Cloth etc.)—			ing—		
Light Goods	12	8	Light	12	.8
Dark Goods	20	12	Dark Sewing—	15	10
Coal Breaking and Washing, Screening	5	3	Light	15 50-100	10 2 5

TABLE No. 5 (Continued)

Present Standards of Foot-Candles of Illumination for INDUSTRIAL INTERIORS (Continued)

	Foot-Candles Recommended			Foot-Candles Recommended	
	Good Practice	Mini- mum		Good Practice	Mini- mum
Ice Making:			Milling-Grain Foods:		
Engine and Compressor Room	10	6	Cleaning, Grinding and Rolling Baking or Roasting	8 12	5 8
Inspecting:			Flour Grading	25	15
Rough	10 15 25 50–100	6 10 15 25	Offices: Private and General— Close Work No Close Work	15 10	10 8
	Usually		Drafting Room	25	15
Polished Surfaces	glint ref from s located source	pecially	Packing: Crating Boxing	6 10	4 6
Jewelry and Watch Manufacturing	50-100	25	Paint Manufacturing	10	6
			Paint Shops:		
Laundries and Dry Cleaning	12	8	Dipping, Spraying, Firing Rubbing, Ordinary Hand	8	5
Leather Manufacturing:			Painting and Finishing Fine Hand Painting and	12	8
Vats	5	3	Finishing Extra Fine Hand Painting	15	10
Stretching Cutting, Fleshing and Stuff- ing	6 10	6	and Finishing (Automobile Bodies, Piano Cases, etc.).	50-100	25
Finishing and Scarfing	15	10	Paper Box Manufacturing:		
Leather Working:			Light Dark Storage of Stock	10 12 5	6 8 3
Pressing, Winding and				J	•
Glazing— Light	12	8	Paper Manufacturing:		
Grading, Matching, Cut-	15	10	Beaters, Machine, Grinding Calendering Finishing, Cutting and	6 10	6
ting, Scarfing, Sewing— Light	15	10	Trimming	12	8
Dark	50-100	25	Plating	8	5
Locker Rooms	6	4	Polishing and Burnishing	12	8
Machine Shops:			Power Plants, Engine Rooms, Boilers:		
Rough Bench and Machine Work	10	6	Boilers, Coal and Ash Handling, Storage Battery		
matic Machines, Rough			Auxiliary Equipment, Oil	5	3
Grinding, Medium Buffing and Polishing Fine Bench and Machine	15	10	Switches and Transformers Switchboard, Engines, Gen- erators, Blowers, Compres-	8	•
Work, Fine Automatic Ma-			sors	10	0
chines, Medium Grinding, Fine Buffing and Polishing Extra Fine Bond and Ma-	20	12	Printing Industries: Matrixing and Casting, Miscellaneous Machines,		
chine Work, Grinding (Fine Work)	50-100	25	Presses	12	8
Meat Packing:			Proof Reading, Lithographing, Electrotyping	15	10
Slaughtering	8	5	Linotype, Monotype, Type- setting, Imposing Stone, Engraving	50-100	25
ing, Grinding, Canning, Packing	12		Receiving and Shipping	6	4

FOOT-CANDLES REQUIRED

TABLE No. 5 (Continued)

Present Standards of Foot-Candles of Illumination for INDUSTRIAL INTERIORS (Continued)

on for

Foot-Candles Recommended Good Mini-Practice mum

	Foot-Ca Recomn			Foot-Ca Recomm	
	Good Practice	Mini- mum		Good Practice	Mini- mum
Rubber Manufacturing and			Store and Stock Rooms:		
Products:			Rough bulky material	3	2
Calendars, Compounding Mills, Fabric Preparation, Stock Cutting, Tubing Ma-			Medium or fine material requiring care	8	5
Stock Cutting, Tubing Machines, Solid Tire Operations, Mechanical Goods			Structural Steel Fabrica-	10	6
Building, Vulcanizing	12	8	Sugar Grading	25	15
Building, Vulcanizing Bead Building, Pneumatic			Testing:		
Tire Building and Finish- ing, Inner Tube Operation, Mechanical Goods Trim-			Rough	8	5
Mechanical Goods Trim-	15	10	Fine Extra Fine Instruments,	15	10
ming, Treading	10	••	Scales, etc	50-100	25
Sheet Metal Works:			Textile Mills:		
Miscellaneous Machines, Ordinary Bench Work	12	8	(Cotton)—		
Punches, Presses, Shears,		•	Opening and Lapping, Carding, Drawing-frame,		
Stamps, Welders, Spinning, Fine Bench Work	15	10	Roving, Dveing	8	
Tin Plate Inspection	25	15	Spooling, Spinning, Drawing-in, Warping, Weaving,		
Shoe Manufacturing:			Quilling, Inspecting, Knit-		
Hand Turning, Miscella-			ting, Slashing (over beam	12	8
neous Bench and Machine	10		end)	12	0
Work	12	8	Winding, Throwing, Dye-	12	8
Material, Cutting, Lasting	10	10	Quilling, Warping, Weav-	12	•
and Welting (Light) Inspecting and Sorting Raw	15	10	ing Quilling, Warping, Weav- ing and Finishing— Light Goods	15	10
Material, Cutting, Stitch-	ED 100	25	Dark Goods	20	15
ing (Dark)	50-100	25	(Woolen)— Carding, Picking, Washing		
Soap Manufacturing:			and Combing Twisting and Dyeing	6	4
Kettle Houses, Cutting, Soap Chip and Powder	8	5	Twisting and Dyeing Drawing-in, Warping—	10	
Stamping, Wrapping and Packing, Filling and Pack-	•	•	Light Goods	10	6
Packing, Filling and Pack- ing Soap Powder	10	6	Dark Goods	15	10
		•	Light Goods	12	8
Steel and Iron Mills, Bar, Sheet and Wire Products:			Dark Goods	20 15	12 10
Soaking Pits and Reheating			•	13	10
Furnaces Charging and Casting	3	2	Tobacco Producta: Drying, Stripping, General	3	9
Floors	6	4	Grading and Sorting	25	15
Muck and Heavy Rolling.			Toilet and Wash Rooms	6	4
Shearing, rough by gauge, Pickling and Cleaning	. 8	. 5	Upholstering:		
Plate Inspection, Chipping Automatic Machines, Red,	25	15	Automobile, Coach and		_
Light and Cold Rolling, Wire Drawing, Sheering,			Furniture	15	10
fine by line	12	8	Warehouse	3	2
		_	Woodworking:		
Stone Crushing and Screening: Belt Conveyor Tubes,			Rough Sawing and Bench Work	8	5
Main Line Shafting, Spaces, Chute Rooms, In-			Sizing, Planing, Rough Sanding, Medium Machine	v	
Spaces, Chute Rooms, Inside of Bins	3	2	Sanding, Medium Machine and Bench Work, Gluing,		
Primary Breaker Room,	•	~	Veneering, Cooperage	12	8
Auxiliary Breakers under Bins	5	3	Fine Bench and Machine Working, Fine Sanding and		
Screen Rooms	8	5	Finish	15	

FOOT-CANDLES REQUIRED

TABLE No. 5 (Continued)

Foot-Candles Illumination for OUTDOOR LIGHTING

These values are included for reference purposes although the special considerations of design are not covered in this bulletin.

	Foot-Ca Recomm			Foot-Ca Recomn	
	Good Practice	Mini- mum		Good Practice	Mini- mum
Automobile Parking Spaces. Baseball Diamond (Indoor	1	0.5	Gasoline Filling Stations: At Pumps Yard and Driveways	15 4	10 2
Game)	10	9	Horseshoe Pitching	6	4
Basket Ball	6	4	Ice Hockey	8	5
Bathing Beaches	1	0.5	Loading Docks	3	2
Bulletin and Poster Boards: Bright Surroundings—			Lumber Yards	1	0.5
Light Surface Dark Surface	30 50	20 30	Seating	3 15	10
Dark Surroundings— Light Surface	15	10	Monuments (See Building Exteriors)		
Dark SurfaceBoxing:	30	20	Piers: Freight (See Loading Docks)		
Seats	3 80	2 50	Passenger	4	2
Ring	80	30	Playgrounds	4	2
Building: Construction Work	6	4	Polo	8	5
Excavation	2	i	Prison Yards	3	2
Building Exteriors and Mon-			Protective Industrial	1	0.5
uments—Floodlighted: Bright Surroundings—	10		Quarries	3	2
Light Surface Dark Surface Dark Surroundings—	20	15	General Scale House	0.25	0.15
Light Surface Dark Surface	6 12	8	RoqueSigns—Painted (See Poster	6	4
Church Windows (Art Glass)	25-50	15	Boards)		
Circus:			Ship Yard Construction	6	4
Seats	.3	2	Skating	2	1
Arena	10	6	Storage Yards	1	0.5
Clock Golf	10	6	Swimming Pools	5	3
Croquet	6	4	Target Shooting	20	15
Dredging	2	1	Tennis Court	25-50	15
Drill Fields	3	2	Toboggan Slides	2	1
Flags—Floodlighted	25-50	15	Traffic Officers	20	10
Football: Practice	6	4	Trap Shooting	15	10
Games	12	8	Volley Ball	15	10

STREETS AND THOROUGHFARES

	Lamp Lumens per Linear Foot of Street
Business District:	
White Way-Large City	. 500-2000
Small City	. 200-500
Park Boulevards	. 50-100
Thoroughfares and Wholesale Districts	. 50-200
Residence Streets	. 20-40
Outlying Districts and Alleys	5-10
Highways	. 10-20

ROOM EFFICIENCY AND REFLECTOR CHARACTERISTICS



special

0.5

Illumination on Horizontal Surfaces is a prime requisite in offices, drafting rooms and those shops where the problem is to provide the best illumination for sustained vision of flat surfaces on the horizontal or slightly oblique planes in which papers, books and other flat objects are usually examined. For relative performance of various units compare coefficients of utilization for any given condition.



Illumination on Vertical Surfaces is essential in many industrial operations where working surfaces are in vertical or oblique planes. It is likewise important in stores with vertical shelving, rug racks, etc., in art museums, library stock rooms, office file rooms. Without supplementary units, the illumination on vertical surfaces from ordinary general lighting units is of the order of one-half to one-third of the horizontal illumination values.



Appearance of Lighted Room refers only to the general or casual effect produced by the complete system, and is not intended to rate the unit as to satisfaction from the standpoint of good vision or freedom from eye fatigue.



Direct Glare is the most frequent and serious cause of bad lighting. It results among other things from unshaded or inadequately shaded light sources located within the field of vision, or from too great contrast between the bright light source and a dark background or adjacent surfaces. Glare should be avoided by the use of proper reflecting and diffusing equipment.



Reflected Glare from polished working surfaces is particularly annoying because of the necessity of directing the eyes toward those surfaces, and further because the eyes are by nature especially sensitive to light rays from below. The harmful effects of this specular reflection can be minimized by properly shielding from below or diffusing the source.



Shadows, that is, differences in brightness of surfaces, are essential in observing objects in their three dimensions, but are of little or no value in the observation of flat surfaces. Where shadows are desirable, they should be soft and luminous, not so sharp and dense as to confuse the object with its shadow.



Maintenance Requirements depend upon contour of reflector, construction of fixture, and average maintenance conditions. The rating is based upon the likelihood of breakage, the labor involved in maintaining the units at comparable degrees of efficiency, and indication given of need of cleaning.

ROOM EFFICIENCY AND REFLECTOR CHARACTERISTICS

TABLE 6 ROOM INDEX FOR NARROW AND AVERAGE ROOMS

					FEET			
For Indirect Use Ceiling		9 and 91/2	10 to 11½	12 to 13½	14 to 16½	17 to 20	21 to 24	25 to 30
					FEET			,
For Direct Use Mountin		7 and 71/2	8 and 8½	9 and 91/2	10 to 11½	12 to 13½	14 to 16½	17 to 20
Room Width (Feet)	Room Length (Feet)			RO	OM INI	EX		
9 (8½-9½)	8-10 10-14 14-20 20-30 30-42 42-up	1.0 1.0 1.2 1.2 1.5 2.0	0.8 0.8 1.0 1.2 1.2 1.5	0.6 0.8 0.8 1.0 1.0	0.6 0.6 0.8 0.8 1.0	0.6 0.6 0.6 0.8	0.6 0.6 0.6	0.6 0.6
10 (9½-10½)	10-14 14-20 20-30 30-42 42-60 60-up	1.2 1.5 1.5 2.0 2.0	1.0 1.0 1.2 1.2 1.5 1.5	0.8 0,8 1.0 1.2 1.2 1.5	0.6 0.8 1.0 1.0	0.6 0.6 0.8 0.8 1.0	0.6 0.6 0.6 0.6 0.8	0.6 0.6 0.6
12 (11-12½)	10-14 14-20 20-30 30-42 42-60 60-up	1.2 1.5 1.5 2.0 2.0 2.0	1,0 1,2 1,2 1,5 1,5 2,0	0.8 1.0 1.2 1.2 1.5 1.5	0.8 0.8 1.0 1.0 1.2 1.2	0.6 0.8 0.8 1.0 1.0	0.6 0.6 0.6 0.6 0.8 0.8	0.6 0.6 0.6 0.6
14 (13-15½)	14-20 20-30 30-42 42-60 60-90 90-up	1.5 2.0 2.0 2.0 2.5 2.5	1.2 1.5 1.5 2.0 2.0 2.0	1.0 1.2 1.5 1.5 2.0 2.0	1.0 1.0 1.2 1.5 1.5	0.8 0.8 1.0 1.0 1.2 1.5	0.6 0.6 0.8 0.8 1.0 1.2	0.6 0.6 0.6 0.6 0.6 0.8
17 (16-18½)	14-20 20-30 30-42 42-60 60-110 110-up	2.0 2.0 2.5 2.5 2.5 3.0	1.5 1.5 2.0 2.0 2.0 2.5	1.2 1.5 1.5 2.0 2.0 2.0	1.0 1.2 1.2 1.5 1.5 2.0	0.8 1.0 1.0 1.2 1.2	0.6 0.8 1.0 1.2 1.2	0.6 0.6 0.8 0.8 1.0
20 (19-21½)	20-30 30-42 42-60 60-90 90-140 140-up	2.5 2.5 2.5 3.0 3.0 3.0	2.0 2.0 2.5 2.5 2.5 2.5 2.5	1.5 2.0 2.0 2.0 2.5 2.5	1.2 1.5 2.0 2.0 2.0 2.0	1.0 1.2 1.5 1.5 1.5	0.8 1.0 1.2 1.2 1.5 1.5	0.6 0.8 0.8 1.0 1.0
24 (22-26)	20-30 30-42 42-60 60-90 90-140 140-up	2.5 3.0 3.0 3.0 3.0 3.0	2.0 2.5 2.5 2.5 3.0 3.0	2.0 2.0 2.5 2.5 2.5 2.5 2.5	1.5 1.5 2.0 2.0 2.0 2.0	1.2 1.2 1.5 1.5 2.0 2.0	1.0 1.2 1.2 1.5 1.5	0.8 0.8 1.0 1.0 1.2 1.2
30 (27-33)	30-42 42-60 60-90 90-140 140-180 180-up	3.0 3.0 4.0 4.0 4.0 4.0	2.5 3.0 3.0 3.0 3.0 3.0 3.0	2.5 2.5 3.0 3.0 3.0 3.0	2.0 2.5 2.5 2.5 2.5 2.5 2.5	1.5 1.5 2.0 2.0 2.0 2.0 2.0	1.2 1.5 1.5 2.0 2.0 2.0	1.0 1.0 1.2 1.5 1.5
36 (34-39)	30-42 42-60 60-90 90-140 140-200 200-up	4.0 4.0 5.0 5.0 5.0 5.0	3.0 3.0 3.0 4.0 4.0 4.0	2.5 3.0 3.0 3.0 3.0 3.0	2.0 2.5 3.0 3.0 3.0 3.0	1.5 2.0 2.0 2.5 2.5 2.5	1.5 1.5 2.0 2.0 2.0 2.0	1.0 1.2 1.5 1.5 1.5 1.5
40 or more	42-60 60-90 90-140 140-200 200-up	5.0 5.0 5.0 5.0 5.0	4.0 4.0 4.0 5.0 5.0	3.0 4.0 4.0 4.0 4.0	The	se value	s are give	

ming Position

nwoi oust

n n

ROOM EFFICIENCY AND REFLECTOR CHARACTERISTICS

RISTICS

XOMS

0.6 0.6 0.6 0.6 0.8

0.6 0.8 0.8 1.0 1.0 0.8 1.0 1.2 1.2 1.0 1.0 1.2

0.6 0.6 0.6

TABLE 6 ROOM INDEX FOR LARGE HIGH ROOMS

					FE	ET			
For Indirect Use Ceiling		14 to 16½	17 to 20	21 to 24	25 to 30	31 to 36	37 to 50		
					FE	ET			
For Direct Use Mounti		10 to 11½	12 to 13½	14 to 161/2	17 to 20	21 to 24	25 to 30	31 to 36	87 to 50
Room Width (Feet)	Room Length (Feet)				ROOM	INDEX	ζ.		
14 (13-15½)	14-20 20-30 30-42 42-60 60-90 90-up	1.0 1.0 1.2 1.5 1.5	0.8 0.8 1.0 1.0 1.2 1.5	0.6 0.6 0.8 0.8 1.0 1.2	0.6 0.6 0.6 0.6 0.6 0.8	0.6 0.6 0.6 0.6	0.6 0.6 0.6		
17 (16-18½)	14-20 20-30 30-42 42-60 60-110 110-up	1.0 1.2 1.2 1.5 1.5 2.0	0.8 1.0 1.0 1.2 1.2 1.5	0.6 0.8 1.0 1.2 1.2	0.6 0.6 0.8 0.8 1.0	0.6 0.6 0.6 0.6 0.8	0.6 0.6 0.6 0.6	0.6 0.6 0.6	
20 (19-21½)	20-30 30-42 42-60 60-90 90-140 140-up	1.2 1.5 2.0 2.0 2.0 2.0	1.0 1.2 1.5 1.5 1.5 1.5	0.8 1.0 1.2 1.2 1.5 1.5	0.6 0.8 0.8 1.0 1.0	0.6 0.6 0.6 0.6 0.8 1.0	0.6 0.6 0.6 0.8 0.8	0.6 0.6 0.6 0.6	0.6 0.6
24 (22-26)	20-30 30-42 42-60 60-90 90-140 140-up	1.5 1.5 2.0 2.0 2.0 2.0	1.2 1.2 1.5 1.5 2.0 2.0	1.0 1.2 1.2 1.5 1.5	0.8 0.8 1.0 1.0 1.2	0.6 0.6 0.8 0.8 1.0	0.6 0.6 0.6 0.6 0.8 0.8	0.6 0.6 0.6 0.8	0.6 0.6 0.6
30 (27-33)	30-42 42-60 60-90 90-140 140-180 180-up	2.0 2.5 2.5 2.5 2.5 2.5 2.5	1.5 1.5 2.0 2.0 2.0 2.0	1.2 1.5 1.5 2.0 2.0 2.0	1.0 1.0 1.2 1.5 1.5	0.8 1.0 1.0 1.2 1.2	0.6 0.8 0.8 1.0 1.0	0.6 0.6 0.6 0.8 0.8	0.6 0.6 0.6 0.6
36 (34-39)	30-42 42-60 60-90 90-140 140-200 200-up	2.0 2.5 3.0 3.0 3.0 3.0	1.5 2.0 2.0 2.5 2.5 2.5 2.5	1.5 1.5 2.0 2.0 2.0 2.0 2.0	1.0 1.2 1.5 1.5 1.5 1.5	0.8 1.0 1.0 1.2 1.5 1.5	0.8 0.8 1.0 1.0 1.2	0.6 0.6 0.6 0.8 1.0	0.6 0.6 0.6 0.8 0.8
42 (40-45)	42-60 60-90 90-140 140-200 200-up	3.0 3.0 3.0 3.0 3.0	2.0 2.5 2.5 2.5 2.5 2.5	1.5 2.0 2.5 2.5 2.5 2.5	1.2 1.5 2.0 2.0 2.0 2.0	1.0 1.2 1.5 1.5 1.5	0.8 1.0 1.2 1.2 1.5	0.8 0.8 1.0 1.0	0.6 0.6 0.6 0.8 0.8
50 (4 6-55)	42-60 60-90 90-140 140-200 200-up	3.0 3.0 3.0 3.0 3.0	2.5 3.0 3.0 3.0 3.0	2.0 2.5 2.5 2.5 2.5 2.5	1.5 1.5 2.0 2.0 2.0	1.2 1.5 1.5 2.0 2.0	1.0 1.2 1.5 1.5 1.5	0.8 1.0 1.2 1.2 1.2	0.6 0.8 0.8 1.0
60 (56-67)	60-90 90-140 140-200 200-up	4.0 4.0 4.0 4.0	3.0 3.0 3.0 3.0	2.5 3.0 3.0 3.0	2.0 2.5 2.5 2.5 2.5	1.5 2.0 2.0 2.0	1.2 1.5 1.5 2.0	1.0 1.2 1.5 1.5	0.8 1.0 1.0 1.0
75 (68-90)	60-90 90-140 140-200 200-up	5.0 5.0 5.0 5.0	4.0 4.0 4.0 4.0	3.0 3.0 4.0 4.0	2.5 2.5 3.0 3.0	2.0 2.0 2.5 2.5	1.5 1.5 2.0 2.0	1.2 1.5 1.5 1.5	0.8 1.0 1.2 1.2
90 or more	60-90 90-140 140-200 200-up	5.0 5.0 5.0 5.0	4.0 5.0 5.0 5.0	3.0 4.0 4.0 4.0	2.5 3.0 3.0 3.0	2.0 2.5 2.5 3.0	1.5 2.0 2.0 2.5	1.2 1.5 1.5 2.0	1.0 1.2 1.2 1.5

						_			
LIGHTING	UNIT	RELATIVI CANDLES FO LAMP	DR A GIVEN	APPEAR- ANCE OF LIGHTED	DIRECT GLARE	RE- FLECTED	SHADOWS	MAIN- TENANCE	
		On Horizontal	On Vertical	ROOM		GLARE			
	Direct Lighti	ng—Ger	neral In	ndustria	al Refle	ectors			
I RLM White Bowl Lamp 90° to 180°—0% 0° to 90°—66%		A Excellent	B Good	B Good	B+ Very Good	B Good	B+ Very Good	A — Very Good	
2 Glassteel Diffuser Clear Lamp 90° to 180°—7% 0° to 90°—60%		A — Very Good	B Good	A — Very Good	A — Very Good	B+ Very Good	A Excellent	B Good	
	$\mathbf{S}_{\mathbf{l}}$	pecial R	LM Ap	plicatio	ns				
3 RLM Dome Dust-tight Cover 90° to 180°—0% 0° to 90°—54%		B Good	B — Very Fair	B Good	B Good	B- Very Fair	B+ Very Good	A+ Excellent	
4. RLM Dome Clear Lamp 90 * to 180 * -0% 0 * to 90 * -76%		A+ Excellent	B+ Very Good	C+ Very Fair	C Satisfactory above 20-foot mount- ing Height	D Unsatisfactory above Polished Surfaces	C+ Very Fair	A+ Excellent	
was been a	Industrial l	Reflector	s for I	ligh Na		Bays			
Concentrated Prismatic Reflector Aluminum Cover Clear Lamp 90° to 180°—5% 0° to 90°—72%		A+ Excellent	B Good	B Good	C+ Very Fair	D Unsatis- factory above Polished Surfaces	C Fair	A Excellent	
Mirrored Glass Reflector Clear Lamp 90° to 180°—3% 0° to 90°—73%		A+ Excellent	B Good	B Good	C+ Very Fair	D Unsatis- factory above Polished Surfaces	C Fair	A Excellent	
Oxidized Aluminum Reflector Clear Lamp 90° to 180°—0% 0° to 90°—12%		A+ Excellent	B Good	B Good	C Very Fair	D Unsatisfactory above Polished Surfaces	C+ Fair	A — Very Good	
	-		24						

TABLE No. 7
AND COEFFICIENTS OF UTILIZATION

OWS TEXANCE

В

A+

A+

		Al	ND CO	EFFIC	TENIS	OF OF	UTILIZ	LATIU	14		
	E AVERAG		CEILING	VERY	LIGHT (10%)	FAIRL	LIGHT	(50%)	FAIRLY DA	RK (30%)
	N—AS FR IAL ILLUM		WALLS	FAIRLY LIGHT (50%)	FAIRLY DARK (30%)	VERY DARK (10%)	FAIRLY LIGHT (50%)	FAIRLY DARK (30%)	VERY DARK (10%)	FAIRLY DARK (30%)	VERY DARK (10%)
Clean Conditions	Average Conditions	Dirty Conditions	ROOM			FFICU	ENTS			TION	
			INDEX			111011		01 01	15127	11011	
						_	eral Uı				
	1		0.6 0.8	.32 .40	.28 .36	.25	.32 .39	.28 .35	.25 .33	.27 .35	.25 .33
			1.0 1.2	.43 .46	.39 .43	.37 .41	.42 .45	.39 . 43	.37 .41	.39 .43	.37 .41
90	.75	.65	1.5	.48	.45	.43	.47	.45	.43	.45	.43
.80		.05	2.0 2.5	.52 .56	.50 .54	.48 .52 .53	.51 .55 .56	.49 .53 .54	.47 .51 .52	.49 .53 .54	.51
			3.0 4.0	.57 .60	.55 .58 .59	.53 .56 .57	.59	.54 .57 .58	.52 .55 .57	.54 .57 .58	.47 .51 .52 .55 .56
	1		5.0 0.6	.61	.59 .25	.57	.60 .28	.58	.57	.58	.56
			0.8 1.0	.36 .39	.32	.21 .29 .33	.35 .38	.24 .31 .35	.21 .28 .33	.23 .31 .34	.28
			1.2	.42	.39	.36	.41	.38	.36	.37	.35
.75	.70	.60	1.5 2.0	.45 .49	.42 .46	.39 .43	.43 .48	.40 .45	.38 .43	.39 .44	.38 .42
			2.5 3.0	.53 .54	.50	.47 .49	.51 .52	.49 .50	.47 .49	.47 .49	.46 .47
			4.0 5.0	.57 .58	.52 .55 .56	.53 .54	.55 .56	.53 .54	.51 .53	.51 .52	.50 .51
	'	C					pecial			.02	
			0.6	.29 .35	.26 .32	.24 .31	.28	.26 .32	.24	.26 .32	.24
			1.0	.37	.36	.35	.37	.35	.34	.35	.34 .37
			1.2 1.5	.40 .42	.38 .41	.37 .38	.39 .41	.38 .39	.37 .38	.37 .39	.38
.80	.75	.70	2.0 2.5	.44 .48	. 43 . 4 5	.41 .44	.44	.43 .45	.41	.42 .44	.41 .44
			3.0 4.0	.49 .50	.47 .48	.45 .48	.48 .49	.46 .47	.45 .46	.45 .46	.44 .46
	<u> </u>		5.0	.52	.49	.48	.50	.48	.47_	.48	.46
			0.6 0.8	.34 .42	.29 .38	.24 .34	.34 .42	.29 .37	.24	.28 .37	.24 .33 .39
			1.0 1.2	.46 .50	. 43 . 4 7	. 3 9 . 43	.45 .49	.42 .46	.39 .43	.42 .45	.42
.80	.75	.70	1.5 2.0	.53 .58	.50 .55	.46 .51	.52 .57	.49 .54	.46 .51	.48 .53	.45 .51
•••		11.5	2.5 3.0	.62 .64	.59 .61	.56 .58	.61 .63	.58 .60	.56 .58	.58 .60	.56 .58
			4.0	.67	.65	.63 .65	.66	.64 .66	.62 .64	.63 .65	.61
			5.0 Calcu	.69 Ilation	.67 Data-		.67 Bay U		1 .049	0.7	.63
	1		0.6	.42	.39	.38	.41	.39	.38	.40	.37
			0.8 1.0	.50 .54	.48 .53	.47 .52	.49 .53	.47 .52	.46 .51	.47 .51	.45 .50
			1.2 1.5	.58 .61	.57 .59	.56 .57	.56 .58	.55 .57	.54 .56	.54 .57	.53 .55
.80	.75	.65	2.0 2.5	.63 .67	.62 .64	.60 .63	.62 .65	.61 .63	.59 .62	.59 .62	.58 .61
			3.0	.68	.67 .68	.64	.66	.65 .66	.63	.63 .64	.62
			4.0 5.0	.69 .72	.69	.67 .68	.67 .68	.67	.65 .66	.65	.63 .64
			0.6 0.8	.42 .51	.40 .49	.39 .48	.42 .49	.40 .48	.39	.41 .48	.38 .46
			1.0 1.2	.55 .59	.54 .58	.53 .57	.54 .57	.53 .56	.52 .55	.52 .55	.51 .54
.80	.70	60	1.5	.61	.60	.58	.57 .59	.58	.57	.58	.56
.00		.60	2.0 2.5	.64 .68	.63 .65	.61 .64	.62 .65	.61 .64	.60 .63	.61 .63	.59 .62
			3.0 4.0	.69 .70	.67 .69	.65 .68	.67 .68	.65 .66	.64 .65	.64 .65	.63 .64
	<u> </u>		5.0 0.6	.72 .41	.70	.69	.69 . 4 0	.67	.66	.66 .40	.65
			0.8 1.0	.49 .52 .55	.47 .52	.47 .51	.48 .52	.39 .47 .51	.46 .50	.47 .51	.37 .44 .50
			1.2	.55	.54	.54	.54	.54	.52	.54	.52 .54
.80	.70	.60	1.5 2.0	.59 .61	.57 .60	.56 .59	.57 .60	.56 .60	.55 .58	.56 .59	.57
			2.5 3.0	.65 .66	.63 .65	.62 .63	.63 .64	.62 .63	.61 .62	.61 .62	.60 .61
			4.0 5.0	.67 .69	.65 .67	.65 .65	.65 .66	.64 .65	.63 .64	.63 .64	.62 .63
			V.U		.01						

25

TABLE No. 7 (Continued) A GUIDE TO THE SELECTION OF REFLECTING EQUIPMENT

LIGHTING UNIT		RELATIV CANDLES FO LAMP	OR A GIVEN	APPEAR- ANCE OF LIGHTED	DIRECT GLARE	RE- FLECTED	SHADOWS	MAIN- TENANCE
		On Horizontal	On Vertical	ROOM		GLARE		
	Store and	General	Utility	Enclos	sing Un	its		
Flattened White Glass Enclosing Globe 90° to 180°—35% 0° to 90°—45%		B+ Very Good	B+ Very Good	A Excellent	B Good	B+ Very Good	A — Very Good	B+ Very Good
9 Prismatic Glass Enclosing Unit 90° to 180°—27% 0° to 90°—53%		A — Very Good	B+ Very Good	A Excellent	B Good	B- Very Fair	B Good	B Good
	Enclosed	Semi-I	ndirect	Lightin	ng Unit	s		
10 Semi-Indirect Enameled Bottom Etched Top Skeleton Glass Holder 90° to 180°—50% 0° to 90°—27%		B — Very Fair	B- Very Fair	A Excellent	A — Very Good	B+ Very Good	A — Very Good	B Good
Enclosed Semi-Indirect Enameled Bottom Etched Top 90° to 180°—48% 0° to 90°—32%		B . Good	B- Very Fair	A Excellent	A — Very Good	B+ Very Good	A — Very Good	B Good
Enclosed Semi-Indirect Enameled Bottom Etched Top (Close Ceiling Only) 90° to 180°—53% 0° to 90°—22%		B — Very Fair	C+ Very Fair	A Excellent	A Excellent	A — Very Good	A Excellent	B Good
Enclosed Semi-Indirect Cased-Glass Bottom Etched Top 90° to 180°—51% 0° to 90°—21%		C+ Very Fair	C+ Very Fair	A Excellent	A Excellent	A Excellent	A Excellent	B — Very Fair
14 Enclosed Semi-Indirect Prismatic Glass 90° to 180°—69% 0° to 90°—17%		B- Very Fair	C+ Very Fair	A Excellent	A Excellent	A Excellent	A Excellent	B Good

TABLE No. 7 (Continued) AND COEFFICIENTS OF UTILIZATION

	E AVERAG		CEILING	VERY	LIGHT (70%)	FAIRL	Y LIGHT	(50%)	FAIRLY DA	RK (30%)
OF INIT	N—AS FR IAL ILLUN	INATION	WALLS	FAIRLY LIGHT (50%)	FAIRLY DARK (30%)	VERY DARK (10%)	FAIRLY LIGHT (50%)	FAIRLY DARK (30%)	VERY DARK (10%)	FAIRLY DARK (30%)	VERY DARK (10%)
Clean Cendition	Average Condition	Dirty * Condition	ROOM		COE	FFICIE	ENTS	OF UT	ILIZA	TION	
				ılation	Data-	-Encl	osing U	Inits			
		1	0.6	.22	.17 .22	.14	.20 .25	.16 .21	1.13	.14 .19	.12 .17
			1.0 1.2	.31 .35	.26 .30	.23 .26	.28 .31	.24	.21 .24	.22 .25	.19
.80	.75	.65	1.5 2.0	.38	.33 .38	.29	.34 .38	.30 .34	.27	.27 .31	.24
	•••		2.5 3.0	.46	.41 .45	.37 .40	.41 .43	.37	.34	.34	.31 .33
			4.0 5.0	.53 .55	.48 .51	.44	.47	.43 .45	.40	.38 .40	.36 .38
		1	0.6 0.8	.28	.22	.18	.26 .33	.21 .28	.17	.19	.16
			1.0 1.2	.38	.33	.29 .33	.36 .40	.32	.28	.30	.27 .30
.80	.70	.60	1.5 2.0	.46 .51	.41 .46	.36 .42	.43 .47	.38	.34	.35	.33
.00			2.5 3.0	.55 .58	.51 .54	.46 .50	.51 .54	.47 .50	.44	.44 .46	.42 .44
			4.0 5.0	.62 .65	.58	.55 .57	.57 .60	.54 .56	.51 .53	.50 .52	.48 .50
	(Calcula									
			0.6	.17 .21	.13 .17	.10	.14	.11	.09	.08	.07
			1.0 1.2	.24 .28	.20 .23	.17 .20	.21 .23	.17	.15	.14	.12
.75	.70		1.5 2.0	.31 .35	.26 .30	.23	.26 .29	.22	.19	.18	.16 .18
			2.5 3.0	.38 .41	.34 .37	.30	.32	.28	.25	.23 .25	.20
			4.0 5.0	.45	.41 .43	.37	.37 .39	.34	.31	.27 .29	.25
			0.6	.19	.14	.11	.16 .21	.12	1.10	.10	.08
			1.0 1.2	.27	.22 .25	.19	.23 .26	.19	.17	.16 .18	.14
.75	.70		1.5 2.0	.34	.29	.25	.29	.25	.22	.20	.18
			2.5 3.0	.36 .41 .44	.37 .40	.33	.35 .38	.32 .34	.28 .31	.26 .28	.24 .26
			4.0 5.0	.49 .51	.44	.40 .43	.41 .43	.37	.35	.31 .33	.29 .31
	! 		0.6 0.8	.18	.14	.11 .16	.15	.12	.10	.09 .12	.08
			1.0 1.2	.25	.21 .24	.19 .21	.21 .24	.18 .20	.16	.15 .16	.12
.75	.70		1.5	.31	.27	.24	.26 .29	.22	.20	.18	.16
			2.0 2.5 3.0	.38 .40	.31 .34 .37	.26 .31 .34	.31 .33	.29 .31	.25 .26 .28	.23 .24	.19 .21 .22
			4.0 5.0	.44 .46	.41 .43	.38 .40	.36 .38	.34 .35	.32 .33	.26 .28	.25 .26
			0.6 0.8	.16 .20	.12	.10	.13	1.10	.08	.08 .11	.07
]	1.0	.23	.10 .19	.17	.19 .22	.16	.14	.13	.11
.75	.65		1.5	.29	.25	.21	.24	.20	.19	.16	.14
		1	2.0 2.5	.32 .35 .38	.28 .31	.25 .28	.27 .29 .31	.26	.21	.18 .20 .22	.17
			3.0 4.0 5.0	.30 .41 .43	.34 .38 .39	.28 .31 .35 .37	.34 .36	.23 .26 .28 .31 .33	.21 .24 .26 .29 .31	.24 .26	.21
			0.6 0.8	18	.14	.11	.14	i .11	.09	.07	.17 .19 .21 .23 .24 .06 .09
			1.0 1.2	.22 .25 .29	.16 .21 .24	.15 .18 .21 .24	.18 .20 .23 .26	.14 .17 .19	.12 .14 .17	.10 .12 .14	.10 .12
.75	.70		1.5	.33	.28	.24	.26	.22	.19	.16	1 .14
			2.0 2.5	.36 .40 .43	.32 .35	.28 .32 .35	.29 .31	.25 .28 .30	.22 .25	.18 .20 .22	.18
			3.0 4.0 5.0	.47 .49	.38 .43 .45	.39 .42	.33 .37 .39	.34 .36	.27 .31 .33	.24 .26	.16 .18 .20 .23 .24
		L	3.0	.49	.40	.42		0	33	1 .40	.29

^{*} Semi-indirect and indirect units unsuitable under very dirty conditions or where ceiling and sidewalls are very dark colored.

TABLE No. 7 (Continued) A GUIDE TO THE SELECTION OF REFLECTING EQUIPMENT

LIGHTING U	NIT	RELATIVI CANDLES FO LAMP	OR A GIVENI	APPEAR- ANCE OF LIGHTED	DIRECT GLARE	RE- FLECTED GLARE	SHADOWS	MAIN- TENANCE	
		On Herizental	On Vertical	ROOM		GLARE			
	Semi-Indir	ect and	Indire	ct Ligh	ting Un	its			
15 Open Semi-Indirect Enameled Deflector Medium Density Glave Bottom Plate 90* to 180 *-54% 0* to 90*-18%		B — Very Fair	C Fair	A Excellent	A — Very Good	B+ Very Good	A — Very Good	C Fair	
Enclosed Luminous Bowl Indirect 90° to 180°—64% 0° to 90°—6%		C+ Very Fair	C Fair	A Excellent	A+ Excellent	A+ Excellent	A Excellent	B- Very Fair	
17 Open Indirect 90° to 180°—80% 0° to 90°—0%		C+ Very Fair	C Fair	B+ Very Good	A+ Excellent	A+ Excellent	A+ Excellent	C Fair	
Si	PECIAL UNI	TS FOR	COM	MERCIA	L INT	ERIORS	3		
Dense White Glass Reflector Frosted Lamp 90° to 180°—12% 0° to 90°—70%		Coeffi Unit No	icients of	Utilizati	on avera	ge about	the sam	rger sizes, tory than s in such her places e as for	
Round and Stalactite Globes 90° to 180°—38% 0° to 90°—42%	様の	and are are, how including efficient Coeff for Unit	usually t ever, apply certain distribution distributions of No. 8.	o be preficable in vistores whe	erred. St waiting roome little in t. n about 1	alactite a oms, banki nportance	nd spheric s and othe is attach	ppreciably are lamp. downward cal globes r interiors ed to the ues given	
20 Large Opaque Reflector Open Diffusing Bowl 90° to 180°—13% 0° to 90°—60%		The diffusing qualities in both the bowl and the large diameter reflector render the unit low in brightness with corresponding freedom from glare and sharp shadows. From the standpoint of dirt collection it retains the disadvantage of the open bowl. This spacing between units often desirable in large stores; it serves well in interiors where indirect lighting is preferred but impractical because of unfavorable ceiling finish. Coefficients of Utilization slightly higher than those given for Unit No. 8.							
21 Enclosing Unit Large Decorative Shade 90° to 180°—21% 0° to 90°—56%	A A	Paper, parchment, silk, or other material may often be effectively used as abades in connection with enclosed opal glass or prismatic units. Such shades only add an element of decoration, leading the decoration of the state of							
			28						

TABLE No. 7 (Continued) AND COEFFICIENT OF UTILIZATION

	E AVERAG		CEILING	VERY	LIGHT (70%)	FAIRL	Y LIGHT	(50%)	FAIRLY DA	RK(30%)
	N-AS FRA	INATION	WALLS	FAIRLY LIGHT (50%)	FAIRLY DARK (30%)	VERY DARK (10%)	FAIRLY LIGHT (50%)	FAIRLY DARK (30%)	VERY DARK (10%)	FAIRLY DARK (30%)	VERY DARK (10%)
Clean Condition	Average Condition	Dirty* Condition	ROOM INDEX		COEFFICIENTS OF UTILIZA						
.70	.60		0.6 0.8 1.0 1.2 1.5 2.0 2.5 3.0 4.0 5.0	.18 .22 .25 .28 .31 .34 .37 .39 .43	.15 .19 .22 .25 .27 .31 .34 .36 .40	.13 .17 .20 .22 .24 .28 .32 .34 .37 .40	.15 .19 .21 .24 .26 .28 .30 .32 .34	.12 .16 .18 .21 .22 .25 .28 .29 .32	.10 .14 .16 .19 .21 .24 .26 .28 .31	.10 .13 .15 .16 .17 .20 .22 .23 .25	.08 .11 .13 .15 .16 .19 .21 .22 .24
.75	.65		0.6 0.8 1.0 1.2 1.5 2.0 2.5 3.0 4.0	.14 .18 .20 .23 .26 .29 .31 .34 .37	.11 .14 .17 .20 .22 .26 .28 .31 .34	.10 .13 .15 .17 .19 .23 .26 .28 .32	.11 .14 .15 .18 .20 .22 .24 .25 .27	.09 .11 .13 .15 .17 .19 .21 .23 .26	.07 .10 .11 .13 .15 .17 .20 .21 .24	.06 .07 .09 .10 .11 .13 .14 .15 .17	.05 .06 .07 .09 .10 .12 .13 .14 .16
.70	.60		0.6 0.8 1.0 1.2 1.5 2.0 2.5 3.0 4.0 5.0	.15 .18 .22 .25 .27 .30 .34 .36 .40	.12 .15 .19 .22 .24 .27 .31 .33 .37	.10 .13 .16 .19 .21 .25 .28 .30 .34	.11 .13 .15 .18 .20 .22 .24 .26 .28 .30	.09 .11 .13 .15 .17 .19 .22 .24 .26	.07 .09 .11 .13 .15 .17 .20 .22 .24	.05 .07 .08 .09 .10 .11 .13 .14 .15	.04 .06 .07 .08 .09 .10 .12 .13 .14

SPECIAL UNITS FOR COMMERCIAL INTERIORS

22
Enclosed Semi-Indirect Inameled Deflector tched Glass Top
90° to 180°—48% 0° to 90°—10%

Fair

treet sixes. ctory than is in such her places

ne as for

ppreciably are lamp, lownward al globes r interiors ed to the

lues given

e diameter responding milpoint of nowl. This ig a wider serves well impractical

e given for

e effectively or prismatic tion, lending

ney are also the direction

in exclusive department

e Unit No. 8.



Units of this design have the same character of distribution as open types, with cover plate serving to exclude the dust and dirt from the lamp and reflecting surfaces of the unit. They have the decided advantage from the standpoint of cleaning accompanied, however, by considerable sacrifice in the total light output of the unit.

Coefficients of Utilization about 20% less than open top units of the same design.

Ornamental Lantern Art Glass Panels Diffusing Bottom Plate Internal Reflector

90° to 180°—8% 0° to 90°—40%



Lanterns of period designs to conform architecturally to interiors, are frequently used in public buildings, notably churches. Reflectors inside of the ornamental housing increase the lighting efficiency and if made of glass may be made to transmit varying amounts of light to illuminate the side panels. Subject to a variety of design in which distribution ranges from direct to totally indirect lighting.

Coefficients of Utilization for the type of unit illustrated will average about two-thirds of the values given for Unit No 2.

24 Multiple Light Clusters Small Frosted Lamps



Multi-light clusters are in favor as decorative elements in public buildings and other monumental interiors. When mounted high with a large number of low wattage lamps, the result is not unsatisfactory. However, when mounted low, the uncontrolled distribution of light and the glare from the unshielded sources, spoils what would otherwise be an artistic effect.

Lighting efficiency about 50% lower than same wattage in single lamp unit.

25 Large Main Unit all Decorative Lamps



The application of shades to multi-light units will, in many instances, raise the over-all effectiveness of the installation. On the other hand, the illuminating qualities of large decoration designs can be materially improved if the decorative lamp clusters are built around a central large-lamp unit either of the indirect type or of dense enclosing glassware. A combination of this sort offers a greater flexibility in control flighting effects, and, in most cases, will allow the illumination level to be raised by the use of a larger lamp in the main unit at any time if the occasion requires.

26 Deep Bowl Enameled Steel Clear Lamp 90° to 180°—0% 0° to 90°—65% 27 Prismatic Reflector Clear Lamp 90° to 180°—20% 0° to 90°—74% the efficiency. 28 Mirrored Glass Reflector Clear Lamp 90° to 180°—0% 0° to 90°—69% Concentrating Aluminum Reflector Dust-tight Housing 90° to 180°—0% 0° to 90°—57% 30 Vapor-proof Fitting Enameled Steel Reflector with Glass Enclosing Globe 90° to 180°—0% 0° to 90°—68% 31 Vapor-proof Fitting Prismatic Enclosing Globe 90° to 180°—28% 0° to 90°—57% 32 Angle Reflector Enameled Steel Output 74% Local Lighting Unit Substantial Reflector and Holder Cover Plate Output 45-55% 30

TABLE No. 7 (Continued) SPECIAL PURPOSE INDUSTRIAL UNITS

Generally inferior to RLM Dome with because of lower efficiency, sharp shadows, when used above shiny surfaces. Contr impression the light at any angle from a deep is generally less than that from the RLM S

Coefficients of Utilization average about those given for Unit No. 4.

Highly efficient reflector which, by mod can be made to give extensive, broad, or nation characteristics. With clear lamps it is sharp shadows and reflected glare, and these handicaps to a more general use of this type at usual mounting heights. White-bow positioned, help these factors, although the some extent, accurate control of light distr

Coefficients of Utilization about 15% given for Unit No. 9.

This unit like all deep-bowl types has a lat to protect against direct glare; it likewise has in that it does not protect against reflected avoid sharp shadows when used with clear I white-bowl lamps lowers the efficiency of the due to the light being bottled up in the general, are not recommended.

Coefficients of Utilization are about 10% given for Unit No. 4.

This unit has an aluminum reflector insi-housing. The reflector insert gives a concent and a consequent higher utilization factor interiors than would be the case with Unit efficiency, compared to Unit No. 7, limits the to locations where excessive dirt and smoke pu

Coefficients of Utilization average about those given for Unit No. 7.

Designed for locations where corrosive vagases, or explosive dusts are likely to be moisture laden atmospheres such as canning rooms, shower baths; also where gases and processes as oil refining, varnish making, spray and the like are present, units of this charamended. See also Unit No. 31.

Coefficients of Likition.

Coefficients of Utilization about 10 to for an open reflector.

Applications same as for Unit No. 30; the is usually not subject to corrosive action obtainable in a variety of metals and composition corrosion from acid vapors of chemical plants, also in grain elevators, spice, flour and feed mifacture of powdered sugar, cornstarch, sulp explosive dusts are present.

Coefficients of Utilization about the same a

Often used in craneways mounted below crament general overhead system in building up lateral surfaces. Used also to light individual processes demand special distribution or dir Special care must be taken in locating units to general, they should be placed high.

To supplement general lighting where op-high levels of illumination of the order of 50 to where general lighting of at least 10 foot-cand Local lamps are subject to much handling and glass cover plates are recommended to pre-surface from grease and dirt; construction must reflectors should not be supported by socket and 25 to 60-watt inside frosted lamps will generate the level of illumination required.

ontinued) DUSTRIAL UNITS

efficients of Utilization about 15% higher than thus for Unit No. 9.

ais unit like all deep-bowl types has a large shielding and tect against direct glare; it likewise has the disadvantage it it does not protect against reflected glare nor does is sharp shadows when used with clear lamps. The used bowl lamps lowers the efficiency of the unit about 2%, to the light being bottled up in the reflector, and, is all, are not recommended.

poefficients of Utilization are about 10% lower than thus for Unit No. 4.

his unit has an aluminum reflector inside of a dust tighting. The reflector insert gives a concentrated distribution a consequent higher utilization factor in high narros from than would be the case with Unit No. 3. Its lower iency, compared to Unit No. 7, limits the use of this unit ocations where excessive dirt and smoke prevail.

Coefficients of Utilization average about 20% lower than one given for Unit No. 7.

Designed for locations where corrosive vapor, inflammable see, or explosive dusts are likely to be encountered. In bisture laden atmospheres such as canning processes, engine oresses as oil refining, varnish making, spray lacquer painting of the like are present, units of this character are recomnded. See also Unit No. 31.

Coefficients of Utilization about 10 to 15% lower than an open reflector.

applications same as for Unit No. 30; the glass reflector unally not subject to corrosive action and holders are unable in a variety of metals and compositions to withstand from acid vapors of chemical plants. Recommended a grain elevators, spice, flour and feed mills, in the manufer of powdered sugar, cornstarch, sulphur, etc., where ive dusts are present.

efficients of Utilization about the same as for Unit No. 9.

a used in craneways mounted below cranerail to supple-neral overhead system in building up illumination on infaces. Used also to light individual machines where demand special distribution or direction of light, are must be taken in locating units to avoid glare; in hey should be placed high.

oplement general lighting where operations require of illumination of the order of 50 to 100 foot-candles aral lighting of at least 10 foot-candles is provided, as are subject to much handling and for this reason, plates are recommended to protect reflecting in grease and dirt; construction must be substantial; hould not be supported by socket shell.

watt inside frosted lamps will generally provide illumination required.

COLOR QUALITY-APPLICATION OF ARTIFICIAL DAYLIGHT

A few years ago discussions of artificial daylight were centered about units built on theoretical lines and of

y inferior to RLM Dome with white-bow has somewhat uncertain performance. Today, good practical units are being marketed and consequently the field for ower efficiency, sharp shadows, and reflected dissuch units has broadened beyond the original conception of limited applications in stores and textile industries. Above shiny surfaces. Contrary to a common the light at any angle from a deep bowlsted referred.

The duplication of natural daylight is confined largely to those industrial and commercial applications results than that from the RLM Standard Dome. Involving accurate color discrimination or color rendition in varying degree, depending upon the specific requiretents of Utilization average about 15% lower the ments. Even in this field difficulties arise because the colorist has been accustomed, perhaps through years of an for Unit No. 4.

exact reproductions of daylight for any given requirement with the attendant advantage of constancy and ade to give extensive, broad, or narrow light distribute acteristics. With clear lamps it is difficult to availability.

Although color quality is accurately specified by color temperature designations, equipments for reproducing aclows and reflected glare, and these factors are sensible standards and reflected glare, and these factors are sensible standards and reflected glare. Although color quality is accurately specified by color temperature designations, equipments for reproducing aclows and reflected glare, and these factors are sensible standards and sensible standards. White-bowl lamps, procedwhich provide a whiter light than the common types of general lighting equipment, but not so white as those deby these factors, although their use sacrifices is isted under (1) and (2).

Although color quality is accurately specified by color temperature designations, equipments for reproducing actors are sensible standards. Although color quality is accurately specified by color temperature designations, equipments for reproducing actors are sensible standards. Although color quality is accurately specified by color temperature designations, equipments for reproducing actors are sensible standards. Although color quality is accurately specified by color temperature designations, equipments for reproducing actors are sensible specified by color temperature designations, equipments for reproducing actors and these factors are sensible specified by color temperature designations, equipments for reproducing actors are sensible specified by color temperature designations, equipments for reproducing actors are sensible specified by color temperature designations, equipments for reproducing actors are sensible specified by color temperature designations, equipments for reproducing actors are sensible specified by color temperature designations, equipments for reproducing actors are sensible specified by color temperatu

34 Skylight Quality Special Color Filter

Clear Lamp



Equipments of this character employ accurately correcting filters by means of which it is possible to duplicate the color of outdoor daylight. Generally designed for localized lighting over counters in stores, for small areas or special operations in industrial plants where precision in color identification, grading, and other color inspection is required. Illumination of the order of 100 foot-candles is desirable for this sort of work.

Color factories, paint and dye mixing, art studios, chemical analysis, dental mechanics, surgery, textile and cigar sorting and grading are examples suggesting the application of skylight reproducing equipment.

As compared to unmodified artificial light, from 6 to 8 times the wattage is required for the same foot-candle values.

35**Sunlight Quality** Reflector and

Color Correcting Globe Clear Lamp



Enclosing globes of special crystal blue glass frosted on the inside modify the light from a lamp to approximate the color of direct sunlight at noon. Their applications are to some extent the same as skylight units, the actual choice depending on specific requirements; in general, noon sunlight equipment is used for less exacting color discrimination. For example, ink and dye mixing, and inspection may be done locally under skylight quality, and a general system of noon sunlight equipment may be installed in certain rooms or over small areas restricted to manufacturing operations requiring small areas restricted to manufacturing operations requiring clear color rendition—such, for example, as lithographing processes, color printing and the like.

As compared to unmodified artificial light, from 2 to 3 times the wattage is required for the same foot-candle values.

36 Ordinary Equipment

Blue Bulb Daylight Lamps



Lamps with blue bulbs, commercially known as Mazna "Daylight" lamps, emit a whiter light which is but a partial step toward daylight whiteness. In many instances of color rendition, their use gives sufficient color correction to be of considerable advantage over the warmer tones of unmodified light. For example, they are widely used in stores and show windows to improve the display of merchandise. Again the light blends well with natural daylight; in fact in many cases it is about the same color as the daylight which one gets indoors taking into account the prevalence of warm tones in window shades, walls and hangings; for this reason the use of daylight lamps in offices and many other places will be found to correct an unsatisfactory mixture of ordinary artificial light and inadequate daylight.

The next larger size of lamp will be required to produce


The next larger size of lamp will be required to produce approximately the foot-candle level as computed for a clear lamp of a given size. They are used in all common types of equipment.

37 Color Modifying Globe Clear Lamp



Enclosing globes with slight bluish ingredient do not appreciably modify the color quality of illumination for utilitarian purposes, but have a considerable field of application by virtue of their whiter appearance. Such equipment sorrect for the yellowish tone usually noticeable with ordinary opal glassware. These usually give far less color correction than Mazoa Daylight lamps. The units are very pleasing, appear white and clean, and are often more satisfactory than units of yellowish tone, particularly when supplementing natural daylight. The spectral quality of illumination is usually not far from that of a clear bulb Mazoa C lamp.

Coefficients of Utilization will be about 10% to 30% less than the values given for Unit No. 8.




Reflection Factors

The proportion of light reflected by walls and ceilings of various colors, that is, their Reflection Factors, has an important bearing on both the natural and the artificial lighting. The proportion reflected will depend somewhat upon the color of the incident light. The figures here given show what proportion of



of Colored Surfaces

the light of Mazda lamps these painted surfaces reflect. Reflection Factors are of special usefulness in determining the Coefficient of Utilization (ratio of light delivered at the work to total light of lamps) applicable to an interior. The Reflection Factor of any colored surface can be approximated by comparing it with these samples.



ROOM USE ONLY

