

THESIS

Concrete, Reinforced

THE UNIVERSITY OF MICHIGAN

1935

RECEIVED ON DATE

1935

Y

W. J. Lin

IN PARTIAL FULFILLMENT OF THE REQUIREMENTS
FOR THE DEGREE OF
C. E.

MICHIGAN STATE COLLEGE

EAST LANSING

MICHIGAN

1935

TREES

PREFACE

The object of this thesis is to provide a practical, simply-worded guide to construction in reinforced concrete, as distinct from the more theoretical treatment that is seen in many reinforced concrete design books. The theoretical side of the subject has not, however, been overlooked.

This thesis is largely concerned with the practical side of reinforced concrete - with what has been done and can be done with this compound material, and how to do it. The first chapter has an explanation of the advantages of reinforced concrete followed by a discussion as to how the steel and the concrete act together as a compound material. The terms and the formulae are explained in the two following chapters. In chapter V attention is called to a special treatment of the inclined shear stresses in fully reinforced beams which is given in Faber and Lowie's, Reinforced Concrete Design, Vol. I and II. The design of various members including columns and retaining walls are discussed in the chapters that follow. In the last chapter special attention is devoted to the cement, sand, stone, and the modern methods of mixing, proportioning, placing, and curing of concrete.

Every effort has been made to keep the explanations as simple as possible and highly technical language has been avoided. The diagrams have been prepared with the same object, and in fact simplicity has been the writer's aim throughout.

The writer is aware that no short and single treatment of reinforced concrete can cover the whole field in any complete way. In fact, this thesis is, only intended to serve the purpose of an introduction to the subject and is necessary for those who desire to specialise in this subject to follow it up with further study.

The writer wishes to acknowledge his indebtedness to Professor C. L. Allen who has read over the manuscript and who has supplied a few ideas.

Foochow, Fukien,

Mu Chi Lin

November, 1914

The principal reference books are listed here:

George A. Noel, Reinforced Concrete Construction, Vol. I & II

Oscar Faler and P. G. Bowie, Reinforced Concrete Design,

Vol. I - Theory and Vol. II - Practice (London)

Wile Authorless and Walter A. Clifford, Some notes on

Reinforced Concrete Design

Leonard Frank Maynard and Charles Edward Maynard, Design

of Concrete Structures

Harvard University, Engineering Bulletin, How to build safety

Concrete in Wall Structures Vol. XVI, No. 1,

January, 1932

Concrete in Structural Engineering, Vol. XI, No. 20

of Fall, October and November, 1918 (London)

The Clemson Agricultural College of South Carolina, Engineering

Bulletin, No. 1, How to build concrete in form and

Steel, June, 1931

George A. Noel and Harry D. Fulver, Concrete Practice

Herbert L. Jones and Albert Lehigh, Cassell's Reinforced

Concrete (London)

George A. Noel and M. C. Hurre, Reinforced Concrete and

Structures

Herbert L. Jones, English for Engineers and Architects (London)

Chinese Engineering Society's Magazine, Vol. 6, No. 1

March, 1930 (in Chinese)

Wheatfield Herring, Strength of Materials

Fred B. Seely, Resistance of Materials

James L. Boyd, Strength of Materials

F. L. Chao, Reinforced Concrete, 1935 (in Chinese)

1. **Introduction** 1

2. **Background** 2

3. Methodology

3.1 **Study Design** 3

The study was designed as a cross-sectional survey. The purpose was to determine the prevalence of the disease in the community. The study was conducted in a rural area of the country. The sample was selected using a simple random sampling method. The data was collected using a structured questionnaire. The questionnaire was administered by trained interviewers. The data was then analyzed using statistical software.

3.2 Data Collection

3.2.1 **Questionnaire** 4

The questionnaire was designed to collect information on the demographic characteristics of the study population, the prevalence of the disease, and the risk factors for the disease. The questionnaire was administered by trained interviewers. The data was then analyzed using statistical software.

3.3 Statistical Analysis

3.3.1 **Descriptive Statistics** 5

The descriptive statistics were used to describe the demographic characteristics of the study population, the prevalence of the disease, and the risk factors for the disease. The data was then analyzed using statistical software.

3.3.2 Inferential Statistics

3.3.2.1 **Chi-Square Test** 6

The Chi-Square test was used to determine the association between the prevalence of the disease and the risk factors for the disease. The data was then analyzed using statistical software.

3.3.2.2 Logistic Regression

3.3.2.2.1 **Model Building** 7

The logistic regression model was used to determine the risk factors for the disease. The data was then analyzed using statistical software.

3.3.2.2.2 Model Evaluation

3.3.2.2.2.1 **Goodness of Fit** 8

The goodness of fit was used to evaluate the model. The data was then analyzed using statistical software.

QUESTION 1

1. The following table shows the number of people who attended the 2010 World Cup in South Africa, by country and by match. The table is divided into two parts: the first part shows the number of people who attended the matches in the first round, and the second part shows the number of people who attended the matches in the second round. The table is divided into two parts: the first part shows the number of people who attended the matches in the first round, and the second part shows the number of people who attended the matches in the second round.

QUESTION 2

2. The following table shows the number of people who attended the 2010 World Cup in South Africa, by country and by match. The table is divided into two parts: the first part shows the number of people who attended the matches in the first round, and the second part shows the number of people who attended the matches in the second round. The table is divided into two parts: the first part shows the number of people who attended the matches in the first round, and the second part shows the number of people who attended the matches in the second round.

3. The following table shows the number of people who attended the 2010 World Cup in South Africa, by country and by match. The table is divided into two parts: the first part shows the number of people who attended the matches in the first round, and the second part shows the number of people who attended the matches in the second round. The table is divided into two parts: the first part shows the number of people who attended the matches in the first round, and the second part shows the number of people who attended the matches in the second round.

QUESTION 3

4. The following table shows the number of people who attended the 2010 World Cup in South Africa, by country and by match. The table is divided into two parts: the first part shows the number of people who attended the matches in the first round, and the second part shows the number of people who attended the matches in the second round. The table is divided into two parts: the first part shows the number of people who attended the matches in the first round, and the second part shows the number of people who attended the matches in the second round.

An Elementary Treatise on Reinforced Concrete

Chapter I

General Principles

Introduction -- During the past several decades concrete has taken its place as one of the most useful and important structural materials in America and Europe. It has been much more so in China up to the present. Owing to the comparative ease with which it can be worked into any desired shape its structural uses are almost unlimited; so wherever Portland cement and suitable aggregates can be obtained it has, for many constructions, displaced other materials. This apparent ease with which concrete may be prepared has led to its being employed by any one who feels that this material is suited to his particular purpose. In many instances, proper knowledge of the substance and skill in its manufacture are lacking, so that the resultant concrete is little more than a bulky, heavy material, lacking the strength and other properties which it should have obtained, and often failing to fulfill the purpose for which it was intended.

To the individuals who obtain such results, concrete is merely a shoveler-together mass of cement, sand, stone, and water, which in a short time attains a varying degree of hardness and an uncertain strength. To the engineer who is more or less familiar with the many elements of variables entering into the

manufacture, the process of making concrete is not as simple as it appears quite so clear and simple. Experience shows that a quality concrete cannot be obtained by merely mixing together the cement, sand, stone and water. The quality and quantity of cement, aggregates, of water, and the process of mixing, placing and curing are all involved in the production of good concrete. Results absolutely depend upon all of these variables. It is, therefore, of great importance that the problem of curing and controlling these factors should be understood in order that a concrete of the desired quality may be obtained.

Plain and Reinforced Concrete -- Concrete is artificial stone made by cementing together into a solid mass a mixture of inert material such as sand and broken stone, gravel or other aggregate. The cementing material almost universally used for reinforced concrete work is Portland cement, the only exception of note being the siliceous cements that have been put on the market. Both these cements are extremely fine powders, made from definite but different proportions of argillaceous and calcareous materials, which, when wet with the proper amount of water, become chemically active and harden.

The usual proportions of the mix of the concrete are 1:2:4, which means one part of cement, 2 parts of sand, and four parts of broken stone or gravel, all measured by volume; these proportions may not be adhered to in all cases, but are generally used in concrete work for ordinary structural work. Such a concrete will set and fairly rapidly harden with age, and produce a mass resembling stone in many of its properties.

It is found experimentally that such concrete under good average conditions, will stand on each square inch a compression of 1,600 lb., and a tension of 100 lb., without fracture at the age of four weeks. At the age of three months and over, average values for these strengths would be 2,400 lb./in.² and 320 lb./in.² respectively.⁺

Let us consider a plain concrete beam, lying between two supports and loaded in the center. It is obvious by considering the curved shape it takes up that the ends of the beam remain perpendicular to the axis of the curved or deflected beam. Obviously the beam has its upper portion compressed and its lower portion extended (see Fig. 2).

If we adopt the lower figures as stated above, the beam will therefore fail when the lower face acquires a tension stress of 100 lb./in.² and because the upper face will also then only be stressed to 100 lb./in.², the greater compressive strength of the concrete is not brought into play, and the beam would therefore be very heavy and wasteful, as we shall show, unless we insert tensile steel reinforcement in the form of steel bars or rods which are to be embedded in the tension side of the beam so that it is now strong enough to bring the full strength of the compression in the top of the beam into play.

The above refers to properties of concrete which underlies the necessity of reinforcing it, is thus the fact that its

⁺ The notation lb./in.² means pounds per square inch, indicating the intensity of stress.

tensile strength is only a fraction (approximately one-eighth) of its compressive strength and also that its tensile strength, besides being low, is also very unreliable, since it may be entirely controlled as the result of a bad mix, or vibration, or from the manner of placement, either in casting and curing or in a rapid fall of the concrete. For this reason, most types of concrete can be used only when such conditions are approximated. The stresses are produced by them are often even than if limited by called the positive reinforcement. This unreliability of concrete is remedied by the inclusion of very serious consideration which proves in its use, if not reinforced, in any form of beam or girder, or in the design of its application to walls, piers and foundations of structures or solid or in retaining walls.

Now the question arises as to how much steel is needed in the best general case? The point of reinforcement at which the tension in steel just balances the compression in the concrete is called the economic lever arm. This percentage can be shown to be within the range of say from .50 % up to .68 % or perhaps even up to .77 % depending upon the values of f_c , f_s and n . See the table on page 16. (Note that for all the examples in this thesis we take $p = .675$ % throughout). With usual values of the stresses, that is $f_c = 600 \text{ lb./in.}^2$, $f_s = 16,000 \text{ lb./in.}^2$, $n = 15$ this economic amount of steel is .675 percent. of the area of concrete. That is to say, if the area of the section of the concrete beam is 100 square in., measured down to the center of the steel reinforcing bars, then the area of the section of the steel rods need only be .675 sq. in., or we will see that the

square inch of steel is sufficient to resist 100 lb. sq. in. of the section of concrete.

Working Stresses in Concrete and Steel -- In the previous paragraph, it has been stated that at the age of four months the concrete should stand at least 2,000 lb./in.² in compression. This is the ultimate strength of the concrete, that is the pressure in lb. required to cause failure of the material has been given for four months. As we will have a safe working stress in the concrete in compression the value 600 lb./in.² This is factor the difference between the working stress and the ultimate strength, and this difference is the factor of safety which provides the margin of safety in the case of failure. "Factor of safety" for the factor of safety in the case would be four.

The ultimate strength of ordinary mild steel in tension is 60,000 lb./in.² and the safe working stress is 16,000 lb./in.² (See first note). This gives a factor of safety of 4. If previously mentioned, the steel rods are introduced in the concrete to provide the necessary resistance or tension, as concrete is deficient in this resistance. It will be seen that, therefore, this 16,000 lb./in.² for steel in tension is a very high figure compared with the values of 600 lb./in.² given for the working stress on concrete in compression and this explains why one

1. In many cases, the ultimate strength of steel is given as 60,000 lb./in. but at about 100,000 lb./in. (10,000 lb./in.²) it is stretched to failure. In such cases, the factor of safety is 3 or 4, and the safe working stress is 16,000 lb./in.² or other a lower stress such as 8,000 lb./in.²

proportion of steel required is as follows.

The allowable working stresses for concrete is 60 lb./in.² + and for mild steel is 17,000 lb./in.²

A reinforced concrete structure designed for a factor of safety of 4 generally allows loading up to about twice the designed load without any serious trouble, and it will commonly carry under collapse between two or three times the designed load.

Adhesion between Concrete and Steel -- the adhesion, or grip, between the concrete and the steel rods is obviously of great importance, because the two materials must act together and in case the adhesion fails then the steel rods would slip through the concrete and the necessary mutual resistance or bond could not then be developed to enable a full tension pull in these bars. The action is that the concrete adheres or sticks to the steel reinforcement and holds this in position while its tension resistance is being called into play, and this bond stress between the two materials must be high enough to withstand the tendency of the steel to slide which will be present when the steel is being either stretched by tension or crushed by compression for compressive reinforcement.

In design the allowable stressing for clearing adhesion is 100 lb./in.² of the surface of the steel in contact with the concrete, provided the ends of the rods are hooked¹ or otherwise

is used when the stressing of the steel is subject to considerable variation or reversal, and also to insure watertightness in the wall of a circular water tank. See Geely, Resistance of Materials, pp. 10

+ Fisher & Bowie, Reinforced Concrete Design, Vol. I, pp. 81
1. Fisher & Bowie, Reinforced Concrete Design, Vol. I, pp. 77

properly anchored. The area of the steel which is in contact will in turn depend on the diameter and length of the rod. A simple rule is that a rod must have a gripping length of at least forty times its diameter, when the end is hooked as shown in the sketch before the resistance of 16,000 lb./in.² can be fully




Fig. 1

developed in the steel without the rod slipping through the concrete.¹ This can be shown by simple calculation from the following relation:

$$x = \frac{f_s \cdot d}{4u} \quad \text{for round or square rods}$$

where x = required length of embedment, including hook

f_s = allowable unit tensile stress in the steel

d = diameter of bar

u = allowable unit bond stress between the concrete and the steel

¹ Letherland & Clifford, Reinforced Concrete Design, pp. 133
 Tool, Reinforced Concrete Construction, Vol. 1, pp. 80

The Joint Committee has recommended a factor of safety of .34 of the ultimate compressive strength for plain bars, that is 100 lb./in.² and .65 for bars of plain wire that is 100 lb./in.²

For the ends of the rods are not properly lapped but say anchored by a clamp, bend or other means then the grip length should be at least sixty-seven times the diameter of the rod.

As the adhesion of the steel rods between the concrete is so important it is necessary to see that the surface of the steel reinforcement is not covered with mud or dirt or loose scales of rust. The rough surface produced by slight rusting is not detrimental but gives a better adhesion than a perfectly smooth surface, but it is absolute necessary to brush off any loose scales with a wire brush.

The necessity for this adhesion can also be realized from the fact that many patent deformed bars for reinforcement are on the market which have projecting ribs on them.

The Elasticity of Steel and Concrete -- Before proceeding to deal further with the combination of steel and concrete it is advisable to give some explanation ~~and~~ about the elasticity of the materials.

Elasticity may be defined as the quality which is possessed by a material when it is stretched, but it is rather its ability to return to its original size after it has been stretched by the application of a load or force. This ability to regain the original shape after the removal of the forces which are stretching it is called elasticity, and a material is said to be elastic when it does so. In its original shape after the removal of the force it is

said to have a "tensile strength", or, in other words, it has become "tensile" in the direction of stress.

When in a tensile stress, a material is stretched, and as it elongates, the cross-section of the material decreases accordingly so that the volume remains, in the limit, constant, even as the material is stretched. This is called the law of conservation of volume, and is given by [1]

$$\epsilon = \frac{\Delta L}{L}$$
$$E = \frac{\text{stress}}{\text{strain}} = \frac{F}{\frac{\Delta L}{L}} \quad (1)$$

where

- ϵ = elongation (strain)
- F = stress (force) in pounds per square inch
- L = length of the bar
- E = a constant depending on the material (and called the modulus of elasticity or Young's Modulus).

With ordinary mild steel, E only varies a constant up to a stress of about 32,000 lb./in.² (This is called its elastic limit.) After this, the steel yields visibly, although before this the elongation was so small as to be invisible except with very delicate measuring apparatus. The value of E can be found by measuring the value of the stress and the length of the tested bar and the corresponding value of the elongation within the elastic limit and substituting in the formula (1). The value of

[1] See, "Strength of Materials", pp. 10-15
[2] "Strength of Materials", pp. 3

For mild steel, $\sigma_c = 10,000 \text{ lb./in.}^2$

If a specimen of concrete subjected to tension, is also elongated and the elongation is extremely small, but just perceptible with delicate apparatus.

For concrete σ_c practically the same as for mild steel is only $2,000,000 \text{ lb./in.}^2$, or the stress of steel is the same as a concrete stress of 1000 times that of steel. For the same elongation of steel, you will have to have 1000 times as much. If, however, the elongation of concrete is 1/1000 that of steel, then the stress in steel, and conversely the elongation of concrete, will be the same as the stress in the steel will be 1000 times the elongation of the concrete.

For example, if steel is to be stretched 0.001 inch per inch, and $\sigma_c = 10,000 \text{ lb./in.}^2$ is to be used, then for the same elongation the concrete stress will be

$$\frac{10,000}{1000} = 1,000 \text{ lb./in.}^2$$

As explained previously, we want the concrete stress to be less than it is able to tolerate, $2,000,000 \text{ lb./in.}^2$. Even if the steel stress is $10,000 \text{ lb./in.}^2$, the concrete will certainly have cracks in tension, and is therefore incapable of resisting tensile stresses. Hence the steel has to be designed to carry the whole tension, receiving no assistance from the concrete.¹

¹ For a full discussion of concrete in T.P., Vol. I, Ch. 15.
In point of volume, the concrete is stronger than steel.

Chapter II

Neutral Axis

The Neutral Axis of a homogeneous beam -- Let us take a wooden beam slung between two supports at its ends and put on it sufficient weight at the center to cause it to break. Upon examination of the broken wooden beam it will be seen that the bottom fibres have been torn apart by stretching or tension and the top fibres are crushed by compression.

Now, it will be obvious that if the top portion of the beam is being crushed or shortened by compression and the bottom portion is being stretched or torn by tension then there must be some line or point at which these stresses change sign, and at this line there can not be any stress because at it there is no tendency either to shorten or stretch. This line, not being subject to compression or tension, is known as the "neutral axis", while the layer of the beam in which it is situated is known as the "neutral plane".




Fig. 2

The position of the neutral axis is dependent on the change from compression to tension stress and the change in the stress from the one kind to the other is gradual throughout the depth of the beam. The greatest compression will be in the top fibres, and this gradually decreases until the neutral layer is reached, where it disappears entirely. The greatest tension is in the bottom fibres and this diminishes upwards until the neutral layer is reached, where again this stress becomes zero, as shown by the shaded portion in Fig. 3.




Fig. 3

The importance of a knowledge of the position of the neutral layer will be appreciated when it is considered that it may be necessary to cut a hole through the beam and near the middle of its length and that by making the hole where the neutral axis occurs the beam will not be weakened to any appreciable extent, because the shear stress although a maximum there is also low, whereas if the cutting away is done at the top or bottom of the beam, the section will be seriously reduced where the greatest resistance is necessary.

The Neutral Axis of Reinforced Concrete Beams -- For

beams of any given material which is equally strong in tension and in compression, the neutral axis passes through the center of gravity of the cross-section.¹ In the case of a reinforced concrete beam, the position of the neutral axis will not generally be at the center of its depth because the two materials that are used conjointly have different strengths and different elasticity values. As we stated previously the maximum working stress of the concrete should be 600 lb./in.², and if the steel is at the same distance from the neutral axis as is the top face of the concrete then the maximum stress that could be developed in it would be only

600×15 which only gives a value of 9,000 lbs. The steel can, however, be safely stressed to 15,000 lb./in.², and consequently the neutral axis should occur nearer the top of the beam, so that the stress on the steel is increased without overstressing the concrete.

We can show that the position of the neutral axis in a reinforced concrete beam depends on the depth of the beam, the safe stresses on the concrete and steel, the proportion of steel to concrete, and the ratio of the elasticity of the two materials. The exact position of the neutral axis can be easily calculated by means of the formula given below:




Fig. 4

¹ Seeley, Resistance of Materials, p. 27

$$k = \sqrt{c_1 n + \left(\frac{1}{15}\right)^2} - \frac{1}{15} n$$

$$\text{Let } \frac{1}{15} = \frac{A_0}{15} \quad \text{and } n = \frac{1}{15}$$

$$k = \sqrt{\frac{c_1 n}{15} + \frac{\left(\frac{1}{15}\right)^2}{\left(\frac{1}{15}\right)^2}} - \frac{A_0}{15}$$

$$15k = \sqrt{\frac{c_1 n}{b} + \frac{\left(\frac{1}{15}\right)^2}{(b)^2}} - \frac{A_0 n}{b}$$

A graphical method can be used to locate the position of the neutral axis for reinforced concrete beams as follows:

Let the assumed shortening which δ for the top concrete face be proportional to 600 on any scale. Now since the steel stretches only $\frac{1}{15}$ times as much as the concrete for the same stress, the extension of the steel will be proportional to $\frac{1}{15}$ of 600 = 1,000 on the same scale as that which gave 600 as the shortening of the extreme concrete fibres. Now draw a vertical line to represent the effective depth⁺ of the beam to any scale and then to the above scale set along 600 units to one side of the vertical line at its top end to represent the shortening of the concrete and also set along 1,000 units to the other side at the bottom of the vertical line to represent the extension of the steel and then the ellipse line joining these two lines will represent the proportional extension or shortening at different distances from the beam, and where it cuts the vertical line

⁺ Effective depth is the distance from the top of the beam to the center of the reinforcement. The concrete below this steel is provided for bonding to the rest of the beam and is in proportion to the steel against rusting or fire only; the steel acts as to the resisting power of the beam after supporting a load.

gives the position of the neutral axis. Thus we can show that the depth of the neutral axis from the compression face equal .87 d. That is the neutral axis is approximately one-third from the compression face of the beam, as shown in Fig. 5.




Fig. 5

TABLE I

Note: Computed ρ for Rectangular Beams

n	f_s	f_c	k	j	ρ in %	R
12	16,000	550	0.292	0.909	.50	72.2
12	16,000	600	0.310	0.907	.52	82.2
12	16,000	650	0.328	0.901	.67	95.0
15	16,000	550	0.309	0.897	.58	82.9
15	16,000	600	0.360	0.890	.68	95.0
15	16,000	650	0.370	0.874	.77	107.7

$$R = W_u \cdot d^2$$

This table is taken from Table, Reinforced Concrete
Construction, pp. 66-67

Note that for all the calculations in this thesis
we will take $\rho = .075$ %, $k = .30$ and $j = .90$ and $R = 14$

Chapter III

Explanation of Terms and Formulas

Before proceeding to deal with the design of reinforced concrete beams, it is necessary here to explain the terms and the formulas we shall use in the design of the beam. The reasoning upon which the various formulas is based should be understood if these formulas are to be used intelligently. Our present intention, therefore, is first to deal with the fundamental principles that must be understood by any one desirous of successfully studying the constructional design of buildings and then, in the succeeding chapter, to show how these principles are applied in reinforced concrete construction.

Principle of Moments -- The "bending moment" at a given point in a beam means the tendency to cause bending and this is a misdirect term, in-as-much as it does not mean only the actual amount of a force in pounds, or tons, but it measures the actual ability of that force to cause stress at any point by bending around that point and its value is dependent on the amounts of all the forces on one side of this point, their directions as well as upon their disposition in relation to that point in the beam where the amount of the bending moment is desired. Thus, "taking moments round a certain point" really means "taking values of the bending moment caused at that point".

Now, the "principle of moments"¹ is that when several

¹ Ferriss, Strength of Materials, p. 10-8.

forces acting in the same plane on a body are in equilibrium, then the moment tendency of all these forces to rotate the body to cause rotation of the body in one direction with respect to one point in the plane is exactly equal to the moment tendency of all the other forces to rotate the body in the opposite direction. In other words, it is that the algebraic sum of the moments of all the forces about a point in the plane of forces is equal to zero. This is in equilibrium.

Reaction -- A reaction is a supporting force or reaction which is the opposite of a lifting action or force. It is said to be that, when any force or forces are introduced, and if equilibrium is still maintained, then there must be a reaction or reactions which are equal to the initial action, but opposite in tendency.

The reaction at the end of a beam can be defined as the positive resistance at the supports created through the strength of the material there, in the process of resisting bending. The reactions at the supports will depend on the amount of the loads and their distribution along the beam.


In the case of a cantilever, because there is only one support, the whole of the reaction must be supplied by this support and at the same time there is also a tendency for the cantilever to overturn by rotation due to the weight of the building, that is there is a tendency to lift up the superstructure above the tilting-down position or else if there is no superstructure

times the weight of the beam, and the upward force at the center is the downward force of the beam. (2) The upward force will be the weight of the beam, and the downward force will be the weight of the beam.

Let us consider a beam of length l and weight W supported at the ends by two supports. The beam is in equilibrium. The forces acting on the beam are the weight W acting downwards at the center and the upward forces R_1 and R_2 acting at the ends. The beam is in equilibrium, so the sum of the forces must be zero. The weight W is equal to the sum of the upward forces R_1 and R_2 . The beam is also in equilibrium, so the sum of the moments must be zero. The weight W acts at a distance of $l/2$ from each end. The upward forces R_1 and R_2 act at a distance of l from each other. The sum of the moments is zero.

Let us consider a beam of length l and weight W supported at the ends by two supports. The beam is in equilibrium. The forces acting on the beam are the weight W acting downwards at the center and the upward forces R_1 and R_2 acting at the ends. The beam is in equilibrium, so the sum of the forces must be zero. The weight W is equal to the sum of the upward forces R_1 and R_2 . The beam is also in equilibrium, so the sum of the moments must be zero. The weight W acts at a distance of $l/2$ from each end. The upward forces R_1 and R_2 act at a distance of l from each other. The sum of the moments is zero.


Let us consider a beam carrying a load of W tons at the center of its length as shown in Fig. 2. The beam will be in equilibrium if the upward forces R_1 and R_2 are equal to the weight W of the load. The beam is in equilibrium, so the sum of the forces must be zero. The weight W is equal to the sum of the upward forces R_1 and R_2 . The beam is also in equilibrium, so the sum of the moments must be zero. The weight W acts at a distance of $l/2$ from each end. The upward forces R_1 and R_2 act at a distance of l from each other. The sum of the moments is zero.

[illegible][illegible][illegible][illegible]

100

1

In the case of a uniformly distributed load, the load is uniformly distributed over the entire length of the beam, and the resultant of the load is a single point load acting at the center of the beam. The load is represented by a horizontal line with arrows pointing downwards, and the resultant is represented by a single point load W acting at the center of the beam. The load is shown in Fig. 7, and the resultant is shown in Fig. 8.



Let the beam be of length L , and the load be uniformly distributed over the entire length of the beam. The load is represented by a horizontal line with arrows pointing downwards, and the resultant is a single point load W acting at the center of the beam.

$$M = \frac{wL^2}{2} - \frac{wL^2}{6} = \frac{wL^2}{3}$$

$$= \frac{WL^2}{6}$$

The beam is shown in Fig. 8, and the load is uniformly distributed over the entire length of the beam. The load is represented by a horizontal line with arrows pointing downwards, and the resultant is a single point load W acting at the center of the beam.

Since the beam is simply supported at both ends, the reaction forces at the ends are equal to the load. The load is represented by a horizontal line with arrows pointing downwards, and the resultant is a single point load W acting at the center of the beam. The beam is shown in Fig. 9, and the load is uniformly distributed over the entire length of the beam.




Fig. 10

Consider a small element of length dx at a distance x from the fixed end. The forces acting on this element are the weight $w dx$ acting downwards at the center of the element, the shear force V acting upwards at the left face, and the shear force $V + dV$ acting downwards at the right face. The equilibrium of the element in the vertical direction gives the equation $V - (V + dV) - w dx = 0$, which simplifies to $-dV = w dx$. Integrating this equation from $x = 0$ to $x = L$, we get $V = -wL$ at $x = L$. The shear force is zero at $x = 0$. The shear force diagram is a straight line from 0 at $x = 0$ to $-wL$ at $x = L$. The bending moment M at a distance x from the fixed end is given by the equation $M = -wx^2/2$. The bending moment diagram is a parabola starting from 0 at $x = 0$ and reaching a maximum value of $-wL^2/2$ at $x = L$.

$$M = -wx^2/2$$

$$M = -wL^2/2$$




Fig. 11





Fig. 12

[illegible]

pressure at the ends and tension in the center).

The stress distribution is shown in diagram 13, and it is the same as that in Fig. 12, except that the point of reflection is at the center of the beam. The degree of the concentration of the stress at the ends is proportional to the square of the length of the beam, but the stress in the center is only a fraction of that at the ends. This is shown in the diagram as $\frac{1}{4}$ of the stress at the ends, and the point of reflection is indicated by a dot. It will be recalled that this degree of stress is of the same order of magnitude as that in the case of the cantilever beam. For the cantilever beam, the concrete beam to be placed near the tension face of the beam, and the reinforcement to be placed on the upper surface between the points A and B, while they are required on the lower surface between the two points marked C. It will be noted that this arrangement, the rods are to be fastened at the point of reflection.

The fixing of the ends of the beam is a very important factor because it has the effect of relieving its ends, and therefore this method of fixing the ends of a beam is adopted in practice whenever possible for economy in design.

Now with Only One End Fixed -- It is not always possible to fix both ends of a beam in practice, but it may be possible to fix one end while the other is only freely supported, and in this case the condition will be as shown in Fig. 14. The section of the beam in this instance tends to bend the lower part, the shape is shown in exaggerated form in Fig. 14, the provision being made for pressure on the upper surface, owing to

to the part near the left end acting as a cantilever so that the maximum deflection is at the right end (Fig. 14). The point of




Fig. 14

inflection or position at which the distribution changes is situated at 0.237 L , or, for practical purposes, say, one-quarter of the span from the fixed end. The reinforcement in this type of reinforced concrete beam will require to be placed in the upper surface between the points A and B, and in the lower surface between the points B and C, with two bars in the reinforcement at the points close to each on either side of the point of inflection.

Continuous Beams -- The case of a continuous beam is one of some complexity and is fully dealt with in many text-books in Reinforced Concrete Design. The reader can turn to the excellent books on reinforced concrete if he wishes to pursue the study of the subject further. Here it is only necessary to refer to the elementary case.

In reinforced concrete floors it is a frequent occurrence to use beams which are continuous over several spans, the intermediate supports consisting of reinforced concrete columns, and in this case the length of beam between any two columns can

be considered as pinned at the end of the span where the load is applied. In the case of the end span this will generally be taken as supported at the exterior wall where it is resting on a wall and the end supported on the interior column will be considered as pinned. The curve of a beam which is continuous over several spans is shown in Fig. 15, where the bending is indicated.




Fig. 15

It will be seen that the stress is alternately compression and tension in both top and bottom surfaces owing to the cantilever action on each side of the column support.

In some cases, when concrete beams are used in conjunction with brickwork, a beam is designed as continuous, running across one or more brick piers, and when this is the case it is essential that the brick piers be built right up to the finished level before the formwork for the beam is fixed, or the beam would otherwise be the subject of the formwork and props remaining to the building up of the piers will result in a tendency for the beam to deflect or sag in one large curve and cause tension stress in the whole of the beam's under surface,

and so perhaps failure too. Although the lean may not get so loaded because the design is lean, still the position for compression there at the joints where the piers occur.

In addition, the span of the lean when in the erection will be the distance between the piers when they are erected complete, and the addition of support at the pier positions while the concrete is green means that the lean is called upon to carry itself (and any applied load) across a span longer than provided for in the design.

It should be noticed that the strutting is continuous. Leans are greatly changed even by slight lateral displacement of interior columns relative to the outer columns or vice versa.

Chapter IV

Reinforced Concrete Beams

It was stated previously that the great value in the design of reinforced concrete is to find the places where tension may occur so that we may strengthen **these** places by steel rods so disposed as to be capable of resisting such tension.

Simply-Supported Beam -- The first step in the designing of a simply supported reinforced concrete beam is to plan its moment of resistance at all points in such a way so that for each of its sections its value there shall equal the bending moment that can occur at that section.

The bending moment represents the ability of the external forces to destroy the beam by tension or by compression, the former taking place on the lower part of the beam and the latter on the upper, in the case of simply supported beam.

The compressional and the tensional resistances of a beam must be equal to one another, and these are acting in opposite directions and are parallel, forming a "couple"⁺ and the value of the moment of resistance of the beam section is the amount of one of these resisting forces multiplied by its distance from the other.

The resistance to compression is supplied by the concrete above the neutral axis, while the resistance to tension

⁺ Two equal parallel forces which are opposite in sense and are not collinear are called a couple. The moment of a couple about any point in the plane of the couple (or any line perpendicular to the plane of the couple) is defined as the algebraic sum of the moments of the forces of the couple about the point (or axis).

is supplied by the steel from the bottom of the beam; the torsional resistance of the concrete below the neutral axis is large enough to fix concrete shear lag at one end only. Now if the beam length is l , the area of concrete fixed is simply the area above the neutral axis, $C = \frac{1}{2} b h^2$ (see page 15 of 2-18). The stress on this concrete at the top of the neutral axis is $60,000 \text{ lb./in.}^2$ at the top fiber, so its average value is therefore $60,000 \text{ lb./in.}^2$. Hence the total compressive force C is,

$$\begin{aligned} C &= \text{area} \times \text{stress} \\ &= .807 \times 12 \times \frac{60,000}{2} \\ &= 109,116 \text{ lbs.} \end{aligned}$$

and this amount also represent the total tension in the steel.

Now if we write the area of steel as a percentage of the area of concrete, we have

$$A = \text{area of steel} = \frac{pA_c}{100}$$

where p is its percentage.

Clearly the total force on the steel is

$$\begin{aligned} T &= \text{area} \times \text{stress} \\ &= \frac{pA_c}{100} \times 16,000 \\ &= 160 \text{ lbs} \end{aligned}$$

Now since $C = T$

therefore $109,116 = 160 \text{ lbs}$

and "160" came in out from both sides,

therefore $109 = 160$

and so $p = 0.675$

This is the proof for the balanced percentage given in Chapter I. With no other percentage are the stresses of 18,000 in the steel and 600 in the concrete simultaneously reached.¹

Now as shown in Fig. 17, the compressive force C clearly acts at the center of gravity of the top triangle which represents the stress in the concrete, that is one-third the dis-




Fig. 17

tance down from the face.²

$$\text{that is at } \frac{0.36d}{3} = .12d$$

from the top, or at a distance

$$d - .12d = .88d$$

from the center of the tension steel bars.

Now the moment of resistance of a beam is the product of either of the forces (tension or compression) and the distance between them. Denoting this by R (moment of resistance)

1 Faber & Wylie, Reinforced Concrete Design, Vol. I, pp. 31

Urquhart & O'Rourke, Design of Concrete Structures, pp. 64

2 Urquhart & O'Rourke, Design of Concrete Structures, pp. 63

Faber & Wylie, Reinforced Concrete Design, Vol. I, pp. 34-36

We have

$$\begin{aligned} R &= \text{force} \times \text{distance} \\ &= 132.17 \times .076 \\ &= 95.15^2 \text{ in.-lb.} \end{aligned}$$

This is a very important result, as we shall see in what follows.

As an example, calculate the moment of resistance of a reinforced concrete beam which has a width of 14 in., and an effective depth of 24 in., if the beam is of 18 foot span and simply supported at its ends.

Then from the formula the moment of resistance is

$$\begin{aligned} R &= 95.15 d^2 \\ &= 95 \times 14 \times 24 \times 24 \\ &= 766,080 \text{ in.-lb.} \end{aligned}$$

This formula was based on a percentage of steel of 0.675, so that the area of steel rods required would be

$$\begin{aligned} A &= \frac{.675}{100} \times 14 \times 24 \\ &= 2.27 \text{ sq. in.} \end{aligned}$$

The area of a $\frac{3}{4}$ in. square rod is .563 sq. in., so that 4 - $\frac{3}{4}$ in. sq. rods give 2.25 sq. in. which is near enough for most practical purpose.

We now need to consider how this calculation helps us to tell what is safe load that the beam can carry. This is done by calculating the bending moment caused in the beam by that loading and provided this bending moment does not exceed the moment of resistance just calculated, then the beam would be safe under those loading conditions.

The total cross-section of the above beam is 14 x 26 (assume 2 in. for covering the steel rods), so it will weigh 380 lb./ft.⁺, or the total dead load for the beam is 6,940 lb. which is evenly distributed.

So the bending moment at the center of the beam due to its own weight or dead load is

$$M' = \frac{WL}{8} = \frac{6,940 \times 18 \times 12}{8}$$

$$= 184,680 \text{ in.-lb.}$$

The bending moment caused by a safe external uniform load of W_1 lbs. per foot run is

$$M_1 = R - M' = 766,080 - 184,680$$

$$= 581,400 \text{ in.-lb.}$$

$$= 48,450 \text{ ft.-lb.}$$

$$\text{Now } M_1 = \frac{W_1 L^2}{8}, \text{ and so}$$

$$W_1 = \frac{8M_1}{L^2} = \frac{8 \times 48,450}{(18)^2}$$

$$= 1,196 \text{ lb./ft.}$$

Therefore, the beam is safe for a uniformly distributed load of 1,196 lb. per foot run.

Tee-Beams -- It is difficult to provide sufficient resistance to compression in the ordinary rectangular sectioned beam where heavy loads have to be carried and so in order to overcome this difficulty the beam is designed as a T-section

⁺The density factor of concrete is 2.1 times the weight of water but for convenience the weight of concrete is generally taken as 150 lb./cu. ft.

with a wide flange to give more concrete in the top part of the beam relative to the width of the flange as shown in Fig. 18 .




Fig. 18

The construction of this Tee-beam then consists of a what is like a slab which is stiffened by a concrete rib on the underside, or a wider slab and its ribs (or girder) are built at the same time and thoroughly tied together, and these ribs with parts of the slabs (or beams) are then called Tee-beams.

Now referring to Fig. 18, which shows a very wide rectangular beam, it will be remembered that the concrete below the neutral axis (which is roughly one-third the depth down) is in tension, and this is roughly two thirds of it but its tensile action must be neglected in the design, so that the two areas shown shaded are not needed and so can be eliminated without in any measurable way reducing the strength of the beam. In other words, the strength of the rib and the slab for a breadth b acting together is equal to that of a rectangular beam of breadth b and of the same depth d , providing the steel which would be used in the larger rectangular beam is now concentrated into the narrow rib.¹ This improvement is obviously very economical and

¹ Faber & Bowie, Reinforced Concrete Design, Vol. I, pp. 38

is largely the cause of the economy of reinforced concrete construction.

From what has been said, it is clear that a Tee-beam may be designed as a rectangular beam of breadth b and depth d . However, in case any Tee-beam might have a greater breadth of slab as their compression member than can be called into play, therefore the resistance moment should be calculated from the amount of tension steel used. So Tee-beams may be calculated from the following formula:

$$R = A \times .85d \times f_s$$

where R = resistance moment in in.-lb.

A = area of steel in sq. in.

d = depth of beam + in in.

f_s = safe tensile stress in steel in lb./in.²

from which formula it is easy to calculate R when A , d , and f_s are known, or to calculate the area of steel needed to give a required value for R .

Now the question arises, what limits the breadth b of the Tee-beam? The width b that can be considered as acting with the beam will depend on circumstances, but it must not exceed either of the following:¹

- (a) one-third of the effective span of the Tee-beam
- (b) three-fourths of the distance from center to center of the ribs of successive Tee-beams
- (c) twelve times the thickness of the slab
- (d) six times the width of the rib of the Tee-beam

⁺ Measured from the top face of the compressed portion to the center of the tensile steel

¹ Faber & Bowie, Reinforced Concrete Design, Vol. I, pp. 38
Sutherland & Clifford, Reinforced Concrete Design, pp. 354

To make sure that the slab will act with the beams, it is necessary that there shall be bars in the slab across the beam. These bars naturally exist when the slab is continuous and spans from beam to beam, but if the beam in question happens to be a main beam (carrying only secondary beams and not slabs as well) then such steel might not ordinarily be provided, but yet its addition is advisable. As a rule, $\frac{3}{8}$ in. rods at 6 in. center to center for the breadth b will be suitable. See Fig. 19.




Fig. 19

Then what limits the width of rib (b_r)? The width of rib is also limited by three considerations --

- (a) It must not be less than one-third of the beam depth
- (b) The shear stress must not be too great. (This will be explained later). It can be shown from this consideration that the width of the rib should not be less than $\frac{W}{200d}$ where W is load on beam in pounds and d = depth in inches and, even then, shearing reinforcement is required.
- (c) If the beam is a continuous one, then, as explained previously (see Figs. 15 and 16i), it has to re-

sist a negative bending moment over the supports. This negative moment is about equal to the positive moment near midspan. The diagram also shows that, at the support, the bottom of the beams is in compression, and therefore at the support the slab does not help. Hence the beam will be too weak in compression at the support, if b_r is made very much less than b . This effect can be, and often is, overcome by increasing the depth of the beam near the support by means of haunches to the columns, but it may also be necessary to add compression reinforcement and then tension reinforcement will be needed of length .3 span in slab over column and set parallel to beam's length. Even so, it will be found that these negative moment at column supports will often determine the minimum width of the rib.

To make sure that the compression slab is really strong enough, all that is necessary is to see that the percentage of steel, calculated relative to the value of $b \times d$, does not exceed .675 per cent. If it does, the safe strength of the beam would be proportionately reduced, or a larger beam would have to be used.

The above discussion assumes that the neutral axis falls either within the slab or that it coincides with the bottom of the slab. If the neutral axis neither falls within the slab nor coincides with the bottom of the slab, but falls below the slab, then it means that we have not only omitted the concrete shown in the shaded area in Fig. 18 which was unstressed, but also a part

of that which was only slightly stressed in compression and so also somewhat of use. To check up for this it is only necessary to test whether the thickness of the slab is equal to or greater than $.36d$.

If the thickness of slab is only slightly less than $.36d$ then the neutral axis falls below the slab and if the thickness of slab is not less than $.30d$ then for such cases the amount of concrete between the underside of the slab and the neutral axis is so small, and the stress value there is so low, on account of its nearness to the neutral axis that the consequent reduction in the resistance of the beam to compression can be neglected in actual calculations.¹

To deal fully with the exact formulas used in the design of a Tee-beam whose neutral axis falls below the slab is too complicated for us to give here. However, the following approximate method is offered for practical requirements.²

When d_s is smaller than $\frac{4}{5}d$ as shown in Fig. 20, take --

$$\frac{m}{d} = \frac{nA}{nA + bd_s}$$

$$R = d - \frac{d_s}{2}$$

$$\text{Then } C = \frac{M}{d - \left(\frac{d_s}{2}\right)}$$




Fig. 20

1 Jones, B. E., Reinforced Concrete, pp. 104-105

2 Faber & Bowie, Reinforced Concrete Design, Vol. I, pp. 39-40

$$c_m = \frac{C}{bd_s}$$

$$c = c_m \times \frac{m}{m - \left(\frac{d_s}{2}\right)}$$

$$A = \frac{M}{\left(d - \frac{d_s}{2}\right) f_s}$$

where m = distance from top surface of slab to
neutral axis

n = modular ratio $\left(\frac{E_s}{E_c}\right)$

A = area of steel

M = bending moment

R = radius arm

C = total compression

c_m = mean compression stress

c = maximum compressive stress in concrete

f_s = safe tensile stress in steel

As an example of Tee-beam design, let us take a continuous beam 20 ft. span, carrying a 6-in. slab, the load being 200 lb. per sq. ft. inclusive of dead weight, and the beams being spaced 10 ft. apart.

The load per beam is : -

$$W = 20 \times 10 \times 200 = 40,000 \text{ lb.}$$

Taking the bending moment as $\frac{WL}{12}$, as suggested in Fig. 16i, we have:-

$$\text{Bending moment} = \frac{40,000 \times 20 \times 12}{12}$$

$$= 200,000 \text{ in.-lb.}$$

Reference to Table II (page 47) shows that a beam 20" x 8" overall, reinforced with 3- $\frac{3}{4}$ in. round rods and 3-1 in. round rods, gives a resistance moment of 240,000 in.-lb., a little more than is required.

The next step is to see whether the slab is sufficient to carry the compression stresses, so we note that the limiting width is :-

- (a) one-third of the effective span
of the Tee-beam $6\frac{2}{3}$ ft.
- (b) three-fourths of the distance from
center to center of the ribs of the
Tee-beam..... $7\frac{1}{2}$ ft.
- (c) twelve times the thickness of the slab... 6 ft.
- (d) six times the thickness of the rib
of the Tee-beam 4 ft.

Taking the smallest of these, we have available a slab of 4 ft breadth x 6 in. thick.

Table II shows that the beam requires a slab 29.5 in. x 6.57 in. thick. Though our slab is not quite the requisite thickness, this is more than compensated for by its breadth being more than required.

For rough approximation we see, as shown in Fig. 161, that a continuous beam has a bending moment of $\frac{WL}{12}$ at midspan, but it also has a moment of $-\frac{WL}{12}$ at the support. But the resistance moment given in Table II applies only to the center section of the beam, and so does not apply to the support, because at the support the compression is at the bottom, and there-

fore the concrete slab, which so greatly assists at the center section, is not available for compression at the ends.

If the end of the beam were to be calculated as a rectangular one of breadth 8 in. and depth $18\frac{1}{4}$ in., its resistance moment would be

$$R = 95 \times 8 \times (18\frac{1}{4})^2 = 253,000 \text{ in.-lb.}$$

But this would really be somewhat larger, because the percentage of steel is considerably greater than .675 per cent., and there would also be some steel on the compression side, but there is no need here to go further with this calculation here.

To make the beam strong enough at the support, it is therefore desirable to increase this moment of resistance nearly four times, which is usually covered by doubling the depth at the end, since it will be remembered that the resistance moment of a beam varies with the square of the depth. Referring again to diagram i in Fig. 16 shows that the reverse moment near the support dies away rapidly along the beam. Therefore the increased depth at the support may also be gradually reduced forming a haunch extending for one-eighth of the span of the beam.




Fig. 21

A general rule for designing the overall depth of the beam at support is to make the beam there twice the overall depth at midspan, as shown in Fig. 21.

The depth and length of haunch should be measured at and from the edge of the column, as shown in the figure.

This beam should now be checked for the tension reinforcement at the top surface of the beam across the column to see if it is strong enough to carry the negative bending moment $-\frac{wL^2}{12}$ there by treating the beam section as doubly reinforced beam which really is.

The arrangement of the reinforcement cannot be determined until we have considered the question of shear.

Ell-Beams -- In some cases beams are required which have a slab on one side only, as for example those acting as the trimmers around an open well for a staircase, lift, or similar purposes, and then it is not possible to design the beams with a Tee-section. If it is necessary to include the slab in the compressive resistance calculations the beam becomes an **ell**-section as shown in Fig. 22, and the compression flange is in-




Fig. 22

icated by the hatched portion. The width b of slab that can be

included as part of the beam is limited to four times the thickness of the slab for all ordinary cases but can be taken as high as six times the thickness only if special extra shear reinforcement is provided to deal with the complicated stress that is set up in a one-sided flange section.

TABLE II
STANDARD TEE BEAMS

NAME	OVERALL DEPTH IN IN.	BREADTH OF RIB IN IN.	TENSION STEEL		RADIUS ARM IN.	SECTION MODULUS IN STEEL UNITS IN ³	SAFE RESISTANCE MOMENT NEAR MID SPAN AT A STEEL STRESS OF 16,000 lb/in. ² IN-LB.	BREADTH OF SLAB (b) NEEDED IN.	THICKNESS OF SLAB NEEDED * IN.	EFFECTIVE DEPTH d IN.	MOMENTS OF INERTIA	
			BOTTOM LAYER	TOP LAYER							STEEL UNITS IN ⁴	CONCRETE UNITS IN ⁴
12x6	12	6	2- $\frac{5}{8}$ " ϕ	2- $\frac{5}{8}$ " ϕ	9.5	11.4	185,000	10.7	3.88	10 $\frac{3}{4}$	78.8	1,180
14x6	14	6	2- $\frac{5}{8}$ " ϕ	2- $\frac{3}{4}$ " ϕ	11.1	16.4	256,000	14.9	4.55	15 $\frac{5}{8}$	133	2,000
16x6	16	6	2- $\frac{3}{4}$ " ϕ	2- $\frac{3}{4}$ " ϕ	12.8	22.5	360,000	18	5.22	14 $\frac{1}{2}$	219	3,290
18x8	18	8	3- $\frac{3}{4}$ " ϕ	3- $\frac{3}{4}$ " ϕ	14.5	38.2	611,000	23.7	5.95	16 $\frac{1}{2}$	405	6,090
20x8	20	8	3- $\frac{3}{4}$ " ϕ	3-1" ϕ	16.0	58.6	940,000	29.5	6.57	18 $\frac{1}{4}$	687	10,300
22x8	22	8	3-1" ϕ	3-1" ϕ	17.6	83	1,330,000	34.9	7.2	20	1,065	16,000
24x10	24	10	4-1" ϕ	4-1" ϕ	19.3	121	1,940,000	42.3	7.9	22	1,710	25,600
26x10	26	10	4-1" ϕ	4-1 $\frac{1}{4}$ " ϕ	20.9	168	2,690,000	50	8.5	23 $\frac{3}{4}$	2,550	38,300
28x10	28	10	4-1 $\frac{1}{4}$ " ϕ	4-1 $\frac{1}{2}$ " ϕ	22.4	219	3,500,000	56.6	9.2	25 $\frac{1}{2}$	3,570	53,600
30x12	30	12	5-1 $\frac{1}{4}$ " ϕ	5-1 $\frac{1}{2}$ " ϕ	24.2	295	4,720,000	66	9.9	27 $\frac{1}{2}$	5,200	78,000

* If slab is of less thickness than given in the column, the breadth needed is greater than given in the previous column

This table is taken from *Faber, Reinforced Concrete Design, Vol. II, pp. 156*






Fig. 26

the following, which is the same as the one in [1, p. 100].

Let $\mathcal{C}$ be a curve in the plane, and let $\mathcal{C}'$ be the curve obtained by reflecting $\mathcal{C}$ across the line $y = x$.

Then the total length of the curve $\mathcal{C}$ is given by

$$L(\mathcal{C}) = \int_{\mathcal{C}} \sqrt{1 + \left(\frac{dy}{dx}\right)^2} dx = \int_{\mathcal{C}'} \sqrt{1 + \left(\frac{dx}{dy}\right)^2} dy$$

where the integral is taken over the curve $\mathcal{C}$ in the first quadrant, and the integral is taken over the curve $\mathcal{C}'$ in the second quadrant.

It is clear that the total length of the curve $\mathcal{C}$ is the same as the total length of the curve $\mathcal{C}'$.

Therefore, the total length of the curve $\mathcal{C}$ is given by

$$L(\mathcal{C}) = \int_{\mathcal{C}} \sqrt{1 + \left(\frac{dy}{dx}\right)^2} dx = \int_{\mathcal{C}'} \sqrt{1 + \left(\frac{dx}{dy}\right)^2} dy$$

where the integral is taken over the curve $\mathcal{C}$ in the first quadrant, and the integral is taken over the curve $\mathcal{C}'$ in the second quadrant.

$$L(\mathcal{C}) = \int_{\mathcal{C}} \sqrt{1 + \left(\frac{dy}{dx}\right)^2} dx = \int_{\mathcal{C}'} \sqrt{1 + \left(\frac{dx}{dy}\right)^2} dy$$

$$L(\mathcal{C}) = \int_{\mathcal{C}} \sqrt{1 + \left(\frac{dy}{dx}\right)^2} dx = \int_{\mathcal{C}'} \sqrt{1 + \left(\frac{dx}{dy}\right)^2} dy$$

Therefore, the total length of the curve $\mathcal{C}$ is given by

$$L(\mathcal{C}) = \int_{\mathcal{C}} \sqrt{1 + \left(\frac{dy}{dx}\right)^2} dx = \int_{\mathcal{C}'} \sqrt{1 + \left(\frac{dx}{dy}\right)^2} dy$$

where the integral is taken over the curve $\mathcal{C}$ in the first quadrant, and the integral is taken over the curve $\mathcal{C}'$ in the second quadrant.

Therefore, the total length of the curve $\mathcal{C}$ is given by

$$L(\mathcal{C}) = \int_{\mathcal{C}} \sqrt{1 + \left(\frac{dy}{dx}\right)^2} dx = \int_{\mathcal{C}'} \sqrt{1 + \left(\frac{dx}{dy}\right)^2} dy$$

It is, therefore, the total shear stress, τ , which must be carried by the concrete, and τ is given by the following equation, where V is the shear force, Q is the first moment of area, I is the moment of inertia, and b is the width of the beam:

$$\tau = \frac{V}{I} \times Q \times \text{distance from } Q \text{ to } I$$

where Q is the first moment of area of the concrete above.

It is assumed that τ is the same throughout the beam, and that the shear stress is uniformly distributed, and that the shear stress is uniformly distributed over the full depth of the beam:

- (1) Vertical stress distribution
- (2) Horizontal stress distribution
- (3) Distribution of shear stress and strain

For example, the concrete beam being designed is 12 in. wide, 18 in. deep, and 18 in. long. The steel, in this case, is 1 in. diameter, and is 18 in. long. It is the same as the steel used in the beam that it can carry without failure by shear. It is the same as the steel used in the beam.

The depth of a reinforced concrete beam, d , may be defined in shear as strictly the depth between the center of the tensile bars and the center of the compression area,¹ which is, usually, about .98 times the depth to the steel reinforcement (see page 84).

$$\text{Force } s = .500 \times 11 = 11.50$$

$$b = 12 \text{ in.}$$

$$t = 18 \text{ in./in.}^2$$

$$\text{Shear force } s = 11.50 \times 12 = 138$$

¹ Sutherland & Clifford, *Reinforced Concrete Design*, p. 81.

$$= 6,100 \text{ lb.}$$

As the shear in half of the beam is 6,100 lb., the resistance to shear is $V = 12,600 \text{ lb.}$

It was explained previously that the shear resistance of a beam having no shear reinforcement is the tensile strength multiplied by the cross-sectional area, or it was shown that failure occurs by the shear on a diagonal plane.

Let us suppose now that the total shear resistance developed in a beam is V pounds, then the tensile strength of steel is f_t pounds per square inch, therefore the diagonal plane. This can be found by breaking up a bar or bars (if several are bent up $\frac{1}{2}$ in.), if " t " is the total tensile stress in the bar there, then $V = At$ is the tension in the bars.

Let the angle of the diagonal shear resistance V is the vertical component of this, and is

$$V = At \sin \theta$$

where the $\sin \theta$ is the angle of the diagonal V in the direction of the bent-up bars, or the angle vertical, as shown in Fig. 27 (b). Therefore the shear resistance of bent-up bars is

$$V = At \sin \theta \quad \text{or } V = At \sin \theta$$




Fig. 27

Now the bars are bent up at 45° , the ratio $\frac{S}{T}$, or $\sin \theta$ is

+ In trigonometry this ratio $\frac{S}{T}$ is called $\sin \theta$

the other side of the river, the other side of the river, the other side of the river.

It is a very interesting thing to see the other side of the river, the other side of the river, the other side of the river. It is a very interesting thing to see the other side of the river, the other side of the river, the other side of the river.

+

The other side of the river.

It is a very interesting thing to see the other side of the river, the other side of the river, the other side of the river. It is a very interesting thing to see the other side of the river, the other side of the river, the other side of the river.

It is a very interesting thing to see the other side of the river, the other side of the river, the other side of the river. It is a very interesting thing to see the other side of the river, the other side of the river, the other side of the river.

(1) The other side of the river, the other side of the river, the other side of the river.

(2) The other side of the river, the other side of the river, the other side of the river.

(3) The other side of the river, the other side of the river, the other side of the river.

(4) The other side of the river, the other side of the river, the other side of the river.

It is a very interesting thing to see the other side of the river, the other side of the river, the other side of the river.

Design of a continuous beam with three equal spans, each 12 ft. long, to carry a uniformly distributed load of 4,000 lb. per ft. The beam is to be made of concrete with a compressive strength of 3,000 lb. per sq. in. and steel with a yield strength of 60,000 lb. per sq. in.

The beam is to be made of concrete with a compressive strength of 3,000 lb. per sq. in. and steel with a yield strength of 60,000 lb. per sq. in.

The beam is to be made of concrete with a compressive strength of 3,000 lb. per sq. in. and steel with a yield strength of 60,000 lb. per sq. in.

The beam is to be made of concrete with a compressive strength of 3,000 lb. per sq. in. and steel with a yield strength of 60,000 lb. per sq. in.

$$\frac{M_L}{C} = \frac{4,000 \times 25 \times 12}{12} = 1,000,000 \text{ in.-lb.}$$




Fig. 29

The area of steel required for the beam is

$$A_s = \frac{1,000,000}{60,000 \times 0.85 \times 24} = 0.1 \text{ sq. in.}$$

The beam is to be made of concrete with a compressive strength of 3,000 lb. per sq. in. and steel with a yield strength of 60,000 lb. per sq. in.

The beam is to be made of concrete with a compressive strength of 3,000 lb. per sq. in. and steel with a yield strength of 60,000 lb. per sq. in.

The beam is to be made of concrete with a compressive strength of 3,000 lb. per sq. in. and steel with a yield strength of 60,000 lb. per sq. in.

$$24,000 \times \frac{8}{125} =$$

1. $\frac{1}{2}$ of the total number of students in the class are girls. If there are 12 girls in the class, how many students are there in total?

2. A number is 15 less than 3 times another number. If the sum of the two numbers is 45, find the numbers.

3. The sum of three consecutive integers is 120. Find the integers.

4. A number is 10 more than 2 times another number. If the difference between the two numbers is 15, find the numbers.

5. The sum of two numbers is 40. One number is 4 less than the other. Find the numbers.

6. A number is 25 more than 4 times another number. If the sum of the two numbers is 100, find the numbers.

7. The sum of three consecutive even integers is 180. Find the integers.

8. A number is 12 less than 5 times another number. If the sum of the two numbers is 60, find the numbers.

9. The sum of two numbers is 50. One number is 6 more than the other. Find the numbers.

10. A number is 30 more than 3 times another number. If the sum of the two numbers is 120, find the numbers.

11. The sum of three consecutive odd integers is 210. Find the integers.

12. A number is 18 less than 6 times another number. If the sum of the two numbers is 90, find the numbers.

13. Find the sum of the first 10 natural numbers.

14. Find the sum of the first 15 natural numbers.

15. Find the sum of the first 20 natural numbers.

16. Find the sum of the first 25 natural numbers.

17. Find the sum of the first 30 natural numbers.

18. Find the sum of the first 35 natural numbers.

19. Find the sum of the first 40 natural numbers.

20. Find the sum of the first 45 natural numbers.

21. Find the sum of the first 50 natural numbers.

22. Find the sum of the first 55 natural numbers.

23. Find the sum of the first 60 natural numbers.

24. Find the sum of the first 65 natural numbers.

25. Find the sum of the first 70 natural numbers.

26. Find the sum of the first 75 natural numbers.

the following: (a) the first two, (b) the third, and (c) the fourth.

and the following: (a) the first two, (b) the third, and (c) the fourth.

1-10. The following are the first two, (b) the third, and (c) the fourth.

1-11. The following are the first two, (b) the third, and (c) the fourth.

1-12. The following are the first two, (b) the third, and (c) the fourth.

1-13. The following are the first two, (b) the third, and (c) the fourth.

1-14. The following are the first two, (b) the third, and (c) the fourth.

1-15. The following are the first two, (b) the third, and (c) the fourth.

1-16. The following are the first two, (b) the third, and (c) the fourth.




Fig. 31

1-17. The following are the first two, (b) the third, and (c) the fourth.

1-18. The following are the first two, (b) the third, and (c) the fourth.

in

1. 在下列各数中，找出所有满足条件的数：
 2. 在下列各数中，找出所有满足条件的数：
 3. 在下列各数中，找出所有满足条件的数：

4. 在下列各数中，找出所有满足条件的数：
 5. 在下列各数中，找出所有满足条件的数：
 6. 在下列各数中，找出所有满足条件的数：
 7. 在下列各数中，找出所有满足条件的数：
 8. 在下列各数中，找出所有满足条件的数：
 9. 在下列各数中，找出所有满足条件的数：
 10. 在下列各数中，找出所有满足条件的数：
 11. 在下列各数中，找出所有满足条件的数：
 12. 在下列各数中，找出所有满足条件的数：
 13. 在下列各数中，找出所有满足条件的数：
 14. 在下列各数中，找出所有满足条件的数：
 15. 在下列各数中，找出所有满足条件的数：
 16. 在下列各数中，找出所有满足条件的数：
 17. 在下列各数中，找出所有满足条件的数：
 18. 在下列各数中，找出所有满足条件的数：
 19. 在下列各数中，找出所有满足条件的数：
 20. 在下列各数中，找出所有满足条件的数：

$$\begin{aligned}
 & \left(\frac{1}{2} - \frac{1}{3} \right) \\
 & \left(\frac{1}{4} - \frac{1}{5} \right) \\
 & \dots
 \end{aligned}$$

21. 在下列各数中，找出所有满足条件的数：
 22. 在下列各数中，找出所有满足条件的数：
 23. 在下列各数中，找出所有满足条件的数：
 24. 在下列各数中，找出所有满足条件的数：
 25. 在下列各数中，找出所有满足条件的数：

26. 在下列各数中，找出所有满足条件的数：
 27. 在下列各数中，找出所有满足条件的数：
 28. 在下列各数中，找出所有满足条件的数：
 29. 在下列各数中，找出所有满足条件的数：
 30. 在下列各数中，找出所有满足条件的数：

The first part of the paper is devoted to the study of the properties of the function $f(x)$ defined by the equation $f(x) = \int_0^x f(t) dt$. It is shown that $f(x)$ is a constant function. The second part of the paper is devoted to the study of the properties of the function $f(x)$ defined by the equation $f(x) = \int_0^x f(t) dt$. It is shown that $f(x)$ is a constant function. The third part of the paper is devoted to the study of the properties of the function $f(x)$ defined by the equation $f(x) = \int_0^x f(t) dt$. It is shown that $f(x)$ is a constant function. The fourth part of the paper is devoted to the study of the properties of the function $f(x)$ defined by the equation $f(x) = \int_0^x f(t) dt$. It is shown that $f(x)$ is a constant function. The fifth part of the paper is devoted to the study of the properties of the function $f(x)$ defined by the equation $f(x) = \int_0^x f(t) dt$. It is shown that $f(x)$ is a constant function.

The first part of the paper is devoted to the study of the properties of the function $f(x)$ defined by the equation $f(x) = \int_0^x f(t) dt$. It is shown that $f(x)$ is a constant function. The second part of the paper is devoted to the study of the properties of the function $f(x)$ defined by the equation $f(x) = \int_0^x f(t) dt$. It is shown that $f(x)$ is a constant function. The third part of the paper is devoted to the study of the properties of the function $f(x)$ defined by the equation $f(x) = \int_0^x f(t) dt$. It is shown that $f(x)$ is a constant function. The fourth part of the paper is devoted to the study of the properties of the function $f(x)$ defined by the equation $f(x) = \int_0^x f(t) dt$. It is shown that $f(x)$ is a constant function. The fifth part of the paper is devoted to the study of the properties of the function $f(x)$ defined by the equation $f(x) = \int_0^x f(t) dt$. It is shown that $f(x)$ is a constant function.

•

[illegible]

$$\begin{aligned}
 \text{The actual weight of steel reinforcement,} \\
 W = 1.57 \times 1.1 \times 11 = 19,300 \text{ lb.} \\
 \text{The actual load} = 11,000 + 4,400 \\
 = 15,400 \text{ lb.} \\
 \text{The load factor} = 1.25
 \end{aligned}$$

$$\begin{aligned}
 \therefore \frac{1}{F} &= \frac{1}{1.25} \\
 &= \frac{11,000 + 11 \times 11}{1.25} \\
 &= 90,000 \text{ in.-lb.}
 \end{aligned}$$

It is assumed that the effective depth of the cylindrical shell is 11 in. (based on the inside diameter only), and this is sufficient for it is sufficient in strength. Let us take the effective diameter of 20 in., thus leaving 2 in. for covering and a breadth of 10 in. Then the economical percentage of reinforcement is

$$A = \frac{90,000}{1.1} \div 11 \times 10 = 1.63 \text{ sq. in.}$$

The weight of reinforcement

$$\begin{aligned}
 W &= A \times f_s \times .008 \\
 &= 1.63 \times 16,000 \times .008 \times 22 \\
 &= 58,000 \text{ in.-lb.}
 \end{aligned}$$

The actual load is not, however, equal to 5,600 in. lb., and the excess weight which has to be provided for extra tensile reinforcement and compressional reinforcement is

$$580,000 - 490,000 = 190,400 \text{ in.-lb.}$$

Before finding the amount of the compressional reinforcement, the question of the correct placement of this compressional

reinforcement must be provided in order to distribute the lever arm between these two sets of reinforcement. It is desirable to place the compressional reinforcement at the top of the pile for the neutral axis will be within a center of gravity of concrete, and this will be a distance of 12.8 in. at a distance 2 in. from the upper surface of the pile as shown in Fig. 32. The two sets of reinforcement, one situated at 4.2 in. from the upper




Fig. 32

surface and the other at a distance 12.8 in. below that axis.

Let the distance from the upper surface to the center of the compressional reinforcement be d_c , then the distance between the centers of the two sets of reinforcement (or lever arm) is $d - d_c$ (in example 22 - 2 in. in our case), as shown in Fig. 33. The distance from the center of the pile to the




Fig. 33

will be $A_t f_s$ in., and this is obtained by dividing the moment by $f_s(C - d_c)$. This may be expressed as follows:

$$\begin{aligned}
 c_2 &= \frac{25,000 \times 1000}{3(6 - 1)} \\
 &= \frac{25,000}{10,000 - 10} \\
 &= .15 \text{ in.}
 \end{aligned}$$

This additional reinforcement must be added to the amount first calculated in order to give the total area of top-side reinforcement, which is,

$$1.62 + 0.45 = 2.07 \text{ sq. in.}$$

It is now previously mentioned that when steel and concrete are working together in compression the stress in the steel can only reach 18 times that in the surrounding concrete, as it is only under these conditions that they can act together. The stress in the concrete at its extreme upper edge is equal to 600 lb./in.² and generally it is assumed that the neutral axis is as previously explained.

Now let us see the steel must be placed in the layer where the maximum compression occurs. Consequently the stress in the concrete there will be less than 600 lb./in.², when the steel is placed at a distance of c_2 from the upper surface of the beam as shown in Fig. 68 for it is closer to the neutral axis. The stress in the steel will be equal to $\frac{n(c_2 - c_1)}{c_2}$ which expresses proportion of stress at this point. The value of c_2 as above will equal n (or 18) times this amount, and therefore,

$$\begin{aligned}
 c_2 &= \frac{n \times 3(c_1 - c_2)}{1} \\
 &= \frac{18 \times 600 \times (7.2 - 3)}{7.2}
 \end{aligned}$$

$$= 6,500 \text{ lb.}$$

Then the area of the compressional reinforcement A_c is,

$$\begin{aligned} A_c &= \frac{\text{bending moment}}{c_c \times (d - c_c)} \\ &= \frac{121,400}{6,500 \times (20 - 2)} \\ &= 1.11 \text{ sq. in.} \end{aligned}$$

The beam is designed, therefore, for an overall size 22 in. by 12 in., with an effective depth of 20 in., and the reinforcement consists of 3.37 sq. in. in the tensional area and 1.11 sq. in. in the compressional area.

It is easily seen that for doubly reinforced concrete beams the total shear resistance from inclined compression, bent up bars and stirrups will have to be larger and so the shear must be very carefully designed for, because of the increase in the compression and tension in the "chord" parts of such beam. As a matter of fact a beam not sufficiently strengthened for its shear resistance would be almost as useless as a plate girder strong enough in its flanges but with too thin a web or one not sufficiently strengthened against buckling or like a bridge truss with proper chords but too weak a diagonal system for its travelling.

See-Beams -- With regard to see-beams with double reinforcement, it is not considered necessary to give any particular examples for this class of calculation, as the same formulae

and principles will apply as were given for beams with double reinforcement when the neutral axis falls within the slab or coincides with the under side, and, as previously stated, these are the most common cases. It must be borne in mind, however, that b will represent the width of the flange acting with the beam can be designed upon the assumption that the concrete in the rib is to be neglected.

In any case where double reinforcement is employed, the two sets should always be connected by binding as shown in Fig. 34.




Fig. 34

Chapter VIII

Reinforced Concrete Columns⁺

Columns are called upon to support the ends of beams and to provide the reactions necessary to counteract their loading. In the ordinary way the columns are subject to direct compression; that is, the stress is not caused by leverage but simply by the direct thrust downwards of a load placed on the top. In many cases the column will also be supporting other columns above, in addition to loads from the ends of beams, and so the total load has to be provided for in the strength of the column.

Plain Concrete Columns -- From what has already been explained it is clear that a concrete column would in many cases be quite satisfactory as a compression member without any reinforcement, since concrete is strong in compression. In certain cases where the load can be assumed to be absolutely centrally applied to the column then it is justifiable in practice to build columns of plain concrete,⁺⁺ and a safe stress of 600 lb./in.² may be allowed. However, usually it can be by no means certain that the loading will be quite central on the column, and that there will be no bending stresses set up, and therefore in practice a lesser value of safe stress than indicated above should be used.

+ To architects a "column" probably means a long round body to support or adorn a building but engineers often use the term to embrace all compression members.

++ providing that l/d is ≤ 6 , where l is length of column and d is least diameter or least side if the column is a rectangular one.

Reinforced Concrete Columns -- It might appear first that to design a column⁺ which has to carry a definite load centrally or axially applied is a very simple matter, as it seems that there is no complication of bending moments, nature of loads, and similar matters. In practice, however, it is practically impossible to secure axial loading. As will be seen, when a beam is built monolithically with a column at each end, and loaded, the beam necessarily deflects, so that its ends now take up a slope even if they were originally horizontal. The effects of this is that either the beam rests on the inside edge of the column or else the column bends so that its upper ends take up approximately the same




Fig. 35

slope as the ends of the beam¹, as shown in Fig. 35. In either case, the column is subjected to a bending moment in addition to the direct load.

Now the amount of this bending moment depends upon the relative stiffnesses of the beam and the column. If the column is very stiff compared to the beam, it will offer great restraint to the end of the beam, and then the beam will approximate to the case of a beam fixed at its ends, for which the bending moment there is

+ providing that l/d is < 15 or l/k is < 40 . Here l is the length of column, d is least diameter or least side for rectangular column, k is least radius of gyration of the column.

1 Faber & Bowie, Reinforced Concrete Design, Vol. I, pp. 94-95

11. If the column is very flexible compared to the beam, it will offer very little restraint and the bending moment at the beam ends will approximate to zero. Practical cases lie between two limits.

Design of the Outer Column -- To measure the relative stiffness of the column to the beam the quantity¹ $\frac{KC}{B}$ is used, in which

K = a constant depending on the fixity at the other end of the column, and may in general be taken as 6 for outside columns, and 4 for interior columns.²

C = stiffness of the column, or equals the moment of inertia of the column divided by its length.

B = stiffness of the beam, or equals the moment of inertia of the beam divided by its length.

Now with Table II on page 47, the moment of inertia of standard beams was given. In Tables III and IV on page 86, the moment of inertia of standard square and rectangular columns are given. With these tables before us, it is therefore quite easy to calculate $\frac{KC}{B}$ of the column for any case.

Tables VII and VIII on page 88 give the bending moments in the column for various ratio of $\frac{KC}{B}$ for outside and interior columns respectively. With all these tables before us, the design of a reinforced concrete column should be quite simple.

For example, suppose we have a beam 20 ft. span carrying 20,000 lb. distributed load including the weight of the beam,

¹ Faber & Bowie, Reinforced Concrete Design, Vol. 1, pp. 124-131

² Lee, Graphs for Engineers and Architecture, pp. 58

Faber & Bowie, Reinforced Concrete Design, Vol. 1, pp. 125, 126

Note:- Tables V and VI give the standard square and rectangular columns allow for neglecting $1\frac{1}{2}$ in. concrete cover, while Tables III and IV do not allow for neglecting $1\frac{1}{2}$ in. concrete covering.

supported on columns 12 ft. 6 in. long in the top story.

The beam being considered as fixed at both ends, the bending moment, therefore, is $\frac{WL}{12}$. Thus

$$B.M. = \frac{30,000 \times 20 \times 12}{12} = 400,000 \text{ in.-lb.}$$

From Table II, we shall find that the standard Tee-beam 18 in. x 8 in. will be required, and the table also gives the moment of inertia of this beam as 6,080 in.⁴, whence

$$C = \frac{6,080}{240} = 25.36$$

240 being the length of the beam in inches (20 ft.).

Suppose we support this on an outer column 14 in. x 14 in., then from table III, we find that its moment of inertia is 3,940 in⁴ whence

$$C = \frac{3,940}{150} = 26.27$$

Taking K as 6 for outside columns, we have

$$\frac{KC}{B} = \frac{6 \times 26.27}{25.36} = 6.2$$

from Table VII it will be seen that the bending moment corresponding to $\frac{KC}{B} = 6.2$ is about $\frac{WL}{17.3}$, which in our case is

$$B.M. = \frac{30,000 \times 20 \times 12}{17.3} = 277,500 \text{ in.-lb.}$$

Now the stress in the column due to bending is given by $\frac{Md}{EI}$

where M = the bending moment

d = the diameter of column (if a rectangular column is used d is the least side).

I = the moment of inertia

or in our case

$$= \frac{277,500 \times 14}{2 \times 3,640} \dots\dots\dots = 493 \text{ lb./in.}^2$$

The direct stress due to load is $\frac{R}{A}$

$$= \frac{10,000}{210} \dots\dots\dots = 47 \text{ lb./in.}^2$$

$$\text{Adding gives a total} \quad = 537 \text{ lb./in.}^2 +$$

Where R is the reaction and A is the total area of concrete and steel in the column, as given in Table II.

The calculation for the foregoing column was for the top floor, that is, for one which stopped at the beam it supported. Such a column is subjected to greater bending stresses than a column in a lower story which also runs up above the beam it carries, because in that case the bending moment from the beam is carried partly by the length of column above the beam and partly by the column below it.

Let us consider an outside column 14 in. x 14 in. that is supporting a standard Tee-beam 18 in. x 8 in. x 20 ft. span, carrying 20,000 lb. distributed load at roof level, and also supporting a similar beam and load at next floor, 12 ft. 6 in. lower, a similar beam and load 12 ft. 6 in. lower still, and so on. Now the stresses in the column of the top floor will be exactly as calculated above (assuming that the roof dead loading intensity is same as floor loading). But, as an example, those in the floor next lower to the top floor will now be calculated.

Column carries 10,000 lb. from roof level

Column carries 10,000 lb. from floor level

Total	<u>20,000 lb.</u>
-------	-------------------

+ These stresses do not include those due to wind pressure, which would be important and greatest near the ground.

From Table III on page 86 the equivalent area of a 14 in. x 14 in. column is given as 230 sq. in. Therefore the direct stress is

$$\frac{20,000}{230} = 87 \text{ lb./in.}^2$$

Now $B = \frac{6,090}{240} = 25.36$ as before; but the stiffness of the column is made up of two parts, one above the floor, and one below the floor. Taking K as 6 as before, then,

$$KC \text{ above the floor} = 6 \times \frac{2,940}{150} = 117.60$$

$$KC \text{ below the floor} = 6 \times \frac{3,940}{150} = 157.60$$

$$315.20$$

Hence the total KC as effecting the joint between the column and the floor beam equals 315.20, whence

$$\frac{KC}{B} = \frac{315.20}{25.36} = 12.5$$

From Table VII on page 88 the moment factor at the joint due to this is .068 WL and the bending moment is,

$$M = .068 \times 20,000 \times 20 \times 12$$

$$= 312,000 \text{ in.-lb.}$$

As stated previously, half of this moment is carried by the upper length of column, and half by the lower length, so that the column under the first floor below the top floor (roof) only carries

$$M = 156,000 \text{ in.-lb.}$$

The stress due to the bending is

$$\frac{M}{Z} = \frac{156,000 \times 14}{2 \times 3,940} = 278 \text{ lb./in.}^2$$

so that the maximum stress there is $278 + 87 = 365 \text{ lb./in.}^2$

From the example shown above, it will be seen that while the direct stress is double (as the lower column carries two

floors instead of one) the bending stress is much reduced, and the total stress is less. If we investigate the stresses for the column under the next lower floor, we shall get,

$$\begin{array}{rcl}
 \text{Direct stress} & = \frac{30,000}{230} & = 130 \text{ lb./in.}^2 \\
 \text{stress due to bending moment} & = & 278 \text{ lb./in.}^2 \\
 \hline
 & \text{Total} & 408 \text{ lb./in.}^2
 \end{array}$$

and so on.

From this, it will be seen that in outside columns the stresses are often greatest in the top floor or under the roof, and that the section of the outer column required for the top floor will also be strong enough for several tiers down. It is advantageous, therefore, to make the outer column the same size on all floors for a building of not more than four to six stories in height, for the reason that the constant section enables the column moulds to be used again which is often a more important consideration than the saving of a *few* inches of concrete by varying the section of the column.

The Design of the Interior Columns -- In the interior columns, the bending moment generally plays a less important part. It will be noted that the dead load is not going to cause any bending moments in the column, since the dead load is balanced. The only bending moments on the interior column will be the live load when the panel on one side is loaded and that on the other is unloaded as shown in Fig. 36. Therefore, in Table VIII, V is the live load only whereas for Table VII, W is the sum of dead and live loads, since both these loads produced deflection and bending on the column.

Bending moments on interior columns may be sometimes neglected without great risk while to do so in outer columns is very dangerous.




Fig. 36

The general design of columns for interior columns has been given. It is necessary to state briefly the arrangement of the vertical bars and the lateral binding in the column section. As shown in Fig. 37, the diagram (a) is the commonest form of reinforced column up to 16 sq. in. or thereabouts. After that eight rods are generally used up to 24 sq. in. as the diagram (b).

It will be noticed that the rods are placed near the edges of the column rather than towards the center. The reason for this is because the action of the rods is principally to take up any tension which may occur during bending and, as such tension exists only near the edges of the column, it is there that the rods are placed. It should be noticed also that as the rods are placed near the edge and are in general very long in comparison to their diameter they would be extremely liable to buckle, and so bursting the small covering skin of concrete around them away from the core of the column and thus allowing the rods to buckle outwards and so destroy it. To prevent this the vertical rods are held in by means of bindings as shown in

Fig. 37. These bindings are generally about $\frac{1}{4}$ in. diameter⁺ round rods, and occur at about 6 in. centers in the column, and the vertical rods generally vary from $\frac{1}{2}$ in. diameter up to $1\frac{1}{4}$ in. diameter. The amount of longitudinal reinforcement used should not be more than 2 per cent. nor less than 0.5 per cent. of the total area of the column.

When only four vertical rods are used square bindings are all that is necessary, but where eight rods are used square binding would not be effective in preventing the rods in the middle of the faces from bursting outwards, since considerable movement could take place before the binding could become effective. Therefore additional bindings have to be used, as indicated in diagram (b) in Fig. 37.

Another form of reinforcement for columns is the spiral binding indicated in Fig. 37 (c). This was first thoroughly investigated by Mons. Considère. Spiral binding considerably strengthens the concrete by preventing it from bulging when the load is applied.

+ There is no rational method of determining the size of the steel rod that should be used for a lateral tie. A safe rule to follow is to use a bar of such diameter that the area of its section is not less than 2 per cent. of the section of the longitudinal reinforcement held in place by the tie.

Chapter IX

Reinforced Concrete Walls

Reinforced concrete is used for the construction of walls of different types which can be divided into two main classes; namely: the walls of a structure above the ground and retaining walls for the support of earth or water.

The Walls of a Structure above Ground -- In this type, the walls are usually in the nature of panels filling in between the main weight-carrying members of the framework, and no great strength is required because these panels merely act as a screen to keep out the weather. Generally speaking, these panels may be of any thickness not less than 4 in. and it is rare that more than 6 in. is required when they are not loaded that is when all loads are transmitted directly to the framework of the structure. Each panel in any external wall is generally designed to safely resist a horizontal wind pressure of at least 30 lb./ft.^2 , assuming that this pressure is acting uniformly over the area of one panel from either side. It should be said that the panel must be strong enough to resist pressure outwards as well as inwards to provide for the suction that occurs on the leeward side of a building during a gale and also to allow for pressures that may be caused by materials stacked against the wall inside the building, and because of this the reinforcement must either be placed in the center of the concrete wall or the wall must be reinforced near both its inner and outer surfaces.

The panel of the wall mentioned above will resemble a

slab on edge in a vertical position with a horizontal load being exerted on either one of the faces, and all the points above above in connection with the design of floor slabs will apply except that the dead weight of the slab itself will not in this case have to be added to the applied load, or, in sure, for the reason that its own weight will not cause any bending moment but may cause some column action which may be somewhat augmented by a load arising at the upper beam. Unless the distance between the main weight-carrying beams is excessive the specified live pressure of 30 lb./ft.² will not produce a very large bending moment and the thickness of concrete and the sectional area of the steel required will be very small.

Where openings occur in the wall the strength required around the edges is usually provided by the addition of some extra reinforcement, and all rods that are cut by the edges of the opening must be hooked at their ends around the bars perpendicular to them placed around the edges of the opening.

Retaining Walls -- As we stated previously retaining walls are built to support or retain earth or water, and the most suitable material for this purpose is reinforced concrete.

Wall for Retaining Earth -- A mass of earth standing alone will **not** stand up with a vertical face, but portions will commence to slide down, especially when exposed to rain or frost. A simple method to illustrate the natural tendency of soil to slide down and thus form sloping sides without lateral support is by pouring sand on to a floor. The slope or the angle that

the sloping sides makes with the floor is known as the "angle of repose". This angle will vary with different materials and also in the same material according to its state of consolidation and Fig. 37. Dry sand will usually make an angle of about 30 degrees with the horizontal, whereas clean fine gravel will make an angle of 45 degrees. When it is necessary to make the earth stand up at a vertical face or at a slope greater than the "natural" slope, it becomes necessary to build a retaining wall in front of it, and the pressure exerted on the back of such a retaining wall will depend on the difference of slope between the face of the wall and the natural slope of the material.

As shown in Fig. 38, the natural slope of the soil is indicated by the sloping line a-b and the retaining wall is shown




Fig. 38

in outline above the lower ground level. The sloping line a-c is the "line of rupture", and it is only the wedge-shaped portion of earth between this line and the back of the wall which will be required to be supported. If the wall should be suddenly removed, the portion of the earth between the line of rupture and the back face of wall will slip down first, because there is

a large amount of friction set up between the sliding wedge that is also tending to slide and the portion below the natural slope which will remain stationary, and to allow for this friction the angle between the natural slope and the face of the wall is divided into two equal parts to give the line of rupture.¹ The earth contained in the triangle between the line a-c and the back face of the wall a-b is then, free and against the wall and needs to push it over, and the wall must have sufficient height and strength to resist this push.

In the design we consider a length of one foot only in calculating the weight of soil to be supported and in the design of wall. Now it is necessary to consider both the vertical portion of the wall and the base, because the latter must be sufficiently large to anchor the vertical portion and to distribute the pressure over such an area of foundation as is necessary to bring the load per square foot within the safe bearing force of the soil.

As an example, a diagram of a retaining wall is shown in Fig. 89, where the natural slope and the line of rupture are indicated for the particular soil to be supported. It is just explained the earth between the line of rupture and the back face of the wall is the portion which causes a pressure on the wall and it is only the effect of the weight of this portion that we need to consider. Now the weight of the earth in the triangle ABC is calculated according to the nature of the soil,

¹ Jones, E. L., *Highway Concrete*, p. 128.

and this weight is represented by the line DF acting along the vertical at the gravity of the triangle ABC (the center of gravity of the triangle ABC).





Fig. 39

AD is the intersection point of the lines connecting each corner with the mid-point of the opposite side) indicated at D in the figure of Fig. 39. The weight of this earth will act downwards, and a vertical line DF through D and F will be drawn. The center of gravity until it cuts the line of rupture is indicated at D . As the soil below the line of rupture is laterally confined, the weight of the earth above the line of rupture is to be considered as resisted by the lower soil, the causing an earth pressure against the back of the wall. Then from the intersection point D , the weight of the earth as calculated is measured equal to scale AB to F , and from F a line parallel to the line of rupture is drawn until it intersects a horizontal line drawn from D in E . The length of this horizontal line DE then indicates to scale the value of the horizontal pressure or thrust on the back face of the wall, and it will be found that the point at which this horizontal pressure acts is usually at approximately

situ



line drawn on the right side to the greater depth will give the necessary thickness of the wall at the joint. The joint on line mn which the wall is going to penetrate must be reinforced by a ring of steel.

In design conditions there is a risk of the wall falling forward or backward at some point. To prevent this, the wall must be designed so that the resultant of the forces acting on it will fall within the middle third of the base.




Fig. 41




Fig. 42

vertical surface which is perpendicular to the plane of the wall.

A typical type of wall is shown in Fig. 43. It is a wall with a projecting or cantilevered base.

When the height of the wall is large, it is necessary to provide for a base that will be able to resist the use of the counterfort type. In this type the vertical wall is supported at intervals by triangular buttresses or counterforts.

These counterforts act as cantilevers and are securely tied to both the vertical wall and the base. The projecting toe of the base is a cantilever while the inner portion is a slab supported by the counterforts. The vertical wall is usually treated as a slab partly continuous and uniformly loaded.

Walls for Retaining Water -- Retaining walls built to resist water pressure follow the same general principles, but here matters are somewhat simplified because there is no variation due to weight or angle of repose and the pressure can be accurately determined when the depth of the water is known. The weight of a cubic foot of water is generally taken as 62½ lb., and the pressure in pounds per square foot against the wall will equal the depth of the water in feet multiplied by 62½. The pressure varies directly as the depth, being zero at the top, and it is a maximum at the bottom, and the center of the whole pressure will be situated at a level of one-third the height ($\frac{H}{3}$) above the base.

A section of a wall to retain water is shown in Fig. 43.




Fig. 43

Table III

Materials	Angle of Dip
1st. Magnetite (magnetite)	10° 0' 0"
2nd. " "	10° 0' 0"
3rd. " "	10° 0' 0"
4th. " "	10° 0' 0"
5th. " "	10° 0' 0"
6th. " "	10° 0' 0"
7th. " "	10° 0' 0"
8th. " "	10° 0' 0"

The above table shows the results of the experiments made with the magnetite, and the results of the experiments made with the other materials.

The above table shows the results of the experiments made with the magnetite, and the results of the experiments made with the other materials.

CHLORINE

Chlorine is a greenish-yellow gas.

Properties

Chlorine is a greenish-yellow gas with a strong odor. It is highly soluble in water, forming a solution known as chlorine water. Chlorine is a strong oxidizing agent and is used in the manufacture of many chemicals.

Chlorine is a gas at room temperature and pressure. It is a strong oxidizing agent and is used in the manufacture of many chemicals. Chlorine is a gas at room temperature and pressure. It is a strong oxidizing agent and is used in the manufacture of many chemicals.

Chlorine is a gas at room temperature and pressure. It is a strong oxidizing agent and is used in the manufacture of many chemicals. Chlorine is a gas at room temperature and pressure. It is a strong oxidizing agent and is used in the manufacture of many chemicals.

Chlorine is a gas at room temperature and pressure. It is a strong oxidizing agent and is used in the manufacture of many chemicals. Chlorine is a gas at room temperature and pressure. It is a strong oxidizing agent and is used in the manufacture of many chemicals.

The variation in pressure is indicated by the solid triangle at the center of the hole pressure is shown at a distance of $\frac{H}{2}$ from the base which is at the center of gravity of the triangle. The resultant acting at the bottom of the wall will equal the total pressure when the distance $\frac{H}{2}$ is equal to $\frac{66\frac{1}{2} \times H}{2} \times \frac{1}{2}$. The pressure of water varies directly to its depth, and is not influenced by the shape or size of the tank or the vessel which contains it. In other words, the pressure per sq. ft. on the walls of a tank 10 ft. deep is 63.2 lbs. equally the same on that of the walls of a tank 100 ft. deep is 632 lbs. provided both are filled with water, and the only thing that a natural pressure is to measure the depth of the water.

The variation in pressure is indicated by the sloped triangle and the center of the whole pressure is shown at a distance of $\frac{H}{3}$ from the base which is at the center of gravity of the triangle. The variation in pressure at the bottom of the wall will equal the total pressure when the width of the wall is equal to $\frac{6P_1}{\gamma \times H} \times \frac{1}{2}$. The pressure of water varies directly as the depth, and it is not influenced by the shape or size of the tank or any other vessel which contains it. In other words, the pressure per sq. ft. on the walls of a tank 10 ft. square by 6 ft. deep is exactly the same as that on the walls of a tank 10 ft. square by 6 ft. high, provided both are filled with water, and the only thing that is required is to know the depth of the water.

Table III

Location	Angle of Dip
Top of the main fault zone	15° to 20°
Base of the main fault zone	10° "
Top of the main fault zone	10° "
Base of the main fault zone	10° "
Top of the main fault zone	10° "
Base of the main fault zone	10° "
Top of the main fault zone	10° "
Base of the main fault zone	10° "

The above data are based on the assumption that the fault zone is a single, continuous, and homogeneous body. The actual conditions may be more complex.

The above data are based on the assumption that the fault zone is a single, continuous, and homogeneous body. The actual conditions may be more complex.

CHAPTER II

THE HISTORY OF THE INDIAN


CHAPTER I

The history of the Indian people is a long and interesting one. It is a story of a people who have lived in this country for many centuries, and who have made many contributions to the civilization of the world. The Indian people have a rich and varied culture, and their history is a testament to their resilience and strength.

The first chapter of the history of the Indian people is the story of their early life. The Indian people have lived in this country for many centuries, and their history is a testament to their resilience and strength. The Indian people have a rich and varied culture, and their history is a testament to their resilience and strength.

The second chapter of the history of the Indian people is the story of their early life. The Indian people have lived in this country for many centuries, and their history is a testament to their resilience and strength. The Indian people have a rich and varied culture, and their history is a testament to their resilience and strength.

The third chapter of the history of the Indian people is the story of their early life. The Indian people have lived in this country for many centuries, and their history is a testament to their resilience and strength. The Indian people have a rich and varied culture, and their history is a testament to their resilience and strength.



portar. But contamination with sulphur often makes it dangerous, as explained above.

Having now considered the qualities of cement, fine aggregates, and coarse aggregates, we may now consider the general principles of proportioning sand, stone, and cement, because production of a good concrete depends not only upon using the best materials, but also upon the best combination of mixture which will give the minimum voids, that is the densest mixture.

Voids -- Concrete can be considered as a mass of stones having certain spaces or voids between them. These voids are then filled with sand, which in turn contains voids. The voids in the sand are not so obvious as those between the stones, but in fact there is often about the same proportion of voids in sand as in the stone. The voids in the sand are finally filled with cement.

Now the main question is how to determine the voids contained in the sand and stone. A good method is to make a few trial mixtures of several different proportions and to find the voids in each. Thus take one part of sand mixed with $1\frac{3}{4}$, 2, and $2\frac{1}{2}$ parts of stone, and a vessel of about 3 cubic feet content, having a depth of about twice its diameter, and this may be filled with each of these mixtures in turn. If the voids in

each case are then filled in with water, and this water measures, then the mixture requiring the addition of least water to fill up to the top surface is the densest of the three and has the least voids. Another method of finding out which one is the densest mixture among those three is to weigh them separately. The heaviest one will be the one containing the densest mixture. Generally about twice as much stone is required as sand for the best mixture.

The quantity of cement must be sufficient to fill all interstices and to form an adhesive material between all particles. The cement should not have a volume less than one half of the sand, and more may be desirable. It should be noted that whatever the proportions of mixing may be, the materials are always measured by volume and not by weight because of the greater ease this way and the varying density of the stone aggregates.

It is impossible at present to make a concrete entirely without voids, because when the concrete is mixed with water in the mixing, this water represents a considerable volume. Although part of this water enters into chemical combination with the cement, the larger part does not, but subsequently evaporates and is replaced by air. It becomes clear from this that an excess of water in concrete reduces the strength because of these incipient holes. So dry mixtures have greater strength than moist ones and it should be mixed as dry as possible and laid down only by ease of mixing and placing.

With insufficient water, curiously enough, lack of density also results because the sand and cement particles have not

sufficient water to act as a lubricant, so as to ease them into the voids between the larger particles, and therefore they require less intimate contact.

Watertight Concrete -- Probably no concrete ever has been, nor ever will be made that does not contain a remaining small percentage of voids. But for all ordinary purposes concrete can be made practically watertight. The simplest way of doing this is to so proportion well graded materials that the voids will be reduced to the lowest possible minimum. In other words, the watertight concrete is simply a denser concrete made in the ordinary way but with special care used throughout to ensure uniformity of the best practise in mixing and placing and ramming.

To produce a watertight concrete it is absolutely necessary to note the following points:

- (1) The proportion of mix should **not** be leaner than $1:2\frac{1}{2}:3\frac{1}{4}$, however a $1:2:3$ mix is preferable.¹
- (2) Only clean, uncoated aggregates should be used, and the proportion of these aggregates should be well balanced in order that the voids will be reduced to the lowest possible minimum.
- (3) The concrete must be thoroughly mixed. Each batch should be carefully measured so that the concrete in all parts of the structure are of the same constitution.
- (4) In placing the concrete we must see that **it is** well tamped and we should guard against rock pockets and

¹ Engineering Bulletin, Purdue University, Vol. XVI, No. 1 (January, 1932) pp. 103

seams between successive batches.

(6) The joints between each successive days' work should first be gone over with a hammer and chisel or compressed air chisel and then should be covered with $\frac{1}{2}$ in. of mortar composed of two parts of sand to one of cement on the old work and then followed by the concrete on to this at once.

(7) Keep the concrete damp for several days.

The Mixing of Concrete -- (a) Hand mixing: The mixing of concrete by hand will give good results, if carefully and thoroughly done. This method of mixing is very economical for small jobs, where only a few batches are needed. The batches in hand mixing should be small, preferably less than one cubic yard, and of such a size that all concrete in any one batch can be put in place in less than half an hour (before initial set occurs).

In mixing a batch, the mixing platform, preferably about 7 x 12 ft. or larger in size should be made of tongued and grooved plank, 2 in. thick and must be set level in a convenient place and the fine aggregate (sand) is first measured and placed on the mixing platform in a flat pile. The cement after measuring is then evenly spread over the top of the fine aggregate. (only one measuring box should be allowed in use to prevent mistakes). Then two workmen mix the cement and the fine aggregate by turning the mix two or three times, until the material is of uniform color. In this work the two should stand facing each other at one end of the pile and they work their shovels close to the platform diagonally towards each other, turning the shovels when

they meet. There is a knack to this shovel work, which may be acquired by experience. If the batch is somewhat larger than two men can start at each end of the pile and work towards the center.

After the cement and fine aggregate are mixed, the mass is leveled off and the coarse aggregate measured, wetted, and spread over the pile. The batch is again turned two or three times, and then "troughed" or "ditched" in the center, and then the mixing water added by pouring into the center. (This water should be carefully measured so that the same amount can be used for each batch of the same size). Then the edges of the dry materials must be turned over into the water, care being taken to prevent the escape of any water. After the materials have been turned into the water, the whole batch is turned over several by the spade until it appears to have a uniform consistency, usually about 5 turnings are required for thorough mixing, but most workers stop after two or three turnings. When one can feel the mixing, it is convenient for him to mix the dry materials thoroughly in a box with a hoe, after which the water is added and the mass thoroughly mixed again. The mixing platform and whatever tools are used should be washed clean at the end of the day's work.

(b) Machine mixing: Machine mixing of concrete is usually much better, quicker, and more economical than hand mixing, and should be required when the amount of work is sufficient to make machine mixing economical.

There are two kinds of machine mixer, continuous and batch. The continuous mixer is rarely used, because the batch

ing. In a batch mixer, a batch of materials is added to the machine, then mixed and discharged, and the cycle repeated for succeeding batches. The time required for mixing depends on the type, speed and condition of the machine, and varies for different machines. Most machines are designed to mix the materials in about one minute. Therefore in any machine mixer, the time of mixing should not be less than one minute. Mixing for a longer time, even up to 30 minutes will not harm the concrete.

At the end of each day's work, the mixer should be thoroughly washed and cleaned out. Any cake concrete adhering to the drum or blades should be broken loose and removed.

The materials used must be also carefully and accurately measure , if consistent results are to be obtained. The cement and the aggregates should be measured by measuring boxes and the water also measured. Measuring aggregates by the shovelful should not be permitted.

Placing of Concrete -- It is absolute necessary that the concrete be carried from the mixer to the form before the initial set has occurred; that no part of the concrete will be lost in transporting; and that no segregation of the materials be allowed to take place. These points must be observed and then also a careful deposition of the concrete in the forms is necessary, because no faults in the mix or in the placing can be corrected later after setting.

Before depositing the concrete in the form, any dirt or other debris should be removed from the forms, and the surfaces of the forms thoroughly wetted or oiled.

The time required for transporting and depositing should not be more than 30 minutes. On large jobs the concrete is transported by crane, barrels, buckets and derricks, wheelbarrows and spouts. Whatever method be used, the flow of the concrete from the mixer to the form should be continuous, until that particular section of the form has been filled. It is advisable to keep the surface of the concrete approximately horizontal in wall, column, or footing forms while the junction plane in beams or slabs between batches should be nearly vertical. As nearly as practical work should be complete in units before high-fall but for special work stop mixing may be needed.

After the concrete has been deposited in the form, it should be thoroughly compacted. The tools used are shovels, spades, rods, tamping bars, etc. Spreading the concrete near to the surface of the form tends to make a smooth surface without air pockets. The concrete must be thoroughly worked into the corners of the forms and around the reinforcement. Tamping and rodding tend to remove air voids and increases the density and strength of the concrete. If the mix is too wet or sloppy, too much tamping may tend to cause segregation of the materials. The compacting of concrete in this form cycle helped by hammering the outside of the forms opposite the area of deposited concrete. The forms should fit so closely in their joint between the boards so as not to let cement or even water escape.

Retempered or reaired concrete or mortar that has set off of its initial set should not be allowed to be placed in the form.

TABLE X

AREAS, WEIGHTS, PERIMETERS & SPACING OF BARS

AREA OF STEEL AND ΣO PER FOOT, SPACING AS SHOWN																	
SIZE IN INCHES	AREA OF ONE BAR SQ. IN.	WEIGHT OF ONE BAR PER FOOT	3½"	4"	4½"	5"	5½"	6"	6½"	7"	7½"	8"	8½"	9"	10"	11"	12"
3⅞"	.1104	.375	ΣO	4.03	3.14	2.83	2.57	2.35	2.17	2.02	1.88	1.76	1.66	1.59	1.41	1.29	1.18
			AREA	.38	.29	.26	.24	.22	.20	.19	.18	.16	.15	.14	.13	.12	.11
1½"	.1963	.667	ΣO	5.38	4.71	3.77	3.42	3.14	2.90	2.69	2.51	2.36	2.22	2.09	1.88	1.73	1.57
			AREA	.67	.59	.52	.47	.39	.36	.33	.31	.29	.28	.26	.23	.21	.20
1¼"	.250	.850	ΣO	6.86	6.00	5.33	4.80	4.00	3.69	3.43	3.20	3.00	2.83	2.67	2.40	2.18	2.00
			AREA	.86	.75	.67	.60	.50	.46	.43	.40	.37	.35	.33	.30	.27	.25
5⅝"	.3068	1.043	ΣO	6.73	5.89	5.24	4.72	3.93	3.62	3.37	3.14	2.95	2.77	2.62	2.36	2.16	1.96
			AREA	1.05	.92	.82	.73	.61	.55	.52	.49	.46	.43	.41	.37	.34	.31
3¼"	.4418	1.502	ΣO	8.06	7.07	6.27	5.64	4.71	4.34	4.03	3.76	3.52	3.32	3.14	2.82	2.59	2.36
			AREA	1.51	1.32	1.18	1.06	.88	.81	.76	.71	.66	.62	.59	.53	.48	.44
7⅛"	.6013	2.044	ΣO	9.42	8.25	7.33	6.60	5.50	5.07	4.71	4.40	4.12	3.88	3.66	3.30	3.02	2.75
			AREA	2.06	1.80	1.60	1.44	1.31	1.20	1.11	1.03	.96	.90	.85	.80	.72	.66
1"	.7854	2.670	ΣO	10.77	9.42	8.38	7.55	6.28	5.80	5.38	5.02	4.71	4.44	4.18	3.77	3.45	3.14
			AREA	2.70	2.35	2.10	1.88	1.71	1.57	1.45	1.35	1.26	1.18	1.11	1.05	.94	.86
1"	1.000	3.400	ΣO	13.70	12.00	10.66	9.60	8.00	7.38	6.86	6.40	6.00	5.65	5.33	4.80	4.36	4.00
			AREA	3.43	3.00	2.67	2.40	2.00	1.85	1.71	1.60	1.50	1.41	1.33	1.20	1.09	1.00
1⅝"	1.2656	4.303	ΣO	15.44	13.50	12.00	10.80	9.00	8.30	7.72	7.20	6.75	6.36	6.00	5.40	4.91	4.50
			AREA	4.34	3.80	3.38	3.04	2.76	2.53	2.34	2.17	2.03	1.90	1.79	1.69	1.52	1.38
1¼"	1.5625	5.313	ΣO	17.14	15.00	13.33	12.00	10.00	9.23	8.57	8.00	7.50	7.06	6.66	6.00	5.46	5.00
			AREA	5.36	4.69	4.17	3.75	3.41	3.13	2.89	2.68	2.50	2.34	2.21	2.08	1.87	1.70

ROOM USE ONLY

ROOM USE ONLY

MICHIGAN STATE UNIVERSITY LIBRARIES



3 1293 03145 6308